# SERVICE MANUAL RA-2A CHASSIS

**MODEL** 

MODEL

COMMANDER DEST. CHASSIS NO.


COMMANDER DEST. CHASSIS NO.

KP-48S65R


RM-Y136A

US S

SCC-N65J-A











#### **SPECIFICATIONS**

**Projection system** 3 picture tubes, 3 lenses,

horizontal in-line system

**Picture tube** 7 inch high-brightness

monochrome tubes (6.3 raster size), with optical coupling and

liquid cooling system

**Projection lenses** High performance, large-

diameter hybrid lens F1.1

**Screen size** 48 inches (measured diagonally)

Television system Channel coverage

American TV standards VHF: 2 – 13 / UHF: 14 – 69 /

CATV: 1 - 125

VIDEO IN 1

Antenna 75 ohm external antenna

terminal for VHF/UHF

Inputs/output

VIDEO IN 2 (VIDEO 2 INPUT)

S VIDEO (4-pin mini DIN):

Y: 1 Vp-p, 75-ohms unbalanced, sync negative C: 0.286 Vp-p (Burst signal)

75 ohms

VIDEO (phono jack): 1 Vp-p, 75-ohms unbalanced, sync

negative

AUDIO (phono jacks): 500 mVrms (100% modulation) Impedance : 47 kilohms

VIDEO IN 3

VIDEO (phono jacks): 1 Vp-p, 75-ohms unbalanced, sync

negative

AUDIO (phono jacks): 500 mVrms (100% modulation) Impedance: 47 kilohms

MONITOR OUT

VIDEO (phono jack): 1 Vp-p, 75-ohms unbalanced, sync

negative

AUDIO (phono jacks): 500 mVrms

(100% modulation), Impedance: 10 kilohms

AUDIO OUT (phono jacks): 900 mVrms (100% modulation) Impedance: 5 kilohms **Speaker** Full range speaker 100 mm (3.9

inches) diameter

Speaker output 15 W x 2

Power requirement 120 V AC, 60 Hz

Power consumption 165 W

Standby mode: 3 W

**Dimensions** 1,106 x 1,337 x 571 mm (W/H/D)

(43 <sup>5</sup>/8 x 52 <sup>5</sup>/8 x 22 <sup>1</sup>/2 inches)

**Mass** 67 kg (147 lbs 11 oz)

Supplied accessories Remote control RM-Y136A (1)

Size AA (R6) battery (2)

Optional accessories U/V mixer EAC-66

Connecting cables RK-74A, RK-G34, VMC-810S/820S, YC-15V/30V High-contrast protective screen

SCN-48X2

Design and specifications are subject to change without notice.

## SAFETY CHECK-OUT

After correcting the original service problem, perfom the following safety checks before releasing the set to the customer:

- Check the area of your repair for unsoldered or poorly-soldered connections. Check the entire board surface for solder splashes and bridges.
- 2. Check the interboard wiring to ensure that no wires are "pinched" or contact high-wattage resistors.
- Check that all control knobs, shields, covers, ground straps, and mounting hardware have been replaced. Be absolutely certain that you have replaced all the insulators.
- 4. Look for unauthorized replacement parts, particularly transistors, that were installed during a previous repair. Point them out to the customer and recommend their replacement.
- Look for parts which, through functioning, show obvious signs of deterioration. Point them out to the customer and recom mend their replacement.
- 6. Check the line cords for cracks and abrasion. Recommend the replacement of any such line cord to the customer.
- 7. Check the condition of the monopole antenna (if any). Make sure the end is not broken off, and has the plastic cap on it. Point out the danger of impalement on a broken antenna to the customer, and recommend the antenna's replacement.
- Check the B+ and HV to see they are at the values specified.
   Make sure your instruments are accurate; be suspicious of your HV meter if sets always have low HV.
- Check the antenna temminals, metal trim, "metallized" knobs, screws, and all other exposed metal parts for AC leakage. Check leakage as described below.


#### **LEAKAGE TEST**


The AC leakage from any exposed metal part to earth ground and from all exposed metal parts to any exposed metal part having a return to chassis, must not exceed 0.5mA (500 microampers). Leakage current can be measured by any one of three methods.

- A commercial leakage tester, such as the Simpson 229 or RCA WT-540A. Follow the manufacturers' instructions to use these instruments.
- 2. A battery-operated AC milliammeter. The Data Precision 245 digital multimeter is suitable for this job.
- 3. Measuring the voltage drop across a resistor by means of a VOM or battery-operated AC voltmeter. The "limit" indication is 0.75V, so analog meters must have an accurate low-voltage scale. The Simpson 250 and Sanwa SH-63Trd are examples of a passive VOM that is suitable. Nearly all battery operated digital multimeters that have a 2V AC range are suitable. (See Fig. A)

#### **HOW TO FIND A GOOD EARTH GROUND**

A cold-water pipe is guaranteed earth ground; the cover-plate retaining screw on most AC outlet boxes is also at earth ground. If the retaining screw is to be used as your earth-ground, verify that it is at ground by measuring the resistance between it and a cold-water pipe with an ohmmeter. The reading should be zero ohms. If a cold-water pipe is not accessible, connect a 60-100 watts trouble light (not a neon lamp) between the hot side of the receptacle and the retaining screw. Try both slots, if necessary, to locate the hot side of the line, the lamp should light at normal brilliance if the screw is at ground potential. (See Fig. B)







### **TABLE OF CONTENTS**

Section		Title	Page	Sec	ction	Title	Page	
1.	GENERAL							
	Step 1: Installing Step 2: Hook up Step 3: Setting up Step 4: Setting up Changing the men Watching the TV Watching two prog Freezing the pictur Adjusting the colo Selecting the vider Adjusting the sour Using audio effect	the projection TV  the remote control the projection TV automatically (AUTO SE u language  grams at one time-PIP tre (FREEZE) ure (VIDEO) tre temperature (TRINITONE) to mode (VIDEO) to d (AUDIO) (SURROUND) to bilingual programs (MTS)		4. 5.	SAF	High-Voltage Cable Installation and Removal	25 y 26 27 xet 27 28 41	
	Setting the speaker Setting audio out ( Setting daylight sa Setting the clock ( Setting the timer to to Customizing the cl Blocking out a cha Setting your favor Setting video label Setting Caption Vi Operating video et Operating a cable Troubleshooting	rs witch (SPEAKER)		6.	6-1. I	Block Diagram (1)		
2.	<ul><li>2-2. Chassis As</li><li>2-3. Service Pos</li></ul>	Y  1 Removalsy RemovalsitionRemoval	24 24	7.	7-1. ( 7-2. (	Cover	86	
	2-5. Beznet Ass	sy Removaler Assy Removal	25	8.	ELE	CTRICAL PARTS LIST	88	

### (CAUTION)

SHORT CIRCUIT THE ANODE OF THE PICTURE TUBE AND THE ANODE CAP TO THE METAL CHASSIS, CRT SHIELD, OR CARBON PAINTED ON THE CRT, AFTER REMOVING THE ANODE.

#### WARNING!!

AN ISOLATION TRANSFORMER SHOULD BE USED DURING ANY SERVICE TO AVOID POSSIBLE SHOCK HAZARD, BECAUSE OF LIVE CHASSIS.

THE CHASSIS OF THIS RECEIVER IS DIRECTLY CONNECTED TO THE AC POWER LINE.

### **SAFETY-RELATED COMPONENT WARNING!!**

COMPONENTS IDENTIFIED BY SHADING AND MARK  $\triangle$  ON THE SCHEMATIC DIAGRAMS, EXPLODED VIEWS AND IN THE PARTS LIST ARE CRITICAL TO SAFE OPERATION. REPLACE THESECOMPONENTS WITH SONY PARTS WHOSE PART NUMBERS APPEAR AS SHOWN IN THIS MANUAL OR IN SUPPLEMENTS PUBLISHED BY SONY. CIRCUIT ADJUSTMENTS THAT ARE CRITICAL TO SAFEOPERATION ARE IDENTIFIED IN THIS MANUAL. FOLLOW THESE PROCEDURES WHENEVER CRITICAL COMPONENTS ARE REPLACED OR IMPROPER OPERATION IS SUSPECTED.

# SECTION 1 GENERAL

The operating instructions mentioned here partial abstracts from the Operating Instructions Manual. The page numbers of the Operating Instruction Manual remain as in the manual.(part.no: 3-862-541-41)

## Welcome!

Thank you for purchasing the Sony Color Rear Video Projection TV. Here are some of the features you will enjoy with your projection TV:

- On-screen menus that let you set the picture quality, sound, and other settings.
- Two tuner Picture-in-Picture (PIP) that allows you to watch another TV channel, video or cable image as a window picture.
- Surround system that simulates the sound quality of a concert hall or movie theater.
- SAVA SPEAKER option of the AUDIO menu that lets you take advantage of the Sony SAVA series speaker system's surround sound and super woofer mode when you connect it to the projection TV.

#### About this manual

Instructions in this manual are based on use of the remote control. You can also use the controls on the projection TV if they have the same name as those on the remote control.

# Precautions |

This projection TV operates on extremely high voltage. To prevent fire or electric shock, please follow the precautions below.

#### Safety

- · Operate the projection TV only on 120 V AC.
- One blade of the plug is wider than the other for safety purposes and will fit into the power outlet only one way. If you are unable to insert the plug fully into the outlet, contact your dealer.
- Should any liquid or solid object fall into the cabinet, unplug the projection TV and have it checked by qualified personnel before operating it further.
- Unplug the projection TV from the wall outlet if you are not going to use it for several days or more. To disconnect the cord, pull it out by the plug. Never pull the cord itself.

For details concerning safety precautions, see the supplied leaflet "IMPORTANT SAFEGUARDS."

#### Note on cleaning

Clean the cabinet of the projection TV with a dry soft cloth. To remove dust from the screen, wipe it gently with a soft cloth using vertical strokes only. Stubborn stains may be removed with a cloth slightly dampened with solution of mild soap and warm water. Never use strong solvents such as thinner or benzine for cleaning. If the picture becomes dark after using the projection TV for a long period of time, it may be necessary to clean the inside of the projection TV. Consult qualified service personnel.

#### Installing


- To prevent internal heat build-up, do not block the ventilation openings.
- Do not install the projection TV in a hot or humid place, or in a place subject to excessive dust or mechanical vibration.
- Avoid operating the projection TV at temperatures below  $5^{\circ}C$  (41  $^{\circ}F).$
- If the projection TV is transported directly from a cold to a warm location, or if the room temperature has changed suddenly, the picture may be blurred or show poor color. This is because moisture has condensed on the mirror or lenses inside. If this happens, let the moisture evaporate before using the projection TV.
- To obtain the best picture, do not expose the screen to direct illumination or direct sunlight. It is recommended to use spot lighting directed down from the ceiling or to cover the windows that face the screen with opaque drapery. It is desirable to install the projection TV in a room where the floor and walls are not of reflecting material. If necessary, cover them with dark carpeting or wall paper.

#### Getting Started

# Step 1: Installing the projection TV

For the best picture quality, install the projection TV within the areas shown below.


#### Optimum viewing area (Horizontal)



#### Carrying your projection TV

Be sure to grasp the areas indicated when carrying the projection TV, and to use more than two people.

#### (Rear of projection TV)




#### Preparing for your projection TV

EN

Before you use your projection TV, adjust convergence. For the procedure, see "Step 4: Setting up the projection TV automatically (AUTO SET UP)" on page 14.


#### Optimum viewing area (Vertical)




#### Connecting an antenna

Connect your antenna cable to the VHF/UHF antenna terminal. If you cannot connect your antenna cable directly to the terminal, follow one of the instructions below depending on your cable type.








#### Notes

0

- Most VHF/UHF combination antennas have a signal splitter. Remove the splitter before attaching the appropriate connector.
- . If you use the U/V mixer, snow and noise may appear in the picture when viewing cable TV channels over 37.


#### Connecting an antenna/cable TV system without a VCR

To cable or antenna




#### To cable box

If your cable company requires you to connect a cable box, make the connection as follows:



#### To cable box and cable




Pay cable TV systems use scrambled or encoded signals requiring a cable box\* in addition to the normal cable connection.

\* The cable box will be supplied by the cable company.

#### Note

· You cannot watch the signal through an AUX connector as a window picture.

#### To cable and antenna



• Do not connect anything to the TO CONVERTER connector in this case

#### Connecting an antenna/cable TV system with a VCR

For details on connection, see your VCR instruction manual.

cords of the equipment to be connected.

## Before making the connection, disconnect the AC power


#### To a conventional VCR

To connect a monaural VCR, connect the audio output of the VCR to AUDIO-L (MONO) of VIDEO 1/2/3 IN on the projection TV.


After making these connections, you will be able to do the following:

- · View the playback of video tapes
- · Record one TV program while viewing another program
- Watch two TV programs at once using PIP

#### Without a cable box



#### With a cable box




EN


#### To an S video equipped VCR

If your VCR has an S VIDEO output connector, make the following connections.

Whenever you connect the cable to the S VIDEO input connector, the projection TV automatically receives S video signals.

#### Without a cable box





#### Note

8-EN


Video signals are composed of Y (luminance) and C (chroma) signals. The S connection sends the two signals separately preventing degradation, and gives better picture quality compared to conventional connections.

**Getting Started** 

#### Connecting a DBS receiver


For details on connection, see the instruction manual of the DBS (Digital Broadcasting Satellites) receiver.

#### To a projection TV



#### Note


· You can use the S VIDEO connector or the composite video connector for the video connection.



Getting Started

#### Connecting a camcorder

Use this connection to view a camcorder picture.




 $\infty$ 

 To connect a monaural camcorder, connect the audio output of the camcorder to AUDIO-L (MONO) of VIDEO 2 INPUT on the projection TV.


#### Connecting an audio system

When connecting audio equipment, see page 28 for more information.




#### Connecting two VCRs for tape editing using MONITOR OUT

You can record input images displayed on the screen. This type of connection should be used only when you connect from the line input of one VCR, and from the line output of a second VCR.



#### Notes

- Do not change the input signal while editing through MONITOR OUT, or the output signal will also change.
- You can use the S video jack to connect a VCR for playback and the composite video connector to connect a VCR for recording.
- · When connecting a single VCR to the projection TV, do not connect the MONITOR OUT to the VCR's line input, while at the same time connecting from the projection TV's VIDEO IN connectors to the VCR's line output, as shown below.




10-EN | Getting Started

12<sup>-EN</sup>

#### Connecting a Sony SAVA series speaker system

If you have a Sony SAVA series speaker system, connect your speakers to the AUDIO (VAR./FIX) OUT jacks on the rear of the projection TV with the audio cable supplied with the speakers. You can take advantage of the speakers' Dolby Pro Logic\* surround system and super woofer mode, and control them with the supplied remote control. When connecting a Sony SAVA series speaker system, see page 27 for more information.

\* Manufactured under license from Dolby Laboratories Licensing Corporation. Additionally licensed under Canadian patent number 1,037,877. "Dolby," the double-D symbol □ and "Pro Logic" are trademarks of Dolby Laboratories Licensing Corporation.



# Step 3: Setting up the remote control

#### Inserting batteries

Insert two size AA (R6) batteries (supplied) by matching the + and – on the battery to the diagram inside the battery compartment.





#### Notes

- Under normal conditions, batteries will last up to six months.
   If the remote control does not operate properly or the
   indicators of the buttons on the remote control do not light up,
   the batteries may be worn out. When replacing batteries,
   replace both of them with new ones.
- Do not mix old batteries with new ones or mix different types of batteries together.
- If the electrolyte inside the battery should leak, wipe the contaminated area of the battery compartment with a cloth and replace the old batteries with new ones. To prevent the electrolyte from leaking, remove the batteries when you don't plan to use the remote control for a long period of time.
- Do not handle the remote control roughly. Do not drop it, step on it, or let it get wet.
- Do not place the remote control in direct sunlight, near a heater, or where the humidity is high.

# Getting to know buttons on the remote control

Names of buttons on the remote control are indicated in different colors to represent the available functions.

#### Button color

Transparent ....... TV/VCR/DBS/Cable box function (light up) buttons. Press the appropriate function button first to change the remote control's function.


Green ...... Buttons relevant to power operations.

#### Label color

White .......TV/VCR/DBS/Cable box operation buttons.

Yellow ...... PIP operation buttons.

Blue ...... DBS operation buttons.



EN

Getting Started Getting Started 13-EN

# Step 4: Setting up the projection TV automatically (AUTO SET UP)

You can set up your projection TV easily by using the AUTO SET UP feature. It presets all the receivable channels, adjusts the convergence and changes the onscreen menu language. To set up the projection TV manually, see "Adjusting convergence" (page 16), "Setting cable TV on or off" (page 17), "Presetting channels" (page 18) and "Changing the menu language" (page 18).

If the projection TV is set to a video input, you cannot perform AUTO SET UP. Press TV/VIDEO so that a channel number appears.

(Front of projection TV)



Before you start using AUTO SET UP, be sure to connect the antenna or cable to the projection TV (see page 6).

1 Press POWER to turn the projection TV on.



2 Press SETUP on the front of the projection


AUTO SET UP screen appears.





3 Press CHANNEL +/- or VOLUME + to select the on-screen menu language.

If you prefer Spanish or French to English, you can change the on-screen menu language.



All of the menus will be set to the factory preset condition in the selected language.

4 Press VOLUME - to start AUTO SET UP.





5 Press CHANNEL + to preset channels.





"AUTO PROGRAM" appears on the screen and the TV starts scanning and presetting channels automatically. When all the receivable channels are stored, "AUTO PROGRAM" disappears and the following menu appears. If the projection TV receives cable TV channels, CABLE is set to ON automatically.

YES: [CH+] NO: [CH-]

To exit AUTO PROGRAM

Press any button.

6 Adjust convergence.

(1) Press CHANNEL +.

The CONVERGENCE adjustment screen






(2) Press TV/VIDEO to select RED or BLUE.






(3) Using CHANNEL +/- or VOLUME +/-, move the line until it converges with the center green



To move horizontal line up/down, press CHANNEL

To move vertical line right/left, press VOLUME +/-.

(4) Repeat steps (2) and (3) to adjust the other lines until all three lines converge and are seen as a white cross.



 Using the AUX connector, press TV (black button) first and make sure that "AUX" is displayed beside the channel number on the screen. Then follow the steps 2 to 6 above to perform

To preview the main functions (DEMO)


Press TV/VIDEO on the projection TV in step 4. The functions and menus are displayed one by one.

To exit DEMO

Press any button.

#### Erasing or adding channels

After AUTO SET UP, you can erase unnecessary channels or add the channels you want. Preset channels during the day rather than late at night, when some channels may not be broadcasting.



1 Press TV (FUNCTION).



2 Press MENU.

The main menu appears.





EN

3 Press ★ or ★ to select 🖶, and press 🕀. The SET UP menu appears.








14-EN Getting Started


4 Press ★ or ★ to select CHANNEL ERASE/ADD, and press ★.

The CHANNEL ERASE/ADD menu appears.





- 5 Erase and/or add channels:
  - To erase an unwanted channel
  - (1) Make sure the cursor (▶) is beside ERASE.
  - (2) Press CH +/- or the 0 9 buttons to select the channel you want to erase, and press ENTER.



(3) Press 🕩 .

The "-" indication appears beside the channel number, showing that the channel is erased from the preset memory.



To add a channel that you want

- (1) Press ♠ or ♥ to move the cursor (▶) to ADD.
- (2) Press the 0 9 buttons to select the channel you want to add, and press ENTER.

#### Selected channel number





(3) Press (±).

16-EN

The "+' indication appears beside the channel number, showing that the channel is added to the preset memory.



6 To erase and/or add other channels, repeat step 5.

7 Press MENU to return to the original screen.



#### Notes

- If you erase or add a VHF or UHF channel, the cable TV channel with the same number is also erased or added, and vice versa
- Erasing and adding channels is also available for the AUX input.


# Adjusting convergence (CONVERGENCE)

The projection tube image appears on the screen in three layers (red, green and blue). If they do not converge, the color is poor and the picture blurs. To correct this, adjust convergence.

You do not have to do this procedure if you perform AUTO SET UP (page 14). Do this procedure only when you want to adjust it manually.

- 1 Press MENU.
- 2 Press ★ or ★ to select 🖶 , and press 🐳 .
- 3 Press ♠ or ♦ to select CONVERGENCE, and press ↔.


The CONVERGENCE adjustment screen appears.



4 Press ♠, ♠, ♠, or ➤ to move the cursor (►) to the symbol showing the line you want to adjust, and press (+).



- +RED: Red vertical and horizontal line (left/right/up/down adjustment)
- +BLUE : Blue vertical and horizontal line (left/right/up/down adjustment)



To move	Press	
Up	+	
Down	+	
Right	+	
Left	+	

- 6 Repeat steps 4 and 5 to adjust the other lines until all three lines converge and are seen as a white cross.
- 7 Press MENU to return to the original screen.

#### Setting cable TV on or off

If you have connected the projection TV to a cable TV system, set CABLE to ON (the factory setting). If not, set CABLE to OFF.

You do not have to do this procedure if you perform AUTO SET UP (page 14). Do this procedure only when you want to set it manually.

- 1 Press MENU.
- 2 Press ★ or ★ to select ♠, and press ↔.
- 3 Set CABLE to ON or OFF:
  - (1) Press ♠ or ♣ to move the cursor (▶) to CABLE, and press ♠.
  - (2) Press ★ or ♥ to select ON or OFF, and press ④.







4 Press MENU to return to the original screen.

#### Note

 If CABLE appears in gray, the projection TV is set to a video input and you cannot select CABLE. Press TV (black button) so that a channel number appears.

Getting Started 17-EN

#### Presetting channels

You can preset TV channels easily by using the AUTO PROGRAM feature.

You do not have to do this procedure if you perform AUTO SET UP (page 14). Do this procedure only when you want to set it manually.

- 1 Press MENU.
- 2 Press ★ or ★ to select 🖶, and press 🛨.
- 3 Press ★ or ♥ to select AUTO PROGRAM, and press 🛨.







"AUTO PROGRAM" appears on the screen and the projection TV starts scanning and presetting channels automatically. When all the receivable channels are stored, "AUTO PROGRAM" disappears and the lowest numbered channel is displayed.

4 Press MENU to return to the original screen.

#### To exit AUTO PROGRAM

Press any button.

#### Notes

- If the AUTO PROGRAM menu appears in gray, the projection TV is set to a video input and you cannot select AUTO PROGRAM. Press ANT button so that a channel number
- Presetting channels is also available for the AUX input.

# Changing the menu language

If you prefer Spanish or French to English, you can change the menu language.

You do not have to do this procedure if you select the language during AUTO SET UP (page 14). Do this procedure only when you want to set it manually.

- 1 Press MENU.
- 2 Press ★ or ★ to select ♠, and press ↔.
- 3 Press ★ or ★ to select LANGUAGE, and press







4 Press ★ or ★ to select your favorite language, "ENGLISH", "ESPAÑOL," or "FRANÇAIS" and press .








5 Press MENU to return to the original screen.

· Certain parts of the Spanish or French menus remain in English.

#### Operations

# Watching the TV



1 Press TV (POWER) to turn on the projection

The TIMER/STANDBY indicator flashes until the picture appears.



If "VIDEO" appears on the screen, press ANT so that a channel number appears.

2 Press TV (FUNCTION).



Once you press TV (FUNCTION), the projection TV function is set unless another function button is pressed.

3 Select the channel you want:

To select a channel directly

Press the 0 - 9 buttons, and press ENTER. For example, to select channel 10, press 1, 0 and ENTER.



To scan through channels

Press CH +/- until the channel you want appears.



The channel can also be selected without pressing

4 Press VOL +/- to adjust the volume.





EN

Switching quickly between two channels

You can use the JUMP button to switch or "jump" back and forth between two channels.

Press JUMP.



Pressing JUMP again switches the channel back to the one you selected last.

Note

 You cannot jump to channels you scanned through using the CH +/- buttons

#### Muting the sound

Press MUTING.

"MUTING" appears on the screen.



To restore the sound, press MUTING again, or press Operations |19-EN

#### Displaying on-screen information

#### Press DISPLAY repeatedly until the desired display appears.

Each time you press DISPLAY, the display changes as follows:

Status display\*  $\rightarrow$  XDS ON\*\*  $\rightarrow$   $\boxed{cc}$  1 ON\*\*\* — DISPLAY OFF ←

- \* Channel number, the current time, channel caption (if set), and MTS mode (if SAP is selected) are displayed. SAP indication disappears after three
- \*\* Some programs are broadcast with XDS (Extended Data Service) which shows a network name. program name, program type, program length, call letters, and time of the show. When you select XDS with the DISPLAY button, this information will be displayed on the screen if the broadcaster offers this
- \*\*\* Some programs are broadcast with Caption Vision. When you select Caption Vision with the DISPLAY button, Caption Vision will be displayed on the screen if the broadcaster offers this service. (See page 34 for selecting Caption Vision.)

To cancel the display, press DISPLAY repeatedly until "DISPLAY OFF" appears. "DISPLAY OFF" goes off after three seconds.

#### Setting the Sleep Timer

The projection TV stays on for the length of time you specify and then shuts off automatically.

#### Press SLEEP repeatedly until the time (minutes) you want appears.

Each time you press SLEEP, the time changes as follows:

$$30 \rightarrow 60 \rightarrow 90 \rightarrow \text{SLEEP OFF}$$

SLEEP

To cancel the Sleep Timer, press SLEEP repeatedly until "SLEEP OFF" appears, or turn off the projection

20-EN Operations

#### Watching a video input picture

#### Press TV/VIDEO repeatedly until the desired video input appears.

Each time you press TV/VIDEO, the display changes as follows:



To return to the TV picture, press ANT so that a channel number appears.

#### Changing the VHF/UHF input to the **AUX** input

#### Press ANT.


"AUX" appears beside the channel number.



Pressing ANT again switches back to the VHF/UHF

# Watching two programs at one time — PIP


The Picture-in-Picture (PIP) feature allows you to watch both the main picture and a window picture simultaneously.




Use the yellow labelled buttons for PIP operations.

#### Displaying a window picture

#### Press PIP.



#### Press PIP again to display a smaller window picture. Input-source mode or TV



To remove the window picture, press PIP again.

· The window picture may be affected by the condition of the main picture

#### Changing the window picture input mode

#### Press TV/VIDEO (yellow labelled button) to select the input mode.

Each time you press TV/VIDEO (yellow labelled button), "TV", "VIDEO 1", "VIDEO 2", and "VIDEO 3" appear in sequence.





A window picture will appear in the same input mode as the last time you used PIP.

· If you connect your VCR without a cable box, your PIP input source is a VCR. If you connect your VCR with a cable box, your PIP input source is a VCR or cable box.

#### Listening to the sound of the window picture

#### Press AUDIO.

The → display appears next to the PIP channel number for a few seconds, indicating that the window picture sound is being received.






To restore the main picture sound, press AUDIO again. The → display moves to the main picture channel number.

#### Changing TV channels in the window picture

Press CH +/- (yellow labelled button).





#### Changing the position of the window picture

#### Press POSITION.

Each time you press POSITION, the window picture will move counterclockwise on the screen.






#### Swapping the main and window pictures

#### Press SWAP.

Each time you press SWAP, the images and sound from the main and window pictures switch places with another.





#### Note

 The channels being received through the AUX connector cannot be displayed as a window picture.

# Freezing the picture (FREEZE)

The FREEZE feature is useful when you want to write down an information such as a recipe from a cooking program, a displayed address, or a phone number. The frozen picture changes as follows depending on whether the PIP function is used or not.



Press FREEZE.



#### When the PIP function is not being used







The frozen picture appears in the

To remove the frozen window picture, press FREEZE

#### When the PIP function is being used




To cancel the frozen window picture, press FREEZE

# Adjusting the picture (VIDEO)

When watching TV programs, you can adjust the picture to suit your taste.

You can adjust the picture of video input(s) as well.



- 1 Press MENU.
- 2 Press or to select III, and press .







- 3 Select the item you want to adjust. For example:
  - (1) To adjust the brightness, press ★ or ▼ to move the cursor (►) to BRIGHTNESS.





(2) Press (+)





- 4 Adjust the selected item:
  - (1) Press ♠, ♠, ♥, or ▶ to adjust the item.





(2) Press (+).

The new setting appears in the VIDEO menu.





For details on each item, see "Description of adjustable items" below.

- 5 To adjust other items, repeat steps 3 and 4.
- 6 Press MENU to return to the original screen.

#### Description of adjustable items

Item	Press + or + to	Press ⇒ or ★ to
PICTURE	Decrease picture contrast and give soft color.	Increase picture contrast and give vivid color.
HUE	Make picture tones become purplish.	Make picture tones become greenish.
COLOR	Decrease color intensity.	Increase color intensity
BRIGHTNES	S Darken the picture.	Brighten the picture.
SHARPNESS	Soften the picture.	Sharpen the picture.

#### To restore the factory settings

Press RESET after displaying and selecting the VIDEO

All of the settings are restored to the factory settings.

# Adjusting the color temperature (TRINITONE)

The TRINITONE feature controls the color temperature, permitting white balance preference adjustment without affecting skin tones.



- 1 Press MENU.
- 2 Press ★ or ♦ to select iii and press ↔.
- 3 Press ♦ or ♦ to select TRINITONE and press







4 Press ★ or ★ to select NTSC STD, MEDIUM, or HIGH and press ⊕.





Choose	То	
HIGH	a cool (bluish) white.	
MEDIUM	a neutral white.	
NTSC STD	a warm (reddish) white.	

# Selecting the video mode (VIDEO)

The video mode feature allows you to choose three different modes of picture settings. Choose the one that best suits the type of program that you want to watch.

- 1 Press MENU
- 2 Press or to select •, and press •.
- 3 Press ★ or ★ to select MODE, and press ⊕.
- 4 Press ★ or ▼ to select STANDARD, MOVIE, or SPORTS mode, and press ⊕.





То
Receive a standard picture.
Receive a finely detailed picture.
Receive a vivid, bright picture.


5 Press MENU to return to the original screen.

#### Note

The settings for these modes can be adjusted in the VIDEO menu.

# Adjusting the sound (AUDIO)

You can adjust the quality of the TV sound to suit your taste. You can adjust the sound of the video input(s) as well.



- 1 Press MENU.
- 2 Press ★ or ★ to select ♪, and press ⊕.







- 3 Select the item you want to adjust. For example:
  - To adjust bass, press ◆ or ▼ to move the cursor
     to BASS.





(2) Press 🛨 .





- 4 Adjust the selected item:
  - (1) Press ♠, ♠, ♣, or ▶ to adjust the item.





(2) Press (+).

The new setting appears in the AUDIO menu





For details on each item, see "Description of adjustable items" below.

- 5 To adjust other items, repeat steps 3 and 4.
- 6 Press MENU to return to the original screen.

ΕN

#### Description of adjustable items

Item	Press ♦ or ♦ to	Press + or + to
TREBLE Decrease the treble response.		Increase the treble response.
BASS Decrease the bass response.		Increase the bass response.
BALANCE	Emphasize the left speaker's volume.	Emphasize the right speaker's volume.

#### To restore the factory settings

Press RESET after displaying and selecting the AUDIO menu.

All of the settings are restored to the factory settings.

#### Note

 When SPEAKER (page 27) is OFF and AUDIO OUT (page 28) is in the FIXED condition, the volume, TREBLE, BASS, and BALANCE cannot be adjusted.


24-EN Operations | 25-EN

16

# Using audio effect (SURROUND)

The audio effect (SURROUND) feature simulates sound reproduction with the atmosphere of a movie theater or a concert hall. Audio effect is only effective for stereo programs.

#### Using the ② (audio effect) button



- 1 Press TV (FUNCTION).
- 2 Press ②.

Each time you press the @ button, the display changes as follows:

SURROUND → SURROUND OFF



#### Using the menu to set audio effect



- 1 Press MENU.
- 2 Press ★ or ★ to select ♪, and press ⊕.
- 3 Press ★ or ★ to select EFFECT, and press ⊕.







4 Press ★ or ★ to select the audio effect mode, and press .







5 Press MENU to return to the original screen.

# Selecting stereo or bilingual programs (MTS)

The Multichannel TV Sound (MTS) feature allows you to enjoy stereo sound or Second Audio Programs (SAP) of your choice. The initial setting is stereo sound (STEREO).



Press MTS repeatedly to select STEREO, SAP, or

Choose	То
STEREO	Listen to stereo sound.  The STEREO indicator on the projection TV lights up when a stereo broadcast is received.
SAP	Listen to bilingual programs. There is no sound when the SAP signal is not broadcasting.
MONO	Listen to monaural sound. Reduce noise during stereo broadcasts.

· Stereo and SAP sounds are subject to program sources.

#### To set MTS using the menu

- 1 Press MENU.
- 2 Press ♠ or ♦ to select ♪, and press ⊕.
- 3 Press ♠ or ♦ to select MTS, and press ⊕.
- 4 Press ♠ or ♦ to select STEREO, SAP, or MONO.
- 5 Press MENU to return to the original screen.

# Setting the speaker switch (SPEAKER)

You may switch off the projection TV speakers when, for example, you want to listen to the sound through a stereo system.

If you connect the Sony SAVA series speaker system to the AUDIO (VAR/FIX) OUT connectors, you can take advantage of the speakers' surround sound and super woofer mode. After making the connections (page 12), set SPEAKER to SAVA SPEAKER, then adjust SURROUND MODE or SUPER WOOFER MODE.





- 1 Press MENU.
- 2 Press ★ or ★ to select ♪, and press ⊕.
- 3 Press ★ or ★ to select SPEAKER, and press







4 Press ★ or ★ to select ON, OFF, or SAVA SP, and press .







5 Press MENU to return to the original screen.

Choose	То
ON	Listen to the sound from the
	projection TV.
OFF	Turn off the projection TV speaker
	sound and listen to the projection
	TV's sound solely through the audio
	system speakers.
SAVA SP	Turn off the projection TV speaker
	sound and listen to the projection
	TV's sound through the Sony SAVA
	series speaker system. You can adjust
	volume, muting, surround modes,
	and super woofer mode with the
	remote control supplied with the
	projection TV.

#### To select surround sound or super woofer mode of the SAVA speaker system

After setting SPEAKER to SAVA SP, follow the procedure below.

#### Press ♠ or ♣ to select SURROUND MODE or SUPER WOOFER MODE, and press .

For details on each option, refer to the operating instructions of the speaker system.







#### Note

· This feature is only for Sony SAVA speaker system with an operation capability for KP-41T65, KP-46C65, KP-48S65, KP 53S65, and KP-61S65.

# Setting audio out (AUDIO OUT)

You can change AUDIO OUT to VARIABLE or FIXED when SPEAKER is set to OFF. AUDIO OUT is variable when SPEAKER is set to ON.



- 1 Press MENU.
- 2 Press or to select ., and press ...
- 3 Press ★ or ★ to select AUDIO OUT, and press







4 Press ★ or ★ to select VARIABLE or FIXED, and press .







VARIABLE: Sound output varied according to the projection TV settings. You can adjust the volume, bass, treble, and balance.

**FIXED:** Sound output is always fixed to a certain level. The volume, bass, treble, and balance are also fixed to the factory settings.

5 Press MENU to return to the original screen.

· If AUDIO OUT appears in gray, set SPEAKER to OFF.

# Setting daylight saving time (DAYLIGHT SAVING)

If your area uses daylight saving time, change DAYLIGHT SAVING setting depending on the season, before setting the current time.

#### Daylight saving start

 After the first Sunday in April, set DAYLIGHT SAVING to YES. Current time setting (right column) automatically moves one hour ahead.

#### Daylight saving end

· After the last Sunday in October, set DAYLIGHT SAVING to NO. Current time setting automatically moves one hour back.




- 1 Press MENU.
- 2 Press ★ or ★ to select ②, and press ④.
- 3 Press ★ or ★ to select DAYLIGHT SAVING, and press (+).







4 Press ★ or ★ to select YES or NO, and press





Choose	То
YES	Set for daylight saving start.
NO	Set for daylight saving end.

5 Press MENU to return to the original screen.

# Setting the clock (CURRENT TIME SET)

Setting the clock enables you to turn the projection TV on and off with the timer. Make sure to set daylight saving time first.



- 1 Press MENU.
- 2 Press or to select •, and press •.
- 3 Press ★ or ★ to select CURRENT TIME SET, and press .







EN

Make sure the cursor (▶) is to the left of "--:-- AM," and press .





5 Set the current day of the week and time. (1) Press ♠ or ♥ to set the day of the week, and press







(2) Set the hour and minutes in the same way as in step (1). When you press (+) after setting the minutes, the clock starts.








6 Press MENU to return to the original screen.

# Setting the timer to turn the projection TV on and off (ON/OFF TIMER)

You can set the projection TV to turn on and off at the times you specify. Make sure the clock is set correctly.

If it is not, set the clock first (page 29).



- 1 Press MENU.
- 2 Press or to select ①, and press ①.
- 3 Press ★ or ★ to select ON/OFF TIMER, and press +.







- 4 Press and enter the ON/OFF TIMER setting.
  - (1) Press ★ or ♥ to set the day(s), and press ↔.

Each time you press ♠ or ♣, the days cycle as follows:

EVERY SUN-SAT→EVERY MON-FRI→  $SUNDAY \rightarrow ... \rightarrow SATURDAY \rightarrow EVERY$ SUNDAY→...→EVERY SATURDAY









(2) Press ★ or ♥ to set the time (hour then minutes) that you want to turn on the projection TV, and







(3) Press ★ or ♥ to set the time duration, and press

Each time you press ♠, the time duration increases by one hour up to a maximum of six







(4) Press ♠ or ♥ to select the channel, and press (+).





The TIMER indicator on the projection TV lights up.

- 5 To set the other program, press , and repeat step 4.
- 6 Press MENU to return to the original screen.

One minute before the projection TV turns off, the message "TV will turn off soon." is displayed on the


To cancel the timer In step 3 or 4, press RESET.

 If you unplug the projection TV or a power interruption occurs, the ON/OFF TIMER setting will be erased. Reset the current time, then set the timer.

# Customizing the channel names

(CHANNEL CAPTION)

You can add a caption for up to 12 channels. This feature allows you to easily identify which channel you are watching. You can make your own caption.



- 1 Press MENU.
- 2 Press ★ or ★ to select 🖶, and press 🛨.







3 Press ★ or ★ to select CHANNEL CAPTION, and press .







4 Press ⊕ and press ♠ or ♦ to select the channel that you want to caption, and press 🛨.









- 5 Enter the letters (up to four) to caption the
  - (1) Press ♦ or ♦ to select the first letter.

Each time you press ★ or ▼, the letter changes as follows:

0...9 ↔ A...Z ↔ &,/,\_(blank space)



(2) Press (+).





EN

- (3) Repeat steps (1) and (2) to select the remaining letters, and press +.
- 6 Repeat steps 4 and 5 to caption other

7 Press MENU to return to the original screen.

After you customize the channel, the channel caption appears green.

To erase a caption

In step 5, press RESET.


- If the CHANNEL CAPTION menu appears in gray, the projection TV is set to a video input, and you cannot select CHANNEL CAPTION. Press TV (black button) so that a channel number appears.
- If more than 90 seconds elapse after you press a button, the menu disappears automatically.
- The channel caption feature is not available for the AUX input.

30-EN Operations

Operations |31-EN

# Blocking out a channel (CHANNEL BLOCK)

The channel block feature allows you to prevent children from watching unsuitable programs. You can block out two channels.



- 1 Press MENU.
- 2 Press ★ or ★ to select 🖶, and press ↔.
- 3 Press ★ or ★ to select CHANNEL BLOCK, and








4 Press ★ or ★ to select program 1 or 2, and press 🕕.



5 Press ♣ or ♣ to select the channel which you want to block out, and press .



6 Press MENU to return to the original screen. When you select the blocked

channel, the message "BLOCKED" appears on the screen.



To cancel a CHANNEL BLOCK setting In step 4 or 5, press RESET.

#### Note

- Once you use CHANNEL BLOCK, Caption Vision and XDS of the blocked channel and the selected channel output from MONITOR OUT are also blocked out.
- 32-EN Operations

# Setting your favorite channels

(FAVORITE CHANNEL)

The favorite channel feature allows your projection TV to memorize your favorite channels easily. If you set to AUTO, the last five channels you selected with the 0 - 9 buttons are automatically set as your favorite channels. If you want to input your own selection of channels, set to MANUAL.

#### Setting your favorite channels



- 1 Press MENU.
- 2 Press ★ or ★ to select 🖶, and press 🖜.
- 3 Press ★ or ★ to select FAVORITE CHANNEL, and press (+).







4 Press ⊕ and press • or • to select AUTO or MANUAL, and press .







If you select AUTO, skip steps 5 and 6. The last five channels you selected with the 0 - 9 buttons are automatically set as your favorite

If you select MANUAL, the favorite channel numbers become white, indicating that favorite channels can be entered.

5 Press ★ or ★ to select a favorite channel







6 Press • or • to select the channel that you want to set as your favorite channel, and







7 Press MENU to return to the original screen.

- If the FAVORITE CHANNEL menu appears in gray, the projection TV is set to a video input and you cannot select FAVORITE CHANNEL.
- · If more than 90 seconds elapse after you press another button, the menu disappears automatically.
- . The favorite channel feature is not available for the AUX input.

#### Selecting your favorite channel




1 Press 🕁. The FAVORITE CHANNEL menu appears.





2 Press • or • to select the favorite channel you want to watch, and press -. The selected channel appears on the screen.



To cancel the FAVORITE CHANNEL menu Press ♠ or ♣ to select "Exit," and press ♠.

# Setting video labels (VIDEO LABEL)

The video label feature allows you to label each input mode so that you can easily identify the connected equipment. For example, you can label VIDEO 1 as VHS.



- 1 Press MENU.
- 2 Press ★ or ★ to select 🖶, and press 🕂.
- 3 Press ★ or ★ to select VIDEO LABEL, and press (+).







EN

4 Press ★ or ★ to select the input mode you want to label, and press +.







Press ★ or ▼ to select the label, and press







Each time you press ♠ or ♣, the label changes as follows:

VIDEO 1   
VIDEO 1 
$$\leftrightarrow$$
 VHS  $\leftrightarrow$  8 mm  $\leftrightarrow$  BETA   
1 DBS  $\leftrightarrow$  DVD  $\leftrightarrow$  S VIDEO  $\leftrightarrow$  LD

VIDEO 2   
VIDEO 2  $\leftrightarrow$  VHS  $\leftrightarrow$  8 mm  $\leftrightarrow$  BETA   
1 DBS  $\leftrightarrow$  DVD  $\leftrightarrow$  S VIDEO  $\leftrightarrow$  LD

VIDEO 3   
VIDEO 3  $\leftrightarrow$  VHS  $\leftrightarrow$  8 mm  $\leftrightarrow$  BETA   
1 DBS  $\leftrightarrow$  DVD  $\leftrightarrow$  LD  $\leftrightarrow$  DDBS  $\leftrightarrow$  DVD  $\leftrightarrow$  LD

6 Repeat steps 4 and 5 to label other input modes.

#### Note

20

 If more than 90 seconds elapse before you press another button, the menu disappears automatically.

# Setting Caption Vision (CAPTION VISION)

Some programs are broadcast with Caption Vision. To display Caption Vision, select either CC1, CC2, CC3, CC4, TEXT1, TEXT2, TEXT3, or TEXT4 from the menu. CC1, CC2, CC3, or CC4 shows you on-screen version of the dialogue or sound effects of a program. (The mode should be set to CC1 for most programs.) TEXT1, TEXT2, TEXT3, or TEXT4 shows you on-screen information presented using either half or the whole screen. It is not usually related to the program.



- 1 Press MENU.
- 2 Press ★ or ★ to select <sup>©</sup>C, and press ↔.







3 Press ★ or ★ to select the caption type, and press ⊕.







4 Press MENU to return to the original screen.

To display Caption Vision Press DISPLAY. (See page 20 for details.)


#### Notes

- Poor reception of TV programs can cause errors in Caption Vision and XDS.
- Captions may appear with a white box or other errors instead of a certain word.
- XDS, Caption Vision, and the status display cannot be used at the same time.
- For details on XDS, see page 20.

# Operating video equipment

You can use the supplied remote control to operate Sony or non-Sony video equipment that has an infrared remote sensor. For this operation, set the manufacturer's code number.

#### Setting the manufacturer's code



Press the CODE SET, VTR (FUNCTION), and 0 - 9 buttons to enter the manufacturer's code number (see the chart on page 35-36), then press ENTER.

For example, to operate a Sony 8 mm VCR, press CODE SET, VTR (FUNCTION), 3, 0, 2, and ENTER.



#### VCR manufacturer code numbers

VOIX IIIaiiaiactarei code	Hullibers
Manufacturer	Code number
Sony	301, 302, 303
Aiwa	338
Audio Dynamic	314, 337
Bell & Howell (M. Wards)	330, 343
Brocsonic	319
Canon	309, 308
Citizen	332
Craig	315, 302, 332
Curtis Mathis	304, 338, 309
Daewoo	341, 312, 309
DBX	314, 336, 337
Dimensia	304
Emerson	319, 320, 316, 317, 318
Fisher	330, 334, 335, 333
Funai	338
General Electric	329, 304, 309
Goldstar Hitachi	332 306, 304, 305
	309, 308
Instant Replay	309, 305, 304, 330, 314,
JC Penny	336, 337
JVC	314, 336, 337
Kenwood	314, 336, 332, 337
LXI (Sears)	332, 305, 333, 334, 330,
LAI (Scars)	335
Magnavox	308, 309
Marantz	314, 336, 337
Marta	332
Memorex	309, 335
Minolta	305, 304
Mitsubishi/MGA	323, 324, 325, 326
Multitech	325, 338, 321
NEC	314, 336, 337
Olympic	309, 308
Panasonic	308, 309, 306, 307
Pentax	305, 304
Philco	308, 309
Philips	308, 309
Pioneer	308
Quasar	308, 309
RCA/PROSCAN	304, 305, 308, 309, 311,
	312, 313
Realistic	309, 330, 328, 335, 324,
	338
Sansui	314
Singer	315
Samsung	322, 313, 321
Sanyo	330, 335
Scott	312, 313, 321, 335, 323,
G1	324, 325, 326
Sharp	327, 328
Shintom	315
Signature 2000 (M. Wards)	338, 327
Sylvania	308, 309, 338
Symphonic	338 332
Tashiro	314, 336, 337
Tatung Teac	314, 336, 338, 337
Technics	309, 308
Toshiba	312, 311
Wards	327, 328, 335, 331, 332
Yamaha	330, 314, 336, 337
Zonith	330, 314, 330, 337

Zenith

Manufacturer	Code number	
Sony	701	
Kenwood	707	
Magnavox	703	
Maranz	702	
Mitsubishi	702	
Panasonic	704	
Philips	703	
Pioneer	702	
RCA	702	
Sanyo	706	
Sharp	705	
Yamaha	703	

#### Notes

2


- · If more than one code number is listed, try entering them one by one, until you come to the correct code for your equipment.
- · In some rare cases, you may not be able to operate your non-Sony video equipment with the supplied remote control. This is because your equipment may use a code that is not included with this remote control. In this case, please use the equipment's own remote control unit.
- . The code numbers for Sony equipment are assigned at the factory as follows:

VHS VCR 301 (preset code for the supplied remote control)

8 mm VCR 302 Beta, ED Beta VCRs 303

· Whenever you remove the batteries — to replace them, for example - if too much time is taken, the code number may revert to the factory setting and must be reset.

#### Operating video equipment



Use the video operating buttons on the remote control to operate the video equipment. Press VTR (FUNCTION) before operating the video equipment.

Operating a VCR	Buttons on the remote control
To turn on or off	Press VTR (POWER).
To select a channel directly	Press the 0 – 9 buttons.
To change channels	Press CH +/
To record	Press ► while pressing ●. First release ►, then release ●.
To play	Press ►.
To stop	Press ■.
To fast forward	Press ▶►.
To rewind the tape	Press ◀◀.
To pause	Press II. To resume normal playback, press again.
To search the picture forward or backward	Press ▶▶ or ◀◀ during playback. To resume normal playback, release the button.
To change input mode	Press TV/VTR.


Operating an MDP	Buttons on the remote control			
To turn on or off	Press VTR (POWER).			
To play	Press ►.			
To stop	Press ■.			
To pause	Press II.  To resume normal playback, press again.			
To search the picture forward or backward	Keep pressing ▶▶ or ◀◀ during playback. To resume normal playback, release the button.			
To search the chapter forward and backward	Press CH +/			

#### Note

. If the video equipment does not have a certain function, the corresponding button on this remote control will not operate.

# Operating a cable box or DBS receiver


You can program the supplied remote control to operate a cable box or DBS receiver. Follow the procedures below to set the manufacturer's code number in the remote control.



- \* The TV/DBS, GUIDE, DISPLAY, \$/\$/\$/\$/, and MENU buttons can be used only with a DBS receiver.
- 1 Turn off the equipment you want to set up, and press DBS/CABLE (FUNCTION).



2 Press the CODE SET. DBS/CABLE (FUNCTION). and 0 - 9 buttons to enter the manufacturer's code number (see the chart on the right column), then press ENTER. For example, to program your remote control to operate a Sony DBS receiver, press CODE SET, DBS/CABLE (FUNCTION), 8, 0, 1, and ENTER.



3 Press DBS/CABLE (POWER) to turn on the cable box or DBS receiver.



4 Use the cable box/DBS control buttons to check if the code number works. For example, to operate a cable box or DBS receiver, you can use the DBS/CABLE (POWER), JUMP, CH

· If the cable box or DBS receiver does not have a certain function, the corresponding button on this remote control will not operate.

#### To operate the projection TV

+/-. 0 - 9 and ENTER buttons.

Press TV (FUNCTION). Then use the projection TV control buttons to control the projection TV.

#### For more details on operating the cable box or DBS receiver

Refer to the operating instructions that come with the equipment.

If the remote control doesn't work

· First, try repeating the setup procedures using the other codes listed for your equipment.

#### Manufacturer code numbers (cable box)

Manufacturer	Code number
Hamlin/Regal	222, 223, 224, 225, 226
Jerrold/G. I.	201, 202, 203, 204, 205, 206, 207, 208, 218
Oak	227, 228, 229
Panasonic	219, 220, 221
Pioneer	214, 215
Scientific Atlanta	209, 210, 211
Tocom	216, 217
Zenith	212, 213

#### Manufacturer code numbers (DBS receiver)

Manufacturer	Code number
Sony	801 (preset code for the supplied remote control)
RCA	802

- · If more than one code number is listed, try entering them one by one until you come to the correct code for your equipment.
- . If you enter a new code number, the code number you previously entered at that setting is erased.
- In some rare cases, your equipment may use a code that is not provided with this remote control and you may not be able to operate your equipment with the supplied remote control. In this case, use the equipment's own remote control unit.
- · Whenever you remove the batteries to replace them, for example — if too much time is taken, the code numbers may revert to the factory setting and must be reset.

#### No picture (screen not lit), no sound

- → Make sure the power cord is connected securely.
- → Operate with the buttons on the projection TV.
- → Insert the batteries in the remote control with the correct polarity.
- → Replace the batteries with new ones if they are weak.
- → Check to see if the TV/VIDEO setting is correct: when watching TV, set to TV, and when watching video tapes, set to VIDEO1, 2, or 3.
- → Try another channel. It could be station trouble.
   → Perform AUTO SET UP again using the SETUP
- button to return to the factory preset condition

# Poor or no picture (screen lit), good sound → Adjust PICTURE in the VIDEO menu. (page 23)

- → Adjust BRIGHTNESS in the VIDEO menu (page 23)
- → Adjust convergence. (page 16)
  → Check antenna/cable connections. (page 6)
- → Perform AUTO SET UP again using the SETUP button to return to the factory preset condition. (page 14)
- → Remove objects from the front of the projection TV.

#### Good picture, no sound

- → Press MUTING so that "MUTING" disappears from the screen. (page 19)
- → Check the MTS setting in the AUDIO menu. (page 27)
- → Make sure SPEAKER is set to ON in the AUDIO menu. (page 27)
- → Perform AUTO SET UP again using the SETUP button to return to the factory preset condition (page 14)

#### No color

- → Adjust the COLOR in the VIDEO menu. (page
- → Confirm that black and white program is not
- being broadcast.

  → Perform AUTO SET UP again using the SETUP button to return to the factory preset condition.

- Only snow and noise appear on the screen

  → Check the CABLE setting in the SET UP menu. (page 17)
  - → Check the antenna/cable connections. (page 6) → Make sure the channel is broadcasting
  - → Press ANT to change the input mode. (page 20)

- Dotted lines or stripes

  → Adjust the antenna.
  - → Move the projection TV away from noise sources such as cars, neon signs, and hair-

#### Double images or ghosts

→ Use a highly directional outdoor antenna or a cable (when the problem is caused by reflections from nearby mountains or tall buildings).

#### Cannot operate menu

- → If the item you want to choose appears in gray, you cannot select it. Press TV/VIDEO
- → Check the CABLE setting in the SET UP menu. (page 17)

### Cannot receive upper channels (UHF) when using an

- → Make sure CABLE is OFF in the SET UP menu. (page 17)
- → Use AUTO PROGRAM to add receivable channels that are not presently in projection TV memory. (pages 14, 18)

#### Cannot receive any channels when using cable TV

- → Make sure CABLE is ON in the SET UP menu. (page 17)
- → Use AUTO PROGRAM to add receivable channels that are not presently in projection TV memory. (pages 14, 18)

#### Remote control does not operate

- → Batteries could be weak. Replace the batteries.
- → Make sure the projection TV's power cord is connected securely to the wall outlet.
   → Press TV (FUNCTION) when operating your
- projection TV.
- → Are fluorescent lights too close to the projection TV? Move them at least 3-4 feet away from the projection TV.

## Cannot gain enough volume when using a cable box → Increase the volume at the cable box. Then press

TV (FUNCTION) and adjust the projection TV's


#### The projection TV needs to be cleaned

Clean the projection TV with a soft dry cloth. Never use strong solvents such as thinner or benzine, which might damage the finish of the cabinet.

# Index to parts and controls

This section briefly describes the buttons and controls on the projection TV and on the Remote control. For more information, refer to the pages next to each description.

#### Projection TV — Front




- 1 TIMER/STANDBY indicator (pages 19, 30)
- 2 STEREO indicator (page 27)
- 3 Remote sensor
- 4 POWER switch (page 14)
- 5 CHANNEL +/- buttons (page 14)

- 6 VOLUME +/- buttons (page 14)
- 7 TV/VIDEO button (page 14, 15)
- 8 SETUP button (page 14)
- 9 S VIDEO/VIDEO 2 INPUT (VIDEO/AUDIO L(MONO)/R) jacks (page 10)

22





- 1 VTR (POWER) switch (page 36)
- 2 MUTING button (page 19)
- 3 VTR (FUNCTION) button (page 35)
- 4 FREEZE button (page 22)
- 5 TV/VTR CH +/- buttons (Yellow labelled button) (page 21)
- 6 POSITION button (page 22)
- 7 DISPLAY button (page 20)
- 8 SLEEP button (page 20)
- 9 JUMP button (page 19)
- 10 TV/DBS © button (page 26, 37)
- 11 RESET button (page 23)
- 12 VOL (volume) +/- buttons (page **19**)
- 13 CODE SET button (page 35)
- 14 DBS/CABLE (POWER) switch (page 37)
- 15 TV (POWER) switch (page 19)
- 16 DBS/CABLE (FUNCTION) button (page 37)

- TV (FUNCTION) button (pages 15, 19)
- 18 SWAP button (page 22)
- 19 PIP button (page 21)
- 20 TV/VIDEO button (yellow labelled button) (page 21)
- 21 AUDIO button (page 21)
- 22 TV/VIDEO button (page 20)
- 23 ANT button (page 20)
- 24 0 9 buttons (page **16**)
- 25 ENTER button (page 16)
- 26 MTS/GUIDE button (page 27, 37)
- 27 Menu operation buttons (page 15) MENU button
  - **♦/♦/♦/** buttons
  - button
- 28 CH (channel) +/- buttons (pages 16, 19)


Additional Information | 41-EN


EN

# SECTION 2 DISASSEMBLY


## 2-1. REAR BOARD REMOVAL

## 2-3. SERVICE POSITION







### 2-2. CHASSIS ASSY REMOVAL




### 2-4. HA BOARD REMOVAL




### 2-5. BEZNET ASSY REMOVAL



# 2-7. HIGH-VOLTAGE CABLE INSTALLATION AND REMOVAL




## 2-6. MIRROR COVER ASSY REMOVAL



## 2-8. PICTURE TUBE REMOVAL


**CAUTION:**Removing the arrow-marked screws is strictly inhibited.

If removed, it may cause liquid spill.






# 2-9. SERVICE STAY ASSY HOW TO USE AND CARRY BACK SERVICE STAY ASSY.




## (1) PICTURE TUBE BRACKET ASSY REMOVAL

- Disassemble HA board and speaker cord.
- Disassemble all the harness from purse lock.



- 1) Remove ① three screws (head tapping screw 4X20) and pull out ② chassis assy from cabinet assy
- 2) Remove ③ two screws (tapping screw 4X20) and remove ④ shield board.
- 3) Remove (§) eight screws (head tapping screw 4X20) and release (§) picture tube bracket assy from cabinet assy.
- 4) Remove ⑦ two screws (+BVTP 4X12) and remove ⑧ X-RAY shield (L).
- 5) Remove (9) two screws (+BVTP 4X12) and remove (10) X-RAY shield (R).


## (2) SETTING OF SERVICE STAY ASSY.



- 1) Remove CR board from picture tube.
- 2) Lift up picture tube bracket assy and fit the hook of ① side board (L) to the notch on the assy. Then fix then with ② six screws (+BVTP 4X12).
- 3) Lift up picture tube bracket assy and fit the hook of ③ side board (R) to the notch on the assy. Then fix then with ④ six screws (+BVTP 4X12).

**Note:** Always be sure to remove the picture tube before trying to set the sideboards (R L). The CR board may be damaged if left in position while setting the sideboards and it may be impossible to set the sideboards correctly.

## (3) INSTALL A CHASSIS ASSY AND CARRY THE PICTURE TUBE BRACKET



- 1) Put ① chassis assy on chassis stays.
- 2) Put ② HA board on ① chassis assy
- 3) Put your hands to side board (L) and (R).
- 4) You can carry the chassis assy in this condition.

Note: Make sure that the CR board has been removed before installing the chassis assy.

# SECTION 3 SET-UP ADJUSTMENTS

# 3-1. SCREEN VOLTAGE ADJUSTMENT (ROUGH ALIGNMENT)

- 1. Receive the Monoscope signal.
- 2. Set 50% BRIGHTNESS and minimum PICTURE.
- 3. Turn the red VR on the FOCUS block all the way to the left and then gradually turn it to the right until the point where you can see the retrace line.
- 4. Next gradually turn it to the left to the position where the retrace line disappears.




Fig. 3-1

#### 3-2. FOCUS LENS ADJUSTMENT

- 1. Loose the lens screw.
- 2. Set in service mode.
- Use VP on the service mode menu to shown only the green color.
- 4. Press the Commander Menu button and select FEATURES and CONVERGENCE to display the test signal (crosshatch) on the screen.
- 5. Rotate the green lens and align with the optimal focus point from the test signal.
- 6. Use RG-RH from the service mode menu to set to green and red.
- 7. Output the test signal and rotate the red lens to obtain the optimum focus at the point where the red and green spots overlap.
- 8. Use RG-BH from the service mode menu to set to red and blue.
- Output the test signal and rotate the blue lens to obtain the optimum focus at the point where the blue and red spots overlap.
- 10. Tighten the lens screw.




Fig. 3-2

### 3-3. SCREEN (G2) ADJUSTMENT

- 1. Select VIDEO mode without signals.
- 2. Connect an oscilloscope to the TP701(KR), TP731(KG) and TP761(KB) of CR board, CG board and CB board.
- 3. Adjust R, G and B screen voltage to 170 173V with screen VR on the focusblock.
- 4. After adjusting the screen VR on the focus block confirm that the retrace lines are not visible. If retrace lines are visible reduce the setting of the screen VR until the retrace lines are not visible.




Fig. 3-3

#### 3-4. FOCUS VR ADJUSTMENT

- 1. Set in service mode.
- Use VP on the service mode menu to shown only the green color.
- Press the Commander Menu button (convergence) and output the test signal (crosshach).
- Rotate the green VR on the FOCUS block and align to obtain the optimal focus point.
- Use RG-RH from the service mode menu to set to green and red
- Output the test signal and rotate the red VR to obtain the optimum focus at the point where the red and green spots overlap.
- Use RG-BH from the service mode menu to set to red and blue.
- 8. Output the test signal and rotate the blue VR aligning to obtain the optimum focus at the point where the blue and green spots overlap.




Fig. 3-4

Fig. 3-5

#### 3-5. DEFLECTION YOKE TILT ADJUSTMENT

- 1. Set to receive the Monoscope signal.
- 2. Set in service mode.
- Use VP on the service mode menu to show only the green color.
- 4. Loosen the deflection yoke set screw and align the tilt of the Deflection Yoke so that the bars at the center of the monoscope pattern are horizontal.
- 5. After aligning the deflection yoke, fasten it securely to the funnel-shaped portion (neck) of the CRT.
- 6. The tilt of the deflection yoke for red is aligned with RG-RH on the service mode menu, and the tilt on the deflection yoke for biue is aligned with RG-BH on the service menu, is aligned the same as was done for green.




Fig. 3-6

#### 3-6. 2-POLE MAGNET ADJUSTMENT

- 1. Disconnect CN1431 on Z board.
- 2. Power on.
- 3. Set to receive dot hatch signal.
- 4. Place caps on the red and blue lenses so that only the green color is shown.
- 5. Turn the green VR on the focus block to the left and set to underfocus to enlarge the spot.
- 6. Adjust the 2-pole magnet so that the spot is centered inside of the flare portion and the width of the flare on the left side and right side is equal.
- 7. Turn the green VR on the focus block to the right and adjust for best focus.
- 8. Perform the same adjustment for red.
- 9. Power off
- 10. Connect CN1431.

#### Use the center dot




Fig. 3-7

#### 3-7. 4-POLE MAGNET ADJUSTMENT

- 1. Disconnect CN1431 on Z board.
- 2. Power on.
- 3. Set to receive the dot signal.
- 4. Place caps on the red and blue lenses so that only the green color is shown.
- 5. Turn the green VR on the focus block to the right and set to overfocus to enlarge the spot.
- 6. Adjust the 4-pole magnet so that the spot becomes a perfect circle.
- 7. Turn the green VR on the focus block to the left and adjust for best focus.
- 8. Perform the same adjustment for red and blue. For red adjust the spot to a circle. For blue adjust the spot so that the spot height is 1.5 times higher than the spot width (x : y = 1 : 1.5).
- 9. Power off
- 10. Connect CN1431.

#### Use the center dot




Fig. 3-8

## 3-8. DEFOCUS ADJUSTMENT (Blue)

- 1. Receive the dot hatch signal
- 2. Adjust the blue FOCUS knob clockwise until the right dot becomes oval.
- Check flare with high luminance dot hatch signal to make sure that the blue flare is minimal Reduce defocus if blue flare is excessive.
- 4. Defocus adjustment is for blue only.

## [Focus adjustment point]




Fig. 3-9

# 3-9. ELECTRICAL ADJUSTMENT BY REMOTE COMMANDER

### 2. MEMORY WRITE CONFIRMATION METHOD

- 1. After adjustment, remove the plug from AC outlet, and then replace the plug in AC outlet again.
- 2. Turn the power switch ON and set to Service Mode.
- 3. Call the adjusted items again and confirm they were adjusted.

By using Remote Commander (RM-Y136A), all circuit adjustments can be made.


### **NOTE: Test Equipment Required.**

- 1. Pattern Generator
- 2. Frequency counter
- 3. Digital multimeter
- 4. Audio oscillator

#### 1. METHOD OF SETTING THE SERVICE ADJUSTMENT MODE

### SERVICE MODE PROCEDURE


1. Standby mode. (Power off)



on the Remote Commander.


(Press each button within a second.)

#### SERVICE MODE ADJUSTMENT




- 3. The CRT displays the item being adjusted.
- 4. Press 1 or 4 on the Remote Commander to select the item.
- 5. Press **3** or **6** on the Remote Commander to change the data.
- 6. Press 2 or 5 on the Remote Commander to select the category.
- If you want to recover the latest values press then ENTER to read the memory.
- 8. Press MUTING then ENTER to write into memory.

#### SERVICE MODE ADJUSTMENT



9. Press **8** then **ENTER** on the Remote Commander to initialize or turn set off and on to exit.

## 3. ADJUST BUTTONS AND INDICATOR



## 4. SERVICE MODE LIST

#### VP

Category	Adjustment item	Standard data	Data range	Note
***		data	-	
VP	VPOS VSIZ	-	0-63 0-63	V SHIFT V SIZE
	VSIZ	0	0-65	HV-COMP-V
	VLIN	7	0-3	V LIN
	VSCO	7	0-15	S CORRECTION
	HPOS	7	0-15	H SHIFT
	HSIZ	/	0-63	H SIZE
	PAMP	_	0-63	PIN AMP
	UPIN	7	0-05	UPPER CORNER PIN
	LPIN	7	0-15	LOWER CORNER PIN
	PPHA	7	0-15	H TRAPEZOID
	AFC	2	0-13	AFC LOOP GAIN
	VBOW	7	0-15	V BOW
	VANG	7	0-15	V ANGLE
	REF	3	0-13	AKB REFERENCE
	GDRV	-	0-63	GREEN DRIVE
	BDRV	_	0-63	BLUE DRIVE
	GCUT	_	0-15	GREEN CUT OFF
	BCUT	_	0-15	BLUE CUT OFF
	SCON	_	0-15	SUB CONTRAST
	SHUE	_	0-15	SUB HUE
	SCOL	_	0-15	SUB COLOR
	SBRT	_	0-63	SUB BRIGHTNESS
	SSHP	7	0-15	SUB SHARPNESS
	GMMA	0	0-3	GAMMA LEVEL
	CDM2	0	0,1	COUNT DOWN MODE 2
	DPIX	1	0,1	DYNAMIC PICTURE
	Y-DC	1	0,1	DC TRANSMISSION RATIO
	ABLM	1	0,1	ABL MODE
	AXIS	0	0,1	R-Y, G-Y AXIS
	NOTC	0	0,1	C TRAP
	CROM	7	0-15	C TRAP F0
	TOT	0	0,1	C TOT FILTER
	PREL	3	0-3	PRE/OVER LEVEL
	SHPF	2	0-3	SHARPNESS F0
	RON	-	0,1	RED ON/OFF
	GON	-	0,1	GREEN ON/OFF
	BON	-	0,1	BLUE ON/OFF
	DCOL	-	0,1	DYNAMIC COLOR
	CDMD	0	0,1	V COUNT DOWN
	LBLK	13	0-15	H BLK WIDTH LEFT SIDE
	RBLK	13	0-15	H BLK WIDTH RIGHT SIDE

## ΑP

te
_

## RG

Category	Adjustment item	Standard data	Data range	Note
RG-GH	GH CENT	-	-127- +127	GREEN H SENT
	GH SKEW	-	-127-+127	GREEN H SKEW
	GH BOW	-	-127-+127	GREEN H BOW
	GH 4BOW	-	-127-+127	GREEN H 4TH BOW
	GH SIZE	-	-127-+127	GREEN H SIZE
	GH LIN	-	-127-+127	GREEN H LINEARITY
	GH MSIZ	-	-127-+127	GREEN H MID SIZE
	GH MLIN	-	-127-+127	GREEN H MID LINEARITY
	GH KEY	-	-127-+127	GREEN H KEY
	GH SSKW	-	-127-+127	GREEN H SUB SKEW
	GH MPIN	-	-127-+127	GREEN H MID PIN
	GH PIN	-	-127-+127	GREEN H PIN
	GH SBOW	-	-127-+127	GREEN H SUB BOW
	GH MBOW	-	-127-+127	GREEN H MID BOW
	GH 4PIN	-	-127-+127	GREEN H 4TH PIN
	GH 4SBO	-	-127-+127	GREEN H 4TH SUB BOW
RG-GV	GV CENT	-	-127-+127	GREEN V CENT
	GV SKEW	-	-127-+127	GREEN V SKEW
	GV BOW	-	-127-+127	GREEN V BOW
	GV SIZE	-	-127-+127	GREEN V SIZE
	GV LIN	-	-127-+127	GREEN V LINEARITY
	GV MSIZ	-	-127-+127	GREEN V MID SIZE
	GV MKEY	-	-127-+127	GREEN V MID KEY
	GV KEY	-	-127-+127	GREEN V KEY
	GV SSKW	-	-127-+127	GREEN V SUB SKEW
	GV MPIN	-	-127-+127	GREEN V MID PIN
	GV PIN	-	-127-+127	GREEN V PIN
	GV SBOW	-	-127-+127	GREEN V SUB BOW
	GV WAVE	-	-127-+127	GREEN V WAVE
	GV 4PIN	-	-127-+127	GREEN V 4TH PIN
RG-RH	RH CENT	-	-95-+96	RED H CENT
	RH SKEW	-	-127-+127	RED H SKEW
	RH BOW	-	-127-+127	RED H BOW

Category	Adjustment item	Standard data	Data range	Note
	RH 4BOW	-	-127-+127	RED H 4TH BOW
	RH SIZE	-	-127-+127	RED H SIZE
	RH LIN	-	-127-+127	RED H LINEARITY
	RH MSIZ	-	-127-+127	RED H MID SIZE
	RH MLIN	-	-127-+127	RED H MID LINEARITY
	RH KEY	-	-127-+127	RED H KEY
	RH SSKW	-	-127-+127	RED H SUB SKEW
	RH MPIN	-	-127-+127	RED H MID PIN
	RH PIN	-	-127-+127	RED H PIN
	RH SBOW	-	-127-+127	RED H SUB BOW
	RH MBOW	-	-127-+127	RED H MID BOW
	RH 4PIN	-	-127-+127	RED H 4TH PIN
	RH 4SBO	-	-127-+127	RED H 4TH SUB BOW
RG-RV	RV CENT	-	-95-+96	RED V CEVT
	RV SKEW	-	-127-+127	RED V SKEW
	RV BOW	-	-127-+127	RED V BOW
	RV SIZE	-	-127-+127	RED V SIZE
	RV LIN	-	-127-+127	RED V LINEARITY
	RV MSIZ	-	-127-+127	RED V MID SIZE
	RV MKEY	-	-127-+127	RED V MID KEY
	RV KEY	-	-127-+127	RED V KEY
	RV SSKW	-	-127-+127	RED V SUB SKEW
	RV MPIN	-	-127-+127	RED V MID PIN
	RV PIN	-	-127-+127	RED V PIN
	RV SBOW	-	-127-+127	RED V SUB BOW
	RV WAVE	-	-127-+127	RED V WAVE
	RV 4PIN	-	-127-+127	RED V 4TH PIN
	RV WING	-	-31-+32	RED V WING
RG-BH	BH CENT	-	-95-+96	BLUE H CENT
	BH SKEW	-	-127-+127	BLUE H SKEW
	BH BOW	-	-127-+127	BLUE H BOW
	BH 4BOW	-	-127-+127	BLUE H 4TH BOW
	BH SIZE	-	-127-+127	BLUE H SIZE
	BH LIN	-	-127-+127	BLUE H LINEARITY
	BH MSIZ	-	-127-+127	BLUE H MID SIZE
	BH MLIN	-	-127-+127	BLUE H MID LINEARITY
	BH KEY	-	-127-+127	BLUE H KEY
	BH SSKW	-	-127-+127	BLUE H SUB SKEW
	BH MPIN	-	-127-+127	BLUE H MID PIN
	BH PIN	-	-127-+127	BLUE H PIN
	BH SBOW	-	-127-+127	BLUE H SUB BOW
	BH MBOW	-	-127-+127	BLUE H MID BOW

Category	Adjustment item	Standard data	Data range	Note
	BH 4PIN	-	-127-+127	BLUE H 4TH PIN
	BH 4SBO	-	-127-+127	BLUE H 4TH SUB BOW
RG-BV	BV CENT	-	-95-+96	BLUE V CENT
	BV SKEW	-	-127-+127	BLUE V SKEW
	BV BOW	-	-127-+127	BLUE V BOW
	BV SIZE	-	-127-+127	BLUE V SIZE
	BV LIN	-	-127-+127	BLUE V LINEARITY
	BV MSIZ	-	-127-+127	BLUE V MID SIZE
	BV MKEY	-	-127-+127	BLUE V MID KEY
	BV KEY	-	-127-+127	BLUE V KEY
	BV SSKW	-	-127-+127	BLUE V SUB SKEW
	BV MPIN	-	-127-+127	BLUE V MID PIN
	BV PIN	-	-127-+127	BLUE V PIN
	BV SBOW	-	-127-+127	BLUE V SUB BOW
	BV WAVE	-	-127-+127	BLUE V WAVE
	BV 4PIN	-	-127-+127	BLUE V 4TH PIN
	BV WING	-	-31-+32	BLUE V WING

# СС

Category	Adjustment item	Standard data	Data range	Note
CC	CRIH	9	0-15	CRI COUNT HIGH
	CRIL	2	0-15	CRI COUNT LOW
	CFLD	5	0-15	FIXED FIELD COUNT
	CCDI	3	0-7	NO CCD INT COMPARE
	CRIP	4	0-7	CRI & PARITY ERROR
	CRIT	2	0-3	CRI TIME CONSTANT
	CSB1	3	0-3	SYNC SLICE BIAS 1
	CSB2	4	0-7	SYNC SLICE BIAS 2
	CCBD	4	0-15	C SYNC BACKPORCH DET
	CCFD	7	0-15	C SYNC FRONTPORCH DET
	CREP	142	0-255	CRI SIGNAL END POSITION
	CSEP	186	0-255	START BIT END POSITION
	CRBD	8	0-15	CRI BACKPORCH DET
	CRFD	9	0-15	CRI FRONTPORCH DET
	CSSD	3	0-15	STROBE WINDOW ST DLY
	CSED	9	0-15	STROBE WINDOW ED DLY
	CSBS	12	0-31	START BIT THRESHOLD
	CDSD	8	0-31	DATA START DELAY
	CCDS	9	0-31	CAPTION DT THRESHOLD
	CHMK	42	0-63	H SYNC MASK WIDTH
	CHSY	136	0-255	H SYNC VCO COUNT

# OP

Category	Adjustment item	Standard data	Data range	Note
OP	DISP	-	0-63	OSD POSITION
	PDPS	-	0-255	FAV/IDX CH POSITION
	PDPO	-	0-7	CH POSITION (OFF SET)

# ID

Category	Adjustment item	Standard data	Data range	Note
ID	ID0	25	0-255	MODEL ID#0
	ID1	55	0-255	MODEL ID#1
	ID2	31	0-255	MODEL ID#2
	ID3	1	0-255	MODEL ID#3
	ID4	155	0-255	MODEL ID#4
	ID5	177	0-255	MODEL ID#5
	ID6	198	0-255	MODEL ID#6
	ID7	66	0-255	MODEL ID#7

# PS

Category	Adjustment item	Standard data	Data range	Note
PS	PIPH	-	0-127	PIP H POSITION
	PIPV	-	0-63	PIP V POSITION
	PMVD	26	0-31	PIP V PULSE DELAY(M)
	PIVD	22	0-31	PIP V PULSE DELAY(I)
	PCON	-	0-15	PIP CONTRAST(I)
	FRMY	7	0-15	PIP FRAME Y LEVEL
	IPER	0	0-15	PIP PEDESTAL R-Y(I)
	IPEB	0	0-15	PIP PEDESTAL B-Y(I)
	IHUE	-	0-15	PIP SUB HUE
	ICOL	-	0-15	PIP SUB COLOR
	PHDL	1	0-15	PIP H PULSE DELAY
	PYSD	1	0-15	PIP SELECT DELAY
	PYDL	0	0-7	PIP Y DELAY
	PCPS	0	0,1	PIP CLP
	PCPF	0	0,1	PIP CLP CYCLES
	PSEL	0	0,1	PIP SELDOWN
	PPLL	0	0-3	PIP PLL
	CHRI	0	0,1	PIP INPUT POLARITY
	CHRO	0	0,1	PIP OUTPUT POLARITY


# IC

Category	Adjustment item	Standard data	Data range	Note
IC	SSCN	6	0-15	P&P SUB SUB CONTRAST
	SSHU	-	0-15	P&P SUB SUB HUE
	SSCL	-	0-15	P&P SUB SUB COLOR
	SUPD	-	0-15	P&P SUB U OFFSET
	SVPD	-	0-15	P&P SUB V OFFSET
	SDLY	0	0-3	P&P SUB Y DELAY
	SBGR	3	0-3	P&P SUB SCP CONTROL(1)
	SBGF	3	0-3	P&P SUB SCP CONTROL(2)
	PAFC	2	0-3	PIP AFC LOOP GAIN
	PTOT	0	0,1	PIP CHROMA TOT FILTER
	PYDR	10	0-31	PIP Y DRIVE
	PYDC	3	0-7	PIP DC TRAN
	PSHP	1	0,1	PIP SHARPNESS F0
	PDPI	0	0,1	PIP DYNAMIC PICTURE
	PSYS	0	0-3	PIP COLOR SYSTEM
	PXTL	0	0-3	PIP X' TAL
	PLOP	0	0-3	PIP COLOR LOOP

### 3-10. CONVERGENCE ADJUSTMENT


• When replacing the deflection yoke, always perform "DEFLECTION YOKE TILT ADJUSTMENT" before adjusting the convergence.

### Adjustment procedure




### [ GREEN REGISTRATION ADJUSTMENT ]

### V-SHIFT adjustment




### V-LINEARITY adjustment




### • V-SIZE, V-CORRECTION adjustment

While tracking, adjust so that the lattice intervals for VSIZ and VSCO are equal.




### • H-SHIFT adjustment




## H-SIZE adjustment

Finely adjust with SUB MSIZ.



### • PIN-AMP adjustment


Finely adjust with SUB MPIN.



## • UPPER/LOWER-CORNER PIN adjustment


Correct the screens top and bottom bow line. However, if this adjustment is overdone, distortion may occur with the PIN-AMP adjustment that can not be re-adjusted.

Note: The PIN-AMP adjusts the overall screen from top to bottom, but the UPPER/LOWER-CORNER PIN adjustments have large movement in the top and bottom sections, so be careful.




### • V-ANGLE, V-BOW adjustment

Correct the tilt and bow of the vertical line at the center of the screen.




# [GREEN SUB ADJUSTMENT] SCREEN CENTER SECTION GREEN VERTICAL LINE ADJUSTMENT

- Finely adjust with GH CENT, GH BOW, GH SKEW.
   Adjust by watching out for the GH CENT screen center section.
- GH 4TH BOW adjustment
   Correct the corner distortion that could not be adjusted away with the GH 4BOW adjustment.




# SCREEN CENTER SECTION GREEN HORIZONTAL LINE ADJUSTMENT

- 1. Finely adjust the center position of the vertical line at the center of the screen with GV CENT.
- 2. Correct the tilt and bow of the horizontal line at the center of the screen with GV SKEW and GV BOW.




#### **GREEN SIZE AND LINEARITY ADJUSTMENT**

- 1. Balance the sizes at both sides of the center section of the screen with GH MLIN.
- 2. Balance the sizes on both end sections of the screen with GH I IN
- 3. While tracking, adjust with GH MLIN and GH LIN so that the sizes of the horizontal line at the center of the screen are symmetrical left and right.




### **GREEN HORIZONTAL SIZE ADJUSTMENT**

- 1. Adjust with GH MSIZE so that the sizes of both ends and of both sides of the center section of the screen are equal.
- Adjust with GH SIZE so that the horizontal sizes of both ends and of both sides of the center section of the screen are equal.
- 3. While tracking, adjust with GH MSIZ and GH SIZE so that the lattice intervals for the horizontal line section of the center section of the screen are equal and so that the horizontal size is the prescribed value.
- 4. If M LIN is changed when the GH MSIZ and GH SIZE adjustment is complete, adjust again while tracking.
- With just the H SIZE adjustment in MAIN, if there is no need to adjust GH SIZE in SUB this can save power.




#### **GREEN VERTICAL LINEARITY ADJUSTMENT**

 Adjust GV LIN so that the vertical lines at the top and bottom of the screen are symmetrical.




#### **GREEN VERTICAL SIZE ADJUSTMENT**

- 1. Adjust with GV MSIZE so that the sizes for the top and bottom sections of the screen and for both sides of the center section of the screen are equal.
- 2. Set the vertical size to the prescribed value with GV SIZE.
- 3. Adjust GV MSIZ and GV SIZE watching the vertical line at the center section of the screen.
- 4. While tracking, adjust with GV MSIZ and GV SIZE so that the lattice intervals for the vertical line section of the center section of the screen are equal and so that the vertical size is the regulation value.
- 5. If GV LIN is out of place when the GV MSIZ and GV SIZE adjustment is complete, adjust again while tracking.
- If there is no need to adjust GV SIZE in SUB with just the V SIZE adjustment in MAIN, this can save power.




### GREEN HORIZONTAL TRAPEZOIDAL DISTORTION ADJUSTMENT

- 1. Adjust with GH SSKW so that the tilt of the vertical lines at both ends of the screen is symmetrical left and right.
- 2. Adjust with GH KEY so that there is no tilt in the vertical lines at both ends of the screen.
- 3. If there is a tilt on either the left or right after the GH KEY adjustment, adjust while tracking.




### **GREEN HORIZONTAL QUATERNARY ADJUSTMENT**

- 1. Correct the quaternary distortion with GH 4PIN.
- 2. While balancing, correct the quaternary distortion of both end sections of the screen with GH 4SBOW.
- 3. While tracking, adjust with GH 4PIN and GH 4SBOW.




### GREEN HORIZONTAL ASYMMETRICAL PIN DISTORTION ADJUSTMENT

- Adjust with GH MBOW so that the pin asymmetry at both sides of the center section of screen is symmetrical.
- 2. Adjust with GH SBOW so that the bow at both end sections of the screen is symmetrical left and right.
- While tracking, adjust with GH MBOW and GH SBOW so that the bow of vertical lines on the entire screen is symmetrical left and right.




## GREEN HORIZONTAL SYMMETRICAL PIN DISTORTION ADJUSTMENT

- 1. Adjust the pin distortion at both sides of the center section of the screen with GH MPIN.
- 2. Adjust the pin distortion at both end sections of the screen with GH PIN.
- 3. While tracking, adjust with GH MPIN and GH PIN so that the PIN of vertical lines on the entire screen have no bowing.
- If there is asymmetrical pin distortion after the GH MPIN and GH PIN adjustments, adjust with GH MBOW and GH SBOW while tracking.
- With just the PIN AMP adjustment in MAIN, if there is no need to adjust GV PIN in SUB, this can save power.




### GREEN VERTICAL WAVE (TERTIARY DISTORTION) ADJUSTMENT

- 1. Take the screen top and bottom horizontal lines with GV WAVE and find the secondary and quaternary waveform.
- 2. There is KEY distortion after the GV WAVE adjustment, so adjust with GV WAVE and GV KEY while tracking.




## GREEN VERTICAL QUATERNARY DISTORTION ADJUSTMENT

- 1. Correct the quaternary distortion of the horizontal lines at the top and bottom sections of the screen with GV 4PIN.
- Since there is no 4SBOW for vertical correction, there will be a slight imbalance, but adjust to eliminate the distortion from the horizontal line at either the top or the bottom of the screen.
- 2) In many cases, the horizontal lines at the top and bottom sections of the screen are not straight lines after the adjustment. As long as the secondary distortion is mild enough that it can be corrected with the PIN adjustment, this is OK.



## GREEN VERTICAL TRAPEZOIDAL DISTORTION ADJUSTMENT

- Adjust with GV SSKW so that the tilt of the horizontal lines at the top and bottom sections of the screen is symmetrical about the center position horizontal line.
- Adjust with GV MKEY so that there is no tilt for the line sections at both sides of the horizontal lines at the center section of the stream.
- 3. Adjust with GV KEY so that there is no tilt for the horizontal lines at the top and bottom sections of the screen.
- 4. While tracking, adjust with GV MKEY and GV KEY so that there is no tilt for the horizontal lines on the entire screen.
- If the tilt is unbalanced after the GV MKEY and GV KEY adjustment, adjust again with GV SSKW.




# GREEN VERTICAL ASYMMETRICAL PIN DISTORTION (SECONDARY DISTORTION) ADJUSTMENT


Correct the asymmetrical pin distortion at the top and bottom sections of the screen with GV SBOW.



### GREEN VERTICAL ASYMMETRICAL PIN DISTORTION ADJUSTMENT

- 1. Adjust the pin distortion for both side sections and the center of the screen with GV MPIN.
- 2. Adjust with GV PIN so that the horizontal lines at the top and bottom sections of the screen are straight lines.
- 3. Adjust with GV MPIN and GV PIN so that there is no curve in the horizontal lines on the entire screen.
- 4. After the adjustments in Items 1-3, adjust the tracking with GV SBOW, GV MPIN, and GV PIN.







## GREEN AND RED REGISTRATION ADJUSTMENT (RRH, RRV)

- 1. Receive a cross-hatch signal.
- Adjust so that the red lines lay on the green lines.Adjust with the same procedure as the GREEN SUB adjustment.

Notes: 1. The main correction is not carried out during red registration adjustment.

- 2. Beware. The green adjustment items can be changed by mistake.
- 3. Unlike for green, adjust within the range -127  $\sim +128$ .

### GREEN AND BLUE REGISTRATION ADJUSTMENT (RBH, RBV)

- 1. Receive a cross-hatch signal.
- Adjust so that the blue and green lines are on top of each other.

Notes: 1. The main correction is not carried out during RED registration adjustment.

2. Beware. The GREEN and RED adjustment items can be changed by mistake.

### 3-11. AGC ADJUSTMENT

- 1. Receive an off-air signal.
- 2. Adjust the AGC VR ( TU 1001 ) so that there is no snow noise and cross-modulation.

### 3-12. WHITE BALANCE ADJUSTMENT

- 1. Receive the monoscope pattern signal and adjust the picture quality with the menu.
- 2. Adjust service mode SBRT so that the signal 10 IRE section barely glows.
- 3. Receive the all-white pattern signal.
- 4. Adjust the white balance with service mode GCUT and BCUT.
- 5. Adjust service mode SBRT so that the signal 100 IRE section barely glows.
- Adjust the white balance with service mode GAMP and BAMP.
- 7. Repeatedly adjust the white balance for the minimum and maximum picture settings.

# SECTION 4 SAFETY RELATED ADJUSTMENTS

### [GBOARD]

# 4-1. HV REGULATION CIRCUIT CHECK AND ADJUSTMENT

When replacing the following components marked with  $\square$  on the schematic diagram always check HV regulation, and if necessary re-adjust.


★: C514☐: C514, C515, C516IC651T502,T503, T504 (FBT)D.Y

### **OPERATION CHECK**

- 1. Connect a HV static voltmeter to the unconnected plug of the high-voltage block. **(Fig.4-1)**
- 2. Power on the set.
- 3. Receive the dot signal. (PICTURE and BRIGHTNESS to minimum)
- 4. Check that the HV static voltmeter is reading 31.00±1.0kVdc.

### **HV Regulation adjustment**

- 1. Connect a HV static voltmeter to the unconnected plug of the hight-voltage block.
- 2. Power on the set.
- Receive the dot signal. (PICTURE and BRIGHTNESS to minimum)
- 4. If anode voltage is 32kV or higher, replace C514 of 390PF/2kV with that of 680PF/2kV, and check if the voltage is within the standard range.
- 5. If anode voltage is 30kV or lower, replace C514 of 390PF/2kV with that of 100PF/2kV, and check if the voltage is within the standard range. (**Fig.4-2**)






Fig. 4-2

# 4-2. HV HOLD DOWN CIRCUIT OPERATION CHECK AND ADJUSTMENT

When replacing the following components marked with  $\square$  on the schematic diagram always check hold-down voltage and if necessary re-adjust.

★: R514, R561
★: C507, C513
D501, D504, D507
IC301, IC501, IC651
R502, R514, R516, R517, R539, R560, R561
T502, T503, T504 (FBT)
D.Y

#### **OPERATION CHECK**

- 1. Remove CN651 connecter.
- 2. Short-circuit across TP-PROT (R692) and ground.
- Connect a HV static voltmeter to the unconnected plug of the high-voltage block.
- 4. Connect a 220k variable resistor, across pin ③ and pin ⑤ of IC651 set to maximum value.
- 5. Power on the set.
- Receive the dot signal. (PICTURE and BRIGHTNESS to minimum)
- 7. Gradually lower the value of the variable resistor and check that the hold-down circuit operates at a static voltmeter reading of 33.5±1.0kVdc when the raster disappears.

### **HV HOLD-DOWN ADJUSTMENT**

- 1. Repart steps (1) ~ (7) as above.
- 2. If hold down voltage is 34.5kV or higher, remove R514, mount a resistor (390k $\Omega$ , 1/4W : RN) onto R561 instead, and check again if the hold-down voltage is within the standard range.
- 3. If hold down voltage is 32.5kV or lower, mount a resistor  $(220k\Omega, 1/4W : RN)$  onto R561 and check again if the hold-down voltage is within the standard range. **(Fig.4-2)**

**NOTE**: Please finish the adjustment as soon as possible

#### 4-3. +B MAX VOLTAGE CONFIRMATION

The following adjustments should always be performed when replacing IC651.

- 1. Supply 130VAC to with variable autotransformer.
- 2. Input a dot signal.
- 3. Set the PICTURE control and the BRIGHTNESS controls to minimum.
- 4. Confirm the voltage of G BOARD TP135V is less than 137.0Vdc.
- 5. If step 4 is not satisfied, replace IC651 and repeat above steps. **(Fig.4-2)**



### 4-4. +B OVP CONFIRMATION

- 1. Remove CN651 connector.
- 2. Connect a voltmeter to TP135V, and TP (PROT) and ground.
- 3. Connect a  $220k\Omega$  variable resistor, across pin 3 and pin 5 of IC651 set to maximum value.
- 4. Supply 120VAC to variable autotransformer.
- 5. Set PICTURE and the BRIGHTNESS controls to minimum.
- 6. Gradually turn the  $220k\Omega$  variable resistor, and check if OVP works properly when the voltage of TP135V is between 139.0 ~ 151.5V. (Fig.4-2)

# SECTION 5 CIRCUIT ADJUSTMENTS

#### 5-1. RF AGC

- 1. Input a color-bar signal.
- 2. Adjust AGC VR of TU1101 so that no snow noise, and crossmodulation disapper from the picture.
- 3. Verify picture quality on each channel.

### 5-2. BER DISPLAY ADJUSTMENT (DISP)

- 1. Receive the cross-hatch signal.
- 2. Set to Service mode.
- 3. Select "DISP", and adjust so that the blank spaces on the both sides of picture bar become equal.
- 4. Write the data into memory.

MUTING → ENTER




Fig. 5-1

### 5-3. SUB CONTRAST ADJUSTMENT (SCON)

- 1. Receive the color-bar signal.
- 2. PICTURE : maximum
  COLOR : minimum
  BRIGHTNESS : maximum

RON---1 GON---0 BON---0

- 3. Set to service mode.
- 4. Connect an oscilloscope between pin **(6)** of CN004 connector (A board) and ground.
- 5. Select "SCON", and adjust so that the wave form level is 1.65±0.1Vp-p.
- 6. Write the data into memory.

MUTING → ENTER

White ↑

1.65 ± 0.1Vp-p

Fig. 5-2

# 5-4. SUB-HUE AND SUB-COLOR ADJUSTMENT (SHUE, SCOL)

- 1. Receive the color-bar signal.
- 2. PICTURE : maximum COLOR : minimum BRIGHTNESS : minimum
- 3. Set to service mode.
- Connect an oscilloscope between pin ⑦ of CN004 connector (A board) and ground.
- 5. Select "SHUE" and "SCOL", and adjust them to have VB1 = VB4 and VB2 = VB3 in the wave form levels.
- 6. Raise SCOL data 1 steps higher.
- 7. Write the data into memory.


MUTING → ENTER

VB1 VB2 VB3 VB4

5-5. P IN P POSITION ADJUSTMENT (PIPH, PIPV)

Fig. 5-3

- 1. Receive the monoscope signal.
- 2. Set to P IN P mode, and to Service mode.
- 3. Check the SUB PICTURE position.
- 4. Select "PIPH" and "PIPV" and adjust H/V position to the center level.
- Write the data into memory.MUTING → ENTER



 $V: 5.25 \pm 0.25$ sq

Fig. 5-4

# 5-6. P IN P SUB CONTRAST ADJUSTMENT (PCON)

1. Receive the color-bar signal.

2. PICTURE : maximum COLOR : minimum BRIGHTNESS : minimum

3. Set to service mode.

- 4. Connect an oscilloscope between **9** pin of CN303 connector (A board) and ground.
- 5. Select " PCON " and adjust so that wave form level is  $1.4\pm^{0.00}_{0.05}$  Vp-p.
- 6. Write the data into memory.

 $\boxed{\text{MUTING}} \rightarrow \boxed{\text{ENTER}}$ 




Fig. 5-5

# 5-7. P IN P SUB HUE, SUB COLOR ADJUSTMENT (SSHU, SSCL)

1. Receive the color-bar signal.

2. PICTURE : maximum COLOR : center BRIGHTNESS : center TRINITONE : medium

3. Set to service mode.

- 4. Connect an oscilloscope between pin ⑦ of CN004 connector (A board) and ground.
- 5. Select "SSHU" and "SSCL", adjust them to have VB1 = VB4 and VB2 = VB3 in the wave form levels.
- 6. Write the data into memory.

 $MUTING \rightarrow ENTER$ 






Fig. 5-6

# SECTION 6




# $CR_{(R\ OUT)}$ (DY/VM)DΥ CG (G OUT) T501 H DRIVE 0501 CB (B OUT) G (H/V-DEF, HV, POWER SUPPLY

### **BLOCK DIAGRAM (3)**




**- 50 -**

**−** 51 **−** 



### 6-3. CIRCUIT BOARDS LOCATION



### 6-4. PRINTED WIRING BOARDS AND SCHEMATIC DIAGRAMS

- Capacitors without voltage indication are all 50V.
- All resistors are in ohms.
- Indication of resistance, which dose not have one for rating electrical power, is
- Rating electrical power: 1/4 W
- △ : internal component. • \_\_\_\_\_: panel designation and adjustment for repair.

- The components identified by 📘 in this basic schematic diagram have been
- When replacing components identified by  $\square$ , make the necessary adjustments indicated. If results do not meet the specified value, change the component identified by 🔀 and repeat the adjustment until the specified value is achieved.
- When replacing the part in below table, be sure to perform the related adjustment.

Part replaced (  )	Adjustment ( 🔀 )
C514, C515, C516, IC651, T502, T503, T504, DY	HV Reagurator (C514)
C507, C513, D501, D504, D507, IC301, IC501, IC651, R502, R514, R516, R517, R539, R560, R561, T502, T503, T504, DY	HV HOLD-DOWN (R514, R561)

- As to the voltage volue shown by the semiconductors on the Shematic Diagram,
- Readings are taken with a color-bar signal input.

- \_\_\_\_\_: B+ bus.
- \_\_\_ : B- bus.
- : signal path.(RF)

- $k\Omega$ =1000 $\Omega$ ,  $M\Omega$ =1000 $k\Omega$
- Pitch : 5mm
- : nonflammable resistor.
- two: if usible resistor.
- All variable and adjustable resistors have characteristic curve B, unless otherwise
- 1777 : earth-chassis.
- carefully factory-selected for each set in order to satisfy regulations regarding X-ray radiation.
- Should replacement be required, replace only with the value originally used.
- (Refer to R514,R561 and C514 adjustment on Page xx xx.)
- see the another list
- Readings are taken with a  $10M\Omega$  digital multimeter.
- Voltages are dc with respect to ground unless otherwise noted. Voltage variations may be noted due to normal production tolerances.
- All voltages are in V.
- \*: Measurement impossibillity.
- Circled numbers are waveform references.

: RC SOLID

Reference information

RESISTOR : RN METAL FILM

: RC SOLID
: FPRD NONFLAMMABLE CARBON
: FUSE NONFLAMMABLE FUSIBLE
: RW NONFLAMMABLE WIREWOUND
: RS NONFLAMMABLE METAL OXIDE
: RB NONFLAMMABLE CEMENT
: X ADJUSTMENT RESISTOR
: LT-8L MICRO INDUCTOR

CAPACITOR : TA TANTALUM

- : PS STYROL : PP POLYPROPYLENE : PT MYLAR : MPS METALIZED POLYESTER
  : MPP METALIZED POLYPROPYLENE
- : ALB BIPOLAR : ALT HIGH TEMPERATURE
- : ALR HIGH RIPPLE lote: The symbol 🛨 🔛 display is on the component slde

The components identified by shading and mark  $\Lambda$ are critical for safety. Replace only with part number

The symbol # indicate fast operating fuse. Replace only with fuse of same rating as maked.


lote: Les composants identifiés per un tramé et une marqu ∴ sont critiques pour la sécurité. Ne les remplacer que par une piéce portant le numéro spécifié.

Le symbole indique une fusible a action rapide Doit etre remplacee par une fusible de meme yaleur comme maque.

### Terminal name of semiconductors in silk screen printed circuit (\*)

	Device	Printed symbol	Terminal name	Circuit
1	Transistor	T	Collector Base Emitter	8
2	Transistor	_	Base Emitter  Collector  Base Emitter	
3	Diode	H	Cathode — Anode	,
4	Diode	T	Cathode Anode (NC)	<u>\$</u>
(5)	Diode		Cathode Anode (NC)	<b>.</b>
6	Diode	T	Common Anode Cathode	
7	Diode		Common Anode Cathode	
8	Diode	T	Common Anode Anode	
9	Diode		Common Anode Anode	
10	Diode	Т	Common Cathode Cathode	
11)	Diode	_	Common Cathode Cathode	
12	Diode		Anode Anode Cathode Anode	
13	Transistor (FET)		Drain Source Gate	
14)	Transistor (FET)	<b> </b>	Drain Source Gate	so so
15	Transistor (FET)		□ Source □ Drain □ Gate	So So So
_	Discrete se	miconductot		

**- 52 -–** 53 **– –** 54 **–** 



**–** 55 **–** 

**–** 58 **–** 

5.0Vp-p (V)

1.4Vp-p (H)

2.2Vp-p (H)

2.0Vp-p (H)

\_HWT\_HWT

0.13Vp-p (500kHz)

1.3Vp-p (V)

5.0Vp-p (H)


2.0Vp-p (H)

2.4Vp-p (H)  $\texttt{In}(\mathcal{M})$ 

A board →

**- 56 -**

**–** 57 **–** 



### A BOARD : IC007 ST24C04FM6TR

Q006 A-11 Q007 H-5

Q009 A-11

Q013 G-9

- Q017 H-9 - Q201 B-8

Q206 B-8

③ Q207 F-5

3 Q209 A-8 3 Q213 F-5

③ Q216 A-8

③ Q217 A-9

③ Q218 C-6

③ Q220 E-6 - Q226 D-7

- Q301 H-11

- Q305 G-11

- Q307 I-10

- Q308 I-10

- Q313 H-11

- Q402 C-1

- Q405 F-2

- Q406 F-2

Q312 H-12

Q314 I-11

Q403 C-1

Q408 C-1

Q409 D-1

Q1101 D-12

Q1501 G-3

- Q2105 F-4

IC001

③ IC002 H-5

③ IC003 F-8

③ IC004 H-6

③ IC201 D-6

③ IC301 H-11

- IC401 D-4 - IC402 D-5 IC403 D-2

① IC1501 G-3

① IC1502 I-4

① | IC1601 F-2

① | IC1602 F-3


IC1101 C-10

Q2106 F-5


– Q410 F-4


Q303 G-11Q304 G-11

Q306 G-12




#### A BOARD: IC301 CXA2025AS






### G BOARD: IC801, 802 PA0053B



### G BOARD : IC651 DM-58





0 00,	ARD				
חומ	DDE	*	D849	G-11	-
			D850	H-14	-
D501	F-10	_	D852	H-12	-
D502	F-9	_	D853	H-11	-
D503	H-7	-	D854	H-12	_
D504	F-10	-	D855	H-12	_
D507	H-10	_	D856	H-12	_
D508	G-6	-	D857	H-11	_
D509	G-5	-	D859	I-11	_
D510	G-4	_	D860	I-12	_
D511	F-8	-	TDAR	NSISTOR	*
D513	H-3	-			•••
D514	F-1	_	Q501	G-5	-
D515	I-1	-	Q502	F-5	-
D517	H-7	-	Q503	H-10	-
D519	H-10	_	Q504	I-11	-
D520	I-2	-	Q505	F-9	-
D521	H-4	-	Q506	H-10	-
D524	H-11	_	Q507	H-9	-
D527	F-9	-	Q651	D-4	-
D528	F-9	-	Q652	A-7	_
D602	B-3	-	Q653	A-7	_
D651	D-4	_	Q654	A-6	_
D652	D-4	_	Q655	A-7	_
D653	C-7	_	Q656	A-6	_
D654	C-7	_	Q657	D-5	_
D655	D-5	_	Q658	E-5	_
D656	C-6	_	Q659	A-7	_
D657	B-6	_	Q660	D-5	_
D658	B-6	-	Q661	E-4	_
D660	D-4	_	Q662	D-5	_
D661	E-6	_	Q802	H-13	_
D662	A-6	_	Q803	G-13	_
D664	A-7	_	Q804	G-13	_
D669	D-3	_	Q805	I-14	_
D670	A-7	_	Q809	B-12	_
D691	E-1	_	Q810	B-9	_
D692	E-2	_	20.0		
D693	E-2	-		IC	
D694	E-1	_	IC501	F-10	
D801	G-14	_	IC601	A-4	
D802	G-14	_	IC651	B-6	
D803	G-14	_	IC652	C-8	
D804	G-14	_	IC653	C-7	
D809	B-12	_	IC654	E-4	
D810	B-12	_	IC655	E-3	
D820	Б-9 F-14	_	IC801	F-14	
D828	F-14 H-14	_	IC802	F-12	
	п-14 I-13	_	IC802	H-14	
D829		_	IC804	D-14	
D835	D-11	_	IC805	D-9 H-12	
D840	I-13	_		D-12	
D842	I-13	_	IC806	D-11 D-13	
D845	I-13	_	IC808		
D846	I-13	_	IC809 IC810	B-13 B-10	
D0/-					
D847 D848	H-11 G-12	_	IC811	I-11	

# NOTE:




The circuit indicated as left contains hight voltage of over 600 Vp-p. Care must be paid to prevent an electric shock in inspection or repairing.





### PT BOARD : IC5052 SDA9288X-GEG



### • PT BOARD WAVEFORMS


	$^{(2)}$	3
0.12Vp-p (500kHz)	4Vp-p (20.48MHz)	1.8Vp-p (H)
4	5	6
1.8Vp-p (H)	1Vp-p (h)	0.1Vp-p (500kHz)


0.24Vp-p (14.32MHz)

# PT BOARD TRANSISTOR VOLTAGE LIST


REF.	Pin	VOL.	REF.	Pin	VOL.	REF.		VOL.	REF.		VOL
	NO.			NO.			В	6.5		В	2.5
	1	2.3		14)	GND	Q5001	E	5.8	Q5101	E	1.9
	2	4.1		(b)	GND	Q0001	c	8.8	40101	C	5.0
	3	9.0		17	4.9		В	5.8		В	0.9
	4	0		18	4.9	Q5002	E	6.5	Q5102	E	1.8
	5	GND	_	19	4.9	Q0002	c	GND	40102	C	GNI
	9	9.0		20	4.9		В	2.8		В	0.9
	10	1.0		21	GND	Q5003	E	2.2	Q5103	E	1.6
	11)	3.8		22	GND	Q3003	c	8.5	- 00100	C	GNI
	12	4.5		23	GND		В	2.9		В	0.8
	13	4.6		24)	GND	Q5004	E	2.2	Q5104	E	1.5
	14	0.1		200	1.5	Q3004	C	4.1	- 23104	C	GN
	16	0.7		26	GND		В	4.1		В	1.9
	17	GND	IC5101	27	1.5	Q5005	E	3.5	Q5105	E	2.6
	18	2.8		28	4.9	Q3003	C	8.5	Q3103	C	GNI
C5001	19	2.9		29	2.6		В	0.4		В	2.4
(	20	2.9		30	GND	Q5051	E	1.0	Q5106	E	1.7
	21	GND		31	0.9	Q3031	C	GND	Q3106	C	4.4
	22	GND		32	4.9		В	0		В	2.4
	200	9.0		33	2.9	OFOE	E	0.5	05407	Е	1.7
	26	2.4		34	1.8	Q5052	C		Q5107	С	
	29	4.5		33-	1.8		_	GND			4.4
	31)	GND	1	36	0.9	05050	В	*	05400	В	2.3
	33	3.3	1	37	0	Q5053	E	*	Q5108	E	1.7
	34)	3.6	1	38	0		С	*		С	5.0
	33-	GND	1	39	0	05054	В	0	05400	В	4.4
	36	4.8	1	40	4.9	Q5054	E	0	Q5109	Е	5.0
	37	4.8	1	41)	0.9		С	4.9		С	2.0
	38	4.1	1	42	GND	05055	В	0.5	05440	В	4.4
	39	3.3	1	49	GND	Q5055	E	1.1	Q5110	Е	5.0
	40	0.7	1	50	4.9		С	GND		С	2.0
	1	GND	1	63	GND		В	*		В	1.5
	2	2.9	1	62	4.9	Q5056	E	*	Q5111	Е	2.1
	3	2.4	1	63	5.0		С	*		С	GNI
	4	2.2	1	64	0		В	0		В	2.1
	(5)	4.9	1	69-	GND	Q5057	Е	0	Q5112	Е	1.5
	6	GND	1	66	4.9		С	4.9		С	4.9
	7	0.4	1	67	GND				Al	I volta	ges are
	(8)	0	1	(68)	GND						


 Pin numbers which are not described are not used.





-73 --74 -









### - CR Board -

2.5 GND 4.9


199.6 113.0




### - CG Board -




CR BOARD: IC701 TDA6106Q CG BOARD: IC701 TDA6106Q CB BOARD: IC701 TDA6106Q





### - CB Board -




### • CB BOARD WAVEFORM















HA BOARD IC VOLTAGE LIST

REF.	Pin	VOL.						
	NO.							
	1	5.0						
IC1301	2	5.0						
	3	GND						
•All voltage are in V.								



Schematic diagram

← HA board

# SECTION 7 EXPLODED VIEWS

### NOTE:


 Items with no part number and no description are not stocked because they are seldom required for routine service.

- The construction parts of an assembled part are indicated with a collation number in the remark column
- Items marked " \* " are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.

The componants identified by shading and mark ∆ are critical for safety.

Replace only with part number

specified.




REF. NO.	PART NO.	DESCRIPTION	REMARK	REF. NO.	PART NO.	DESCRIPTION	REMARK
1	X-4034-438-1	BEZNET ASSY (48)		14	4-378-522-31	SCREW (4X20), TAPPING	
2	4-064-651-01	SCREEN (48), CONTRAST		15	X-4035-410-2	GRILLE ASSY, SPEAKER	
3	4-063-555-01	PLATE (L), DIFFUSION					
4	4-058-455-11	PLATE (F), DIFFUSION		16	4-059-346-01	CUSHION, GRILLE	
5	* 4-058-892-01	HOLDER (S), SCREEN		17	4-057-605-01	DOOR, CONTROL PANEL	
				18	4-057-604-01	GUIDE, LED/IR	
6	* 4-058-893-01	HOLDER (L), SCREEN		19	4-057-603-11	BUTTON, MULTI	
7	* 4-051-790-02	HOLDER, MIRSD (L)		20 *	<sup>k</sup> A-1372-474-A	HA MOUNT (VAR)	
8	* 4-051-789-02	HOLDER, MIRSD (R)					
9	* 4-049-098-01	CUSHION		21 *	* X-4035-414-1	CABINET ASSY, BOTTOM	22,23
10	* 4-037-351-01	HOLDER, MIRROR		22	4-048-175-01	FOOT, PLASTIC	
				23	4-040-755-01	CASTER (DIA.30)	
11	4-058-545-01	MIRROR (48), REFLECTION		24	1-505-378-11	SPEAKER (10CM)	
12	7-600-003-52	BLACK ACETATE (2142) 46X50M		25 *	4-057-556-01	BOARD (48), REAR	
13	* 4-057-610-02	COVER, MIRROR					



### 7-2. CHASSIS

■:+BVTP 3X12 7-685-648-79

The componants identified by shading and mark ≜ are critical for safety.
Replace only with part number specified.




REF. NO	D. PART NO.	DESCRIPTION	REMARK	REF. NO.	PART NO.	DESCRIPTION	REMARK
201 202 203 204 205	* 4-057-594-01 4-057-595-21 4-052-894-01	RESISTOR ASSY (HIGH-VOLTAC BRACKET, MAIN TERMINAL BOARD SCREW (4X20), HEAD TAPPING G BOARD, COMPLETE	GE)	209 210 211	* A-1190-265-A 8-598-339-00	A BOARD, COMPLETE PT BOARD, COMPLETE TUNER BTF-LA402 TUNER BTF-WA404 CABLE, P-P	
	<b>△</b> 1-453-238-11	TRANSFORMER ASSY, FLYBACI	07//X4A4)	213 214	1-556-945-21	,	

The componants identified by shading and mark △ are critical for safety.

Replace only with part number specified.

### 7-3. PICTURE TUBE

### ●:+BVTP 4X12 7-685-661-14



REF. NO	PART NO.	DESCRIPTION	REMARK	REF. NO	PART NO.	DESCRIPTION	REMARK
301 302 303 304	4-052-894-01 4-048-142-01	LENS (DELTA 78) SCREW (4X20), HEAD TAPPING SPRING, TENSION PICTURE TUBE 07MXC3 (R)		311 312	1-452-909-31 * A-1331-777-A	Z BOARD, COMPLETE MAGNET ASSY, 4 POLE CR BOARD, COMPLETE CG BOARD, COMPLETE	
305	₾ 8-733-537-0	5 PICTURE TUBE 07MXC2 (G)		314	* A-1331-779-A	CB BOARD, COMPLETE	
306	₾ 8-733-528-0	5 PICTURE TUBE 07MAC3 (B)	D SPRING)	315 316		BRACKET, HV BROCK ASSY, HIGH-VOLTAGE	
307 308	⚠ 1-451-455-3 ⚠ 1-452-790-2	1 DEFLECTION YOKE (R) (B)	D SFRING)	317		CAP (Z), RUBBER	
309	<b>↑</b> 1-451-454-1	1 DEFLECTION YOKE (G)					





### **SECTION 8 ELECTRICAL PARTS LIST**

#### NOTE:

The componants identified by shading and mark A are critical for safety.
Replace only with part number

specified.

 The components identified by 

in this manual have been carefully factory-selected for each set in order to satisfy regulations regarding X-ray radiation. Should replacement be required, replace only with the value originally used.

- $\bullet$  Items marked "  $^{*}$  " are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.
- All variable and adjustable resistors have characteristic curve B, unless otherwise noted.

### RESISTORS

- · All resistors are in ohms
- F : nonflammable

When indicating parts by reference number, please include the board name.

- CAPACITORS PF : μμ F
- There are some cases the reference number on one board overlaps on the other board. Therefore, when ordering parts by the reference number, please include the board name.

REF. NO.	PART NO.	DESCRIPTION			REMARK	REF. NO.	PART NO.	DESCRIPTION			REMAR
	* A-1190-265-A	PT BOARD, COM				C5069	1-163-031-11	CERAMIC CHIP	0.01µF		50V
						C5070	1-163-031-11	CERAMIC CHIP	0.01µF		50V
						C5071	1-163-038-91	CERAMIC CHIP	0.1µF		25V
		<capacitor></capacitor>				C5072		CERAMIC CHIP	0.1µF		25V
						C5073		CERAMIC CHIP	0.47µF		25V
C5001	1-104-664-11	ELECT	47μF	20%	25V	C5076		CERAMIC CHIP	100PF	5%	50V
C5002		CERAMIC CHIP	100PF	5%	50V	00070	1 100 201 11	0214 11110 0111	10011	270	201
C5002	1-126-957-11		0.22μF	20%	50V	C5077	1-163-251-11	CERAMIC CHIP	100PF	5%	50V
C5004		CERAMIC CHIP	0.22μ1 0.1μF	2070	25V	C5078		CERAMIC CHIP	0.01µF	370	50V
C5005		CERAMIC CHIP	0.0047μF	10%	50V	C5079	1-103-031-11		47μF	20%	25V
C3003	1-103-017-00	CERAINIC CIII	0.004/μ1	1070	30 V	C5079	1-126-960-11		4/μΓ 1μF	20%	50V
C5006	1 126 050 11	ELECT	0.47E	200/	5037				•		
C5006	1-126-959-11		0.47μF	20%	50V	C5101	1-104-664-11	ELECT	47μF	20%	25V
C5007	1-126-961-11		2.2μF	20%	50V	05100	1 162 021 11	CED LINE CHID	0.01 F		5017
C5008	1-126-963-11		4.7μF	20%	50V	C5102		CERAMIC CHIP	0.01µF	100/	50V
C5009		CERAMIC CHIP 4		10%	50V	C5103		CERAMIC CHIP	$0.01\mu F$	10%	50V
C5010	1-126-934-11	ELECT	220μF	20%	16V	C5104		CERAMIC CHIP	$0.01\mu F$		50V
						C5105		CERAMIC CHIP	10PF	0.5PF	
C5011	1-126-960-11	ELECT	1μF	20%	50V	C5106	1-163-031-11	CERAMIC CHIP	$0.01\mu F$		50V
C5012	1-126-959-11	ELECT	0.47µF	20%	50V						
C5013	1-163-021-91	CERAMIC CHIP	$0.01\mu F$	10%	50V	C5107	1-163-245-11	CERAMIC CHIP	56PF	5%	50V
C5014	1-163-038-91	CERAMIC CHIP	$0.1\mu F$		25V	C5108	1-163-031-11	CERAMIC CHIP	$0.01\mu F$		50V
C5015	1-163-229-11	CERAMIC CHIP	12PF	5%	50V	C5109	1-126-964-11	ELECT	10μF	20%	50V
						C5110	1-126-964-11	ELECT	10μF	20%	50V
C5016	1-163-038-91	CERAMIC CHIP	$0.1 \mu F$		25V	C5111	1-163-099-00	CERAMIC CHIP	18PF	5%	50V
C5017	1-163-038-91	CERAMIC CHIP	0.1µF		25V						
C5018	1-126-934-11		220µF	20%	16V	C5112	1-163-031-11	CERAMIC CHIP	$0.01 \mu F$		50V
C5019		CERAMIC CHIP	0.1µF		25V	C5113		CERAMIC CHIP	0.22µF	10%	16V
C5020		CERAMIC CHIP	0.1μF		25V	C5114		CERAMIC CHIP	33PF	5%	50V
00020	1 100 000 71	obra mare orm	0.1762		20 .	C5115		CERAMIC CHIP	15PF	5%	50V
C5021	1-163-038-91	CERAMIC CHIP	0.1µF		25V	C5116	1-164-096-11		0.01µF	570	50V
C5022		CERAMIC CHIP	220PF	5%	50V	C3110	1 104 070 11	CLIMINIC	0.01μ1		30 <b>v</b>
C5022	1-103-239-91		22011 10μF	20%	50V	C5117	1 163 800 11	CERAMIC CHIP	0.047µF	10%	25V
C5023	1-126-933-11		100μF	20%	16V	C5117			•	10%	50V
C5024			0.1μF	2070				CERAMIC CHIP	0.01µF	10%	
C3023	1-103-036-91	CERAMIC CHIP	0.1μΓ		25V	C5119	1-164-096-11		0.01μF	E0/	50V
C5051	1 162 020 01	CED AMIC CUID	0.1		2537	C5120		CERAMIC CHIP	15PF	5%	50V
C5051		CERAMIC CHIP	0.1μF	100/	25V	C5121	1-163-021-91	CERAMIC CHIP	$0.01\mu F$	10%	50V
C5052		CERAMIC CHIP	0.22μF	10%	16V	G5100	1 162 000 11	CED AMIC CUID	0.047	100/	2517
C5053	1-104-664-11		47μF	20%	25V	C5122		CERAMIC CHIP	0.047μF	10%	25V
C5054		CERAMIC CHIP	470PF	10%	50V	C5123	1-126-960-11		1μF	20%	50V
C5055	1-164-346-11	CERAMIC CHIP	1μF		16V	C5124		CERAMIC CHIP	0.01µF	10%	50V
						C5125		CERAMIC CHIP	$0.01\mu F$	10%	50V
C5057		CERAMIC CHIP	220PF	10%	50V	C5126	1-163-017-00	CERAMIC CHIP	$0.0047 \mu F$	10%	50V
C5058		CERAMIC CHIP	$0.1\mu F$		25V						
C5062	1-104-664-11	ELECT	47μF	20%	25V	C5127	1-104-664-11		47μF	20%	25V
C5063	1-104-664-11	ELECT	47μF	20%	25V	C5129	1-163-038-11	CERAMIC CHIP	$0.1\mu F$		25V
C5064	1-163-239-11	CERAMIC CHIP	33PF	5%	50V	C5130	1-104-664-11	ELECT	47μF	20%	25V
						C5131	1-163-021-91	CERAMIC CHIP	0.01µF	10%	50V
C5065	1-163-239-11	CERAMIC CHIP	33PF	5%	50V	C5132	1-163-231-11	CERAMIC CHIP	15PF	5%	50V
	1 162 021 11	CERAMIC CHIP	$0.01 \mu F$		50V						
C5066	1-103-031-11										
C5066 C5067		CERAMIC CHIP	0.01µF		50V	C5133	1-163-038-91	CERAMIC CHIP	$0.1 \mu F$		25V



REF. NO.	PART NO.	DESCRIPTION			REMARK	REF. NO.	PART NO.	DESCRIPTION			REMARK
C5135	1-163-031-11	CERAMIC CHIP	0.01µF		50V	IC5052	8-759-533-89	IC SDA9288XE-G	EG-B121		
C5136	1-163-031-11	CERAMIC CHIP	0.01µF		50V	IC5101	8-752-375-30	IC CXD2043Q			
C5137	1-163-031-11	CERAMIC CHIP	$0.01 \mu F$		50V	IC5102	8-752-062-80	IC CXA1686M			
						IC5103	8-759-701-56	IC NJM78M05FA			
C5138	1-104-664-11		47μF	20%	25V						
C5139	1-126-964-11		10μF	20%	50V			COIL >			
C5140 C5141		CERAMIC CHIP CERAMIC CHIP	0.1μF 0.1μF		25V 25V			<coil></coil>			
C5141		CERAMIC CHIP	0.1μF		25V	L5001	1-410-478-11	INDUCTOR	47μΗ		
			0.1-64-			L5002	1-410-478-11		47μH		
C5143	1-163-031-11	CERAMIC CHIP	$0.01 \mu F$		50V	L5003	1-410-478-11	INDUCTOR	47μH		
C5144	1-163-031-11	CERAMIC CHIP	$0.01 \mu F$		50V	L5004	1-410-478-11	INDUCTOR	47μΗ		
C5145	1-126-964-11		10μF	20%	50V	L5052	1-408-607-31	INDUCTOR	22μΗ		
C5146		CERAMIC CHIP	0.01µF	10%	50V	1.5101	1 410 470 11	INDLICTOR	10		
C5147	1-163-038-91	CERAMIC CHIP	0.1μF		25V	L5101	1-410-470-11		10μH		
C5148	1-163-038-91	CERAMIC CHIP	0.1μF		25V	L5102 L5103	1-410-476-11 1-410-470-11		33μΗ 10μΗ		
C5149	1-104-664-11		47μF	20%	25V	L5105	1-410-470-11		10μH		
C5150		CERAMIC CHIP	0.01µF		50V						
C5151	1-104-664-11		47μF	20%	25V						
C5152	1-163-031-11	CERAMIC CHIP	0.01µF	50V				$<\!\!TRANSISTOR\!\!>$			
C5153	1-104-664-11		47μF	20%	25V	Q5001		TRANSISTOR 2SI			
C5154	1-104-664-11		47μF	20%	25V	Q5002		TRANSISTOR 2S			
C5157	1-104-004-11	CERAMIC CHIP	0.1μF	10%	25V	Q5003 Q5004		TRANSISTOR 2SI			
						Q5005		TRANSISTOR 2SI			
		<connector></connector>				(					
						Q5051	8-729-216-22	TRANSISTOR 2S	A1162-G		
		CONNECTOR, BO				Q5052		TRANSISTOR 2S.			
CN5101	1-770-156-21	CONNECTOR, BO	DARD TO I	BOARE	) 8P	Q5053		TRANSISTOR 2S			
						Q5054 Q5055		TRANSISTOR 2SI			
		<diode></diode>				Q3033	8-729-210-22	TRANSISTOR 25	A1102-G		
		(DIODL)				Q5056	8-729-422-27	TRANSISTOR 2SI	D601A-O		
D5053	8-719-404-49	DIODE MA111				Q5057		TRANSISTOR 2SI			
D5101	8-719-158-15	DIODE RD5.6SB				Q5101	8-729-422-27	TRANSISTOR 2SI	D601A-Q		
						Q5102	8-729-216-22	TRANSISTOR 2S.	A1162-G		
		EEDDITE DE L				Q5103	8-729-216-22	TRANSISTOR 2S	A1162-G		
		<ferrite bead<="" td=""><td>&gt;</td><td></td><td></td><td>05104</td><td>9 720 216 22</td><td>TD A NEIGTOD 2C</td><td>1162 C</td><td></td><td></td></ferrite>	>			05104	9 720 216 22	TD A NEIGTOD 2C	1162 C		
FB5051	1-414-135-11	FERRITE	0μΗ			Q5104 Q5105		TRANSISTOR 2SA TRANSISTOR 2SA			
FB5052	1-414-135-11		0μΗ			Q5105 Q5106		TRANSISTOR 2SI			
FB5053	1-414-135-11		0μΗ			Q5107		TRANSISTOR 2SI			
FB5101		CONDUCTOR, CI				Q5108		TRANSISTOR 2SI	-		
FB5102	1-216-295-91	CONDUCTOR, CI	HIP								
		G01#				Q5109		TRANSISTOR 2SA			
FB5103		CONDUCTOR, CI				Q5110		TRANSISTOR 2S			
FB5104 FB5105	1-414-135-11 1-414-135-11		0μH 0μH			Q5111 Q5112		TRANSISTOR 2S. TRANSISTOR 2S.			
FB5105	1-414-135-11		оµн ОµН			Q3112	0-129-422-21	TRANSISTOR 251	D001A-Q		
FB5107	1-414-135-11		0μΗ								
								<resistor></resistor>			
FB5108	1-410-396-41	FERRITE	$0.45\mu H$								
FB5109	1-414-135-11		0μΗ			R5001		METAL GLAZE	1K	5%	1/10W
FB5110	1-414-135-11	FERRITE	0μΗ			R5002		METAL GLAZE	3.3K	5%	1/10W
						R5003		METAL GLAZE	2.2K	5% 5%	1/10W
		<filter></filter>				R5004 R5005		METAL GLAZE METAL GLAZE	220 100	5% 5%	1/10W 1/10W
						13003	1-210-023-91	WILLIAL OLAZE	100	J 70	1/ 1 () VV
FL5101	1-239-847-11	FILTER, LOW PA	SS			R5006	1-216-025-91	METAL GLAZE	100	5%	1/10W
FL5102		FILTER, LOW PA				R5007		METAL GLAZE	100	5%	1/10W
FL5103	1-239-847-11	FILTER, LOW PA	SS			R5008		METAL GLAZE	330K	5%	1/10W
						R5009		METAL GLAZE	470	5%	1/10W
		10				R5010	1-216-071-00	METAL GLAZE	8.2K	5%	1/10W
		<ic></ic>				R5011	1 216 077 00	METAL GLAZE	15K	5%	1/10W
IC5001	8-752-086-80	IC CXA2019Q-T4				R5011		METAL GLAZE	15K 10K	5% 5%	1/10W 1/10W
100001	3 .52 000 00					1.0012	0/5 00	OLI ILL		2 /0	1,1011



REF. NO.	PART NO.	DESCRIPTION		I	REMARK	REF. NO.	PART NO.	DESCRIPTION		:	REMARK
R5013 R5014		METAL GLAZE METAL GLAZE	1.5K 100	5% 5%	1/10W 1/10W	R5116	1-216-043-91	METAL GLAZE	560	5%	1/10W
R5014		METAL GLAZE	470	5%	1/10W 1/10W	R5117	1-216-049-91	METAL GLAZE	1K	5%	1/10W
10010	1 210 0 .1 00		.,,	270	1,10,1	R5118		METAL GLAZE	8.2K	5%	1/10W
R5016	1-216-041-00	METAL GLAZE	470	5%	1/10W	R5120	1-208-766-11	METAL CHIP	220	0.50%	1/10W
R5017	1-216-057-00	METAL GLAZE	2.2K	5%	1/10W	R5121	1-216-041-00	METAL GLAZE	470	5%	1/10W
R5018	1-216-057-00	METAL GLAZE	2.2K	5%	1/10W	R5122	1-216-049-91	METAL GLAZE	1K	5%	1/10W
R5019	1-216-037-00	METAL GLAZE	330	5%	1/10W						
R5021	1-216-041-00	METAL GLAZE	470	5%	1/10W	R5124	1-216-025-91	METAL GLAZE	100	5%	1/10W
						R5127	1-216-069-00	METAL CHIP	6.8K	5%	1/10W
R5022	1-216-047-91	METAL GLAZE	820	5%	1/10W	R5128	1-216-075-00	METAL GLAZE	12K	5%	1/10W
R5023	1-216-041-00	METAL GLAZE	470	5%	1/10W	R5129	1-216-043-91	METAL GLAZE	560	5%	1/10W
R5024	1-216-049-91	METAL GLAZE	1K	5%	1/10W	R5130	1-216-075-00	METAL GLAZE	12K	5%	1/10W
R5025	1-216-075-00	METAL GLAZE	12K	5%	1/10W						
R5026	1-216-081-00	METAL GLAZE	22K	5%	1/10W	R5132	1-216-043-91	METAL GLAZE	560	5%	1/10W
						R5133	1-216-081-00	METAL GLAZE	22K	5%	1/10W
R5027	1-216-049-91	METAL GLAZE	1K	5%	1/10W	R5134	1-216-077-00	METAL GLAZE	15K	5%	1/10W
R5033	1-216-025-91	METAL GLAZE	100	5%	1/10W	R5135	1-216-081-00	METAL GLAZE	22K	5%	1/10W
R5051	1-216-061-00	METAL GLAZE	3.3K	5%	1/10W	R5136	1-216-081-00	METAL GLAZE	22K	5%	1/10W
R5052	1-216-049-91	METAL GLAZE	1K	5%	1/10W						
R5053	1-216-065-91	METAL GLAZE	4.7K	5%	1/10W	R5137	1-208-766-11	METAL CHIP	220	0.50%	1/10W
						R5138	1-208-794-11	METAL CHIP	3.3K	0.50%	1/10W
R5054		METAL GLAZE	4.7K	5%	1/10W	R5139	1-208-794-11	METAL CHIP	3.3K	0.50%	1/10W
R5055	1-216-049-91	METAL GLAZE	1K	5%	1/10W	R5140	1-216-041-00	METAL GLAZE	470	5%	1/10W
R5056		METAL GLAZE	10K	5%	1/10W	R5141	1-216-033-00	METAL GLAZE	220	5%	1/10W
R5057		METAL GLAZE	1K	5%	1/10W						
R5058	1-216-049-91	METAL GLAZE	1K	5%	1/10W	R5142		METAL GLAZE	470	5%	1/10W
						R5143	1-216-033-00	METAL GLAZE	220	5%	1/10W
R5059		METAL GLAZE	100	5%	1/10W	R5144		METAL GLAZE	5.6K	5%	1/10W
R5060		METAL GLAZE	1K	5%	1/10W	R5145	1-216-035-00	METAL GLAZE	270	5%	1/10W
R5061		METAL GLAZE	4.7K	5%	1/10W	R5146	1-216-035-00	METAL GLAZE	270	5%	1/10W
R5062		METAL GLAZE	1K	5%	1/10W						
R5063	1-216-025-91	METAL GLAZE	100	5%	1/10W	R5147		METAL CHIP	1.8K		1/10W
						R5148		METAL CHIP	1.8K		1/10W
R5072		METAL GLAZE	6.8K	5%	1/10W	R5149		METAL GLAZE	560	5%	1/10W
R5073		METAL GLAZE	1K	5%	1/10W	R5150		METAL CHIP	3.3K		1/10W
R5074		METAL GLAZE	2.2K	5%	1/10W	R5151	1-208-794-11	METAL CHIP	3.3K	0.50%	1/10W
R5075		METAL GLAZE	560	5%	1/10W						
R5076	1-216-069-00	METAL GLAZE	6.8K	5%	1/10W	R5152		METAL GLAZE	100	5%	1/10W
D 5000	1 21 5 01 7 00				4 /4 0777	R5156		METAL GLAZE	100	5%	1/10W
R5077		METAL GLAZE	680	5%	1/10W	R5157		METAL GLAZE	100	5%	1/10W
R5078		METAL GLAZE	470	5%	1/10W	R5158		METAL GLAZE	100	5%	1/10W
R5079		METAL GLAZE	1K	5%	1/10W	R5159	1-216-025-91	METAL GLAZE	100	5%	1/10W
R5080		METAL GLAZE	1K	5%	1/10W	D5160	1 216 025 01	METAL OLATE	100	50/	1/10337
R5081	1-216-041-00	METAL GLAZE	470	5%	1/10W	R5160		METAL GLAZE	100	5%	1/10W
R5082	1 216 025 01	METAL CLAZE	100	5%	1/1007	R5161 R5163		METAL GLAZE	100 100	5% 5%	1/10W 1/10W
R5082		METAL GLAZE METAL GLAZE	220	5%	1/10W 1/10W	K3103	1-210-023-91	METAL GLAZE	100	370	1/10 W
R5085		METAL GLAZE	220	5%	1/10W 1/10W						
R5089		METAL GLAZE	2.2K	5%	1/10W 1/10W			<crystal></crystal>			
R5099		METAL GLAZE	100	5%	1/10W 1/10W			(CKISIAL)			
K3090	1-210-023-91	METAL GLAZE	100	370	1/10 VV	X5001	1 577 611 11	OSCILALTOR, CE	DAMIC		
R5091	1-216-025-91	METAL GLAZE	100	5%	1/10W	X5001 X5002		OSCILLATOR, CR			
R5091		METAL GLAZE	100	5%	1/10W	X5051		VIBRATOR, CRYS			
R5102		CONDUCTOR, CH		570	1/10**	X5101		VIBRATOR, CRYS			
R5102		METAL GLAZE	820	5%	1/10W	X5101 X5102		OSCILALTOR, CE			
R5103		CONDUCTOR, CH		570	1/10**	2102	1 377 011 11	OBCILIALION, CL	ita nine		
10104	1 210 293 91	CONDUCTOR, CI									
R5106	1-216-035-00	METAL GLAZE	270	5%	1/10W						
R5107		METAL GLAZE	100K	5%	1/10W	******	******	******	*******	*****	*****
R5108		METAL GLAZE	4.7K	5%	1/10W						
R5100		METAL CHIP	560		1/10W	*	A-1298-448-A	A BOARD, COMP	LETE		
R5110		METAL CHIP	470		1/10W			******			
R5112	1-216-049-91	METAL GLAZE	1K	5%	1/10W	*	4-051-927-01	CASE, SHIELD			
R5113	1-216-043-91	METAL GLAZE	560	5%	1/10W		4-382-854-11	SCREW (M3X10),	P, SW (+)		
R5114	1-216-073-00	METAL GLAZE	10K	5%	1/10W						
R5115	1-216-049-91	METAL GLAZE	1K	5%	1/10W						



REF. NO.	PART NO.	DESCRIPTION			REMARK	REF. NO.	PART NO.	DESCRIPTION			REMARK
		CARACITOR.				G220	1 126 064 11	ELECT.	10F	200/	5017
		<capacitor></capacitor>				C229 C230	1-126-964-11 1-126-964-11		10μF 10μF	20% 20%	50V 50V
C001	1-163-031-11	CERAMIC CHIP	0.01µF		50V	C230	1-126-933-11		100μF	20%	16V
C001	1-126-933-11		100μF	20%	16V	C232		CERAMIC CHIP	0.1μF	10%	25V
C005	1-126-964-11		10μF	20%	50V	C302	1-126-959-11		0.47μF	20%	50V
C006		CERAMIC CHIP	0.01µF	2070	50V	C302	1 120 757 11	EEECT	0.17μ1	2070	50 1
C017		CERAMIC CHIP	0.047µF	10%	25V	C303	1-163-031-11	CERAMIC CHIP	0.01µF		50V
2017	1 103 007 11	CERTIFIC CITI	0.0+/μ1	1070	25 1	C304	1-126-964-11		10μF	20%	50V
C018	1-163-259-91	CERAMIC CHIP	220PF	5%	50V	C305		CERAMIC CHIP	15PF	5%	50V
C019	1-126-960-11		1μF	20%	50V	C308		CERAMIC CHIP	0.1µF	10%	25V
C021		CERAMIC CHIP	47PF	5%	50V	C309	1-126-933-11		100μF	20%	16V
C024		CERAMIC CHIP	0.1µF	10%	25V	0000	1 120 700 11	22201	100pt1	2070	10.
C025		CERAMIC CHIP	0.01µF		50V	C310	1-163-133-00	CERAMIC CHIP	470PF	5%	50V
						C311		CERAMIC CHIP	3300PF	5%	25V
C026	1-107-714-11	ELECT	10μF	20%	16V	C312	1-126-959-11		0.47µF	20%	50V
C027	1-126-935-11		470µF	20%	16V	C313	1-130-495-00		0.1µF	5%	50V
C028	1-107-714-11		10μF	20%	16V	C314	1-130-495-00		0.1µF	5%	50V
C032		CERAMIC CHIP	0.1µF	10%	25V						
C033		CERAMIC CHIP	220PF	5%	50V	C315	1-130-495-00	FILM	0.1µF	5%	50V
						C316	1-163-021-91	CERAMIC CHIP	0.01µF	10%	50V
C034	1-163-809-11	CERAMIC CHIP	$0.047 \mu F$	10%	25V	C317	1-163-021-91	CERAMIC CHIP	0.01µF	10%	50V
C035	1-104-664-11	ELECT	47μF	20%	25V	C318	1-163-021-91	CERAMIC CHIP	0.01µF	10%	50V
C036	1-163-231-11	CERAMIC CHIP	15PF	5%	50V	C319	1-164-004-11	CERAMIC CHIP	0.1µF	10%	25V
C037	1-163-237-11	CERAMIC CHIP	27PF	5%	50V				•		
C038	1-126-960-11	ELECT	1μF	20%	50V	C320	1-164-004-11	CERAMIC CHIP	$0.1 \mu F$	10%	25V
			•			C321	1-126-963-11	ELECT	4.7μF	20%	50V
C045	1-163-017-00	CERAMIC CHIP	$0.0047 \mu F$	10%	50V	C322	1-130-495-00	MYLAR	0.1μF	5%	50V
C046	1-163-031-11	CERAMIC CHIP	0.01µF		50V	C323	1-137-581-11	FILM	0.1µF	5%	100V
C047		CERAMIC CHIP	0.0012μF	10%	50V	C324	1-164-182-11	CERAMIC CHIP	0.0033µF	10%	50V
C048	1-164-005-11	CERAMIC CHIP	0.47μF		25V				•		
C054	1-163-033-91	CERAMIC CHIP	$0.022 \mu F$		50V	C325	1-126-959-11	ELECT	$0.47\mu F$	20%	50V
						C326	1-126-964-11	ELECT	10μF	20%	50V
C057	1-163-259-91	CERAMIC CHIP	220PF	5%	50V	C329	1-163-017-00	CERAMIC CHIP	$0.0047\mu F$	10%	50V
C092	1-163-259-91	CERAMIC CHIP	220PF	5%	50V	C330	1-163-263-11	CERAMIC CHIP	330PF	5%	50V
C107	1-163-031-11	CERAMIC CHIP	$0.01\mu F$		50V	C331	1-126-959-11	ELECT	$0.47\mu F$	20%	50V
C108	1-104-664-11	ELECT	47μF	20%	25V						
C109	1-126-916-11	ELECT	1000μF	20%	6.3V	C332	1-163-021-91	CERAMIC CHIP	$0.01\mu F$	10%	50V
						C333	1-163-021-91	CERAMIC CHIP	$0.01\mu F$	10%	50V
C110		CERAMIC CHIP	15PF	5%	50V	C334		CERAMIC CHIP 0	.001µF	5%	50V
C111	1-163-229-11	CERAMIC CHIP	12PF	5%	50V	C335	1-126-935-11	ELECT	470μF	20%	16V
C119		CERAMIC CHIP	10PF	0.5PF		C337	1-126-960-11	ELECT	1μF	20%	50V
C120		CERAMIC CHIP	10PF	0.5PF							
C121	1-163-227-11	CERAMIC CHIP	10PF	0.5PF	50V	C338	1-126-961-11		2.2μF	20%	50V
						C339	1-126-959-11		$0.47\mu F$	20%	50V
C124		CERAMIC CHIP	$0.01\mu F$		50V	C342	1-130-495-00		0.1μF	5%	50V
C201	1-126-960-11		1μF	20%	50V	C344		CERAMIC CHIP	100PF	5%	50V
C203	1-126-935-11		470μF	20%	16V	C345	1-163-251-11	CERAMIC CHIP	100PF	5%	50V
C204		CERAMIC CHIP	0.1μF	10%	25V	62.40	1 160 045 11	CED AND CHID	5 CDE	50/	5017
C206	1-164-004-11	CERAMIC CHIP	0.1µF	10%	25V	C349		CERAMIC CHIP	56PF	5%	50V
C207	1 164 004 11	CED A MIC CHID	0.1	100/	251	C351		CERAMIC CHIP	0.1μF	10%	25V
C207		CERAMIC CHIP	0.1μF	10%	25V	C401	1-126-964-11		10μF	20%	50V
C208		CERAMIC CHIP	0.1μF	10%	25V	C402	1-126-964-11		10μF	20%	50V
C209	1-126-964-11		10μF	20%	50V	C403	1-137-367-11	FILM	0.0033μF	5%	50V
C210	1-126-964-11		10μF	20%	50V	C404	1 127 267 11	EII M	0.0022E	<b>5</b> 0/	50V
C211	1-126-964-11	ELECT	10μF	20%	50V	C404 C405	1-137-367-11		0.0033μF 0.022μF	5% 5%	50V
C212	1-126-964-11	EI ECT	10μF	20%	50V	C405	1-137-372-11 1-130-495-00		0.022μΓ 0.1μF	5% 5%	50V
C212	1-126-964-11		10μΓ 10μF	20%	50V	C400 C407	1-130-493-00		0.1μ1· 1μF	20%	50V
C213	1-126-964-11		10μΓ 10μF	20%	50V	C407	1-120-900-11		0.0033µF		50V
C218		CERAMIC CHIP	10μr 0.01μF	∠U /0	50V	C+00	1-106-161-1	1 11-171	υ.υυσσμι	J 70	JU ¥
C218	1-103-031-11		0.01μΓ 10μF	20%	50V	C409	1-137-367-11	FII M	0.0033µF	5%	50V
C217	1-120-704-11	LLLCI	τομι	∠U /0	JU V	C409 C410	1-137-307-11		0.0035μF 0.022μF	5%	50V
C220	1-126-964-11	ELECT	10μF	20%	50V	C410 C411	1-137-372-11		0.022μΓ 0.1μF	5%	50V
C220		CERAMIC CHIP	0.1μF	10%	25V	C411 C412	1-130-493-00		0.1μΓ 100μF	20%	16V
C224	1-104-004-11		0.1μΓ 47μF	20%	25 V 25 V	C412 C413	1-120-933-11		22μF	20%	25V
C224	1-126-964-11		47μΓ 10μF	20%	50V	C+13	1 120 331-11	LLLCI	2241	20/0	<i>20</i> ₹
C227		CERAMIC CHIP	0.1μF	10%	25V	C414	1-163-038-11	CERAMIC CHIP	0.1µF		25V
				•		C415	1-126-964-11		10μF	20%	50V
								- <del>-</del>			



REF. NO.	PART NO.	DESCRIPTION			REMARK_	REF. NO.	PART NO.	DESCRIPTION			REMARK
C416	1-126-964-11		10μF	20%	50V	C1521	1-164-161-11	CERAMIC CHIP	0.0022μF	10%	50V
C417 C418	1-126-964-11 1-104-664-11		10μF	20% 20%	50V 25V	C1522	1 164 004 11	CERAMIC CHIP	0.1uE	10%	25V
C418	1-104-004-11	ELECI	47μF	20%	23 V	C1522 C1523		CERAMIC CHIP	0.1μF 470PF	10%	50V
C419	1-128-551-11	ELECT	22μF	20%	25V	C1523	1-137-150-11		0.01µF	10%	100V
C422	1-104-664-11		47μF	20%	25V	C1525	1-106-220-00		0.1µF	10%	100V
C424	1-126-961-11		2.2µF	20%	50V	C1601	1-126-935-11		470µF	20%	16V
C425	1-126-935-11		470µF	20%	16V						
C426	1-126-964-11	ELECT	10μF	20%	50V	C1602	1-126-767-11	ELECT	1000μF	20%	16V
						C1603	1-126-916-11	ELECT	1000μF	20%	6.3V
C427	1-126-933-11		100μF	20%	16V	C1604	1-126-934-11		220μF	20%	16V
C428	1-126-969-11		220μF	20%	50V	C1605		CERAMIC CHIP	$0.01 \mu F$		50V
C429	1-126-967-11		47μF	20%	50V	C1606	1-163-031-11	CERAMIC CHIP	0.01µF		50V
C430 C431	1-126-964-11 1-126-969-11		10μF 220μF	20% 20%	50V 50V	C1607	1 162 021 11	CERAMIC CHIP	0.01µF		50V
C451	1-120-909-11	ELECI	220μΓ	20%	30 V	C1607 C1608		CERAMIC CHIP	0.01μF 0.01μF		50V
C432	1-136-173-00	FII M	0.47µF	5%	50V	C1608		CERAMIC CHIP	0.01µF		50V
C433	1-130-495-00		0.1μF	5%	50V	C1610	1-126-933-11		100μF	20%	16V
C434	1-128-550-11		2200µF	20%	50V	C1611		CERAMIC CHIP	0.01µF		50V
C435	1-130-495-00	FILM	0.1μF	5%	50V				•		
C436	1-128-548-11	ELECT	4700μF	20%	25V			<connector></connector>			
C437	1-128-548-11	ELECT	4700µF	20%	25V	CN001 *	1 564 507 11	PLUG, CONNECT	OD 4D		
C437 C440	1-126-964-11		4700μΓ 10μF	20%	50V			PLUG, CONNECT			
C440	1-126-964-11		10μF	20%	50V			CONNECTOR, BC		OARD	10P
C1101		CERAMIC CHIP	0.01µF	2070	50V	CN004		CONNECTOR, BC			
C1102		CERAMIC CHIP	0.01µF		50V			CONNECTOR, BC			
G1102	1 126 022 11	DI DOT	100 F	200/	1.07	CN 1202 v	1 564 500 11	DILLIC CONNECT	OD 5D		
C1103	1-126-933-11		100μF	20%	16V			PLUG, CONNECT			
C1104 C1105	1-164-161-11	CERAMIC CHIP	0.0022μF 1μF	10% 20%	50V 50V	CN303 *		PLUG, CONNECT CONNECTOR, BC		OADE	N OD
C1105	1-126-933-11		100μF	20%	16V	CN304 CN305		CONNECTOR, BC			
C1100	1-126-953-11		47μF	20%	25V			PLUG, CONNECT		OAKL	201
								,			
C1108	1-126-964-11		10μF	20%	50V			PLUG, CONNECT	OR 3P		
C1109	1-126-933-11		100μF	20%	16V	CN403		TAB (CONTACT)			
C1110		CERAMIC CHIP	0.0022μF	10%	50V			PLUG, CONNECT			
C1111	1-126-960-11	CERAMIC CHIP	1μF	20%	50V 50V			PLUG, CONNECT CONNECTOR, BC		0 4 D D	10D
C1112	1-103-031-11	CERAMIC CHIP	0.01µF		30 V	CN1001 **	1-//4-185-11	CONNECTOR, BC	JAKD TOB	UAKD	10P
C1113	1-126-964-11	ELECT	10μF	20%	50V	CN1602 *	1-774-183-11	CONNECTOR, BC	OARD TOB	OARD	10P
C1114	1-163-031-11	CERAMIC CHIP	0.01µF		50V						
C1115	1-163-031-11	CERAMIC CHIP	$0.01 \mu F$		50V			<diode></diode>			
C1116		CERAMIC CHIP	0.01µF		50V						
C1117	1-163-031-11	CERAMIC CHIP	0.01µF		50V	D001		DIODE 1SS133T-7			
C1110	1 162 021 11	CED A MIC CHID	0.010E		50V	D002		DIODE 1SS133T-7 DIODE 1SS133T-7			
C1118 C1119	1-103-031-11	CERAMIC CHIP	0.01μF 100μF	20%	50V 50V	D003 D004		DIODE 1SS133T-7			
C1119	1-126-933-11		100μF	20%	16V	D004 D007		DIODE RD5.6ESB			
C1122	1-104-664-11		47μF	20%	25V	,					
C1501		CERAMIC CHIP	0.001µF	10%	50V	D010	8-719-109-89	DIODE RD5.6ESB	2		
			•			D011		DIODE RD5.6ESB			
C1502	1-107-504-11		10PF		500V	D202		DIODE RD10ESB2			
C1503	1-136-177-00		1μF	5%	50V	D203		DIODE RD5.6ESB	2		
C1506	1-126-969-11		220μF	20%	50V	D206	8-719-977-28	DIODE DTZ10B			
C1507 C1508	1-163-243-11 1-137-401-11	CERAMIC CHIP	47PF	5% 10%	50V 100V	D207	9 710 077 20	DIODE DT710B			
C1308	1-13/-401-11	I ILIVI	0.22μF	10%	100 4	D207 D208		DIODE DTZ10B DIODE DTZ10B			
C1509	1-163-251-11	CERAMIC CHIP	100PF	5%	50V	D208 D209		DIODE DTZ10B			
C1510	1-126-942-61		1000μF	20%	25V	D210		DIODE DTZ10B			
C1511	1-126-942-61		1000μF	20%	25V	D211		DIODE DTZ10B			
C1513		CERAMIC CHIP	0.01µF		50V						
C1514	1-163-031-11	CERAMIC CHIP	0.01µF		50V	D212	8-719-977-28	DIODE DTZ10B			
						D213		DIODE DTZ10B			
C1517	1-126-964-11		10μF	20%	50V	D214		DIODE RD10ESB2			
C1518	1-126-933-11		100μF	20%	16V	D215		DIODE RD10ESB2			
C1519	1-126-933-11		100μF	20%	16V 50V	D216	δ-/19-110-17	DIODE RD10ESB2	۷		
C1520	1-126-964-11	ELECI	10μF	20%	50V						



REF. NO.	PART NO.	DESCRIPTION	REMARK	REF. NO.	PART NO.	DESCRIPTION		REMARK
D015	0.510.110.15	D.O.D. D. 100000		***	4 == 4 = 40 44	THE STATE OF THE S	-	
D217		DIODE RD10ESB2 DIODE RD10ESB2		J206 J208		JACK BLOCK, PIN JACK BLOCK, PIN		
D218 D219		DIODE RD10ESB2		J208 J209		TERMINAL BLOC		
D219 D220		DIODE RD10ESB2		3209	1-774-731-11	TERMINAL BLOC	Λ, 5	
D221		DIODE RD10ESB2						
						<chip conduct<="" td=""><td>OR&gt;</td><td></td></chip>	OR>	
D222	8-719-110-17	DIODE RD10ESB2						
D225	8-719-110-17	DIODE RD10ESB2		JR003	1-216-295-91	CONDUCTOR, CH	IIP	
D226		DIODE RD10ESB2		JR201		CONDUCTOR, CH		
D232		DIODE MTZJ-T-77-36B		JR202		CONDUCTOR, CH		
D236	8-719-110-17	DIODE RD10ESB2		JR1501		CONDUCTOR, CH		
D237	8 710 110 17	DIODE RD10ESB2		JR1502	1-216-295-91	CONDUCTOR, CH	IIP	
D237 D238		DIODE RD10ESB2		JR1601	1-216-295-91	CONDUCTOR, CH	ΠP	
D239		DIODE ISS133T-77		JR1602		CONDUCTOR, CH		
D240		DIODE 1SS133T-77		JR1603		CONDUCTOR, CH		
D241	8-719-991-33	DIODE 1SS133T-77		JR1604	1-216-295-91	CONDUCTOR, CH	IIP	
				JR1605	1-216-295-91	CONDUCTOR, CH	IIP	
D305		DIODE RD10ESB2						
D401		DIODE 1SS133T-77		JR1607		CONDUCTOR, CH		
D403		DIODE 155122T 77		JR1609		CONDUCTOR, CH		
D405 D406		DIODE 1SS133T-77 DIODE 1SS133T-77		JR1610 JR1611		CONDUCTOR, CH CONDUCTOR, CH		
D400	0-719-991-33	DIODE 1331331-77				CONDUCTOR, CH		
D408	8-719-991-33	DIODE 1SS133T-77		3111012	1 210 255 51	conduction, cir		
D410		DIODE MTZJ-T-77-36B		JR1613	1-216-295-91	CONDUCTOR, CH	IIP	
D411	8-719-929-15	DIODE HZS9.1NB2		JR1614	1-216-295-91	CONDUCTOR, CH	IIP	
D1101	8-719-982-26	DIODE MTZJ-33B		JR1615		CONDUCTOR, CH		
D1102	8-719-977-28	DIODE DTZ10B				CONDUCTOR, CH		
D1102	0.710.077.00	DIODE DEZION		JR1619	1-216-295-91	CONDUCTOR, CH	IIP	
D1103 D1104		DIODE DTZ10B DIODE DTZ10B		JR1620	1 216 205 01	CONDUCTOR, CH	IID	
D1104 D1105		DIODE DTZ10B		JR1621		CONDUCTOR, CH		
D1106		DIODE DTZ10B		JR1622		CONDUCTOR, CH		
D1107		DIODE DTZ10B		JR1623		CONDUCTOR, CH		
				JR1624	1-216-295-91	CONDUCTOR, CH	IIP	
D1501		DIODE RD5.6ESB2						
D1502	8-719-908-03	DIODE GP08D				CONDUCTOR, CH		
		<ferrite bead=""></ferrite>		JR1627 JR1629		CONDUCTOR, CH		
		(TERRITE BEAD)		JK1029	1-210-293-91	CONDUCTOR, CH	ш	
FB1102	1-414-135-11	FERRITE 0µH						
		·				<coil></coil>		
		<ic></ic>		L002	1-410-482-31		100μΗ	
IC001	9.752.904.06	IC CVD0505CA 000C		L003	1-410-482-31		100μΗ	
IC001 IC002		IC CXP85856A-009S IC CXP85112B-613S		L004 L005		CONDUCTOR, CH		
IC002 IC003		IC PST9143NL		L005		INDUCTOR	10μH	
IC004		IC PST9143NL		Looo	1 410 470 11	INDUCTOR	ТОДІТ	
IC007		IC X24C04S8		L007	1-410-482-31	INDUCTOR	100μΗ	
				L201	1-410-478-11		47μH	
IC201		IC MM1313AD/		L302	1-410-482-31		100μΗ	
IC301		IC CXA2025AS		L303		INDUCTOR	10μΗ	
IC401		IC BH3856FS-E2		L1101	1-410-478-11	INDUCTOR	47μΗ	
IC402		IC UPC4558G2		I 1102	1 /10 /70 11	INDLICTOR	47uH	
IC403	8-759-089-13	IC 1DA/202		L1103 L1104	1-410-478-11 1-410-478-11		47μH 47μH	
IC1101	8-759-231-53	IC TA7805S		L1104 L1105		INDUCTOR	10μH	
IC1501	8-759-192-71			L1106		INDUCTOR	47μH	
IC1502		IC CA0007AM		L1501		INDUCTOR	0μΗ	
IC1601		IC PQ09RF21					•	
IC1602	8-759-231-53	IC TA7805S		L1502	1-412-533-21		47μΗ	
		JACK.		L1503	1-412-533-21		47μH	
		<jack></jack>		L1601	1-406-975-21	INDUCTOR	0μΗ	
J203	1-507-667-00	JACK, MIC						
J205		JACK BLOCK, PIN						

REF. NO.	PART NO.	DESCRIPTION	REMARK	REF. NO.	PART NO.	DESCRIPTION			REMARK
		<ic link=""></ic>				<resistor></resistor>			
PS401	1_532_984_11	LINK, IC 2A/90V		R003	1-216-295-91	CONDUCTOR, CH	ПÞ		
15-01	1 332 704 11	Envir, 10 27 0 70 V		R004		METAL GLAZE	220	5%	1/10W
				R005		METAL GLAZE	220	5%	1/10W
		<transistor></transistor>		R006		METAL GLAZE	220	5%	1/10W
				R007	1-216-081-00	METAL GLAZE	22K	5%	1/10W
Q001		TRANSISTOR 2SD601A-Q							
Q002		TRANSISTOR DTA144EKA-T146		R008	1-216-073-00	METAL GLAZE	10K	5%	1/10W
Q003		TRANSISTOR DTA144EKA-T146		R009		METAL GLAZE	220	5%	1/10W
Q004		TRANSISTOR 2SA1162-G		R010		METAL GLAZE	220	5%	1/10W
Q005	8-729-216-22	TRANSISTOR 2SA1162-G		R011		METAL GLAZE	220	5%	1/10W
0006	9 720 027 29	TD ANGICTOD DTA 144EVA T146		R012	1-216-033-00	METAL GLAZE	220	5%	1/10W
Q006 Q007		TRANSISTOR DTA144EKA-T146 TRANSISTOR DTC144EKA-T146		R013	1 216 022 00	METAL GLAZE	220	5%	1/10W
Q007 Q008		TRANSISTOR DTC144ERA-1140		R013		METAL GLAZE	220	5%	1/10W 1/10W
Q008 Q009		TRANSISTOR 25D001A-Q TRANSISTOR DTA144EKA-T146		R015		METAL GLAZE	100	5%	1/10W 1/10W
Q013		TRANSISTOR 2SD601A-Q		R016		METAL GLAZE	100	5%	1/10W
2010	0 ,2, .22 2,	11011 (515 1010 252 00111 Q		R017		METAL GLAZE	4.7K	5%	1/10W
Q015	8-729-422-27	TRANSISTOR 2SD601A-Q							
Q016	8-729-422-27	TRANSISTOR 2SD601A-Q		R018	1-216-065-91	METAL GLAZE	4.7K	5%	1/10W
Q017		TRANSISTOR 2SD601A-Q		R019	1-216-097-91	METAL GLAZE	100K	5%	1/10W
Q201	8-729-422-27	TRANSISTOR 2SD601A-Q		R020	1-216-057-00	METAL GLAZE	2.2K	5%	1/10W
Q206	8-729-027-56	TRANSISTOR DTC143TKA-T146		R021		METAL GLAZE	47K	5%	1/10W
				R023	1-216-065-91	METAL GLAZE	4.7K	5%	1/10W
Q207		TRANSISTOR DTC144EKA-T146		D024	1 216 121 01	METAL CLASE	13.4	50/	1 /1 011
Q209		TRANSISTOR DTC143TKA-T146		R024		METAL GLAZE	1M	5%	1/10W
Q213		TRANSISTOR 2SA1162-G TRANSISTOR 2SA1162-G		R025 R026		METAL GLAZE METAL GLAZE	100K 220	5% 5%	1/10W
Q214 Q216		TRANSISTOR DTC143TKA-T146		R026 R027		METAL GLAZE	4.7K	5%	1/10W 1/10W
Q210	6-729-027-30	TRANSISTOR DTC145TRA-1140		R030		METAL GLAZE	10K	5%	1/10W 1/10W
Q217	8-729-027-56	TRANSISTOR DTC143TKA-T146		11030	1 210 075 00	WIE IT IE GET IEEE	1011	570	1/1011
Q218		TRANSISTOR 2SD601A-Q		R033	1-216-065-91	METAL GLAZE	4.7K	5%	1/10W
Q219		TRANSISTOR 2SD601A-Q		R034		METAL GLAZE	10K	5%	1/10W
Q220	8-729-422-27	TRANSISTOR 2SD601A-Q		R035		METAL GLAZE	4.7K	5%	1/10W
Q226	8-729-422-27	TRANSISTOR 2SD601A-Q		R036	1-216-033-00	METAL GLAZE	220	5%	1/10W
				R037	1-216-033-00	METAL GLAZE	220	5%	1/10W
Q301		TRANSISTOR 2SA1162-G							
Q302		TRANSISTOR 2SA1162-G		R038		METAL GLAZE	47K	5%	1/10W
Q303		TRANSISTOR 2SD601A-Q		R039		METAL GLAZE	47K	5%	1/10W
Q304		TRANSISTOR 2SD601A-Q TRANSISTOR 2SD601A-Q		R040 R041		METAL GLAZE METAL GLAZE	4.7K 100	5% 5%	1/10W
Q305	0-129-422-21	TRANSISTOR 25D00TA-Q		R042		METAL GLAZE	47K	5%	1/10W 1/10W
Q306	8-729-216-22	TRANSISTOR 2SA1162-G		1042	1-210-007-71	WILIAL GLAZE	7/IX	370	1/10 **
Q307		TRANSISTOR 2SD601A-Q		R043	1-216-065-91	METAL GLAZE	4.7K	5%	1/10W
Q308		TRANSISTOR 2SA1162-G		R045		METAL GLAZE	10K	5%	1/10W
Q311	8-729-422-27	TRANSISTOR 2SD601A-Q		R046	1-216-049-91	METAL GLAZE	1K	5%	1/10W
Q312	8-729-422-27	TRANSISTOR 2SD601A-Q		R047	1-216-057-00	METAL GLAZE	2.2K	5%	1/10W
				R048	1-216-065-91	METAL GLAZE	4.7K	5%	1/10W
Q313		TRANSISTOR 2SD601A-Q		D050	1 216 272 22	ACCURATE OF A CO	1017	<b>5</b> 6.	1 /1 0***
Q314		TRANSISTOR 2SD601A-Q		R050		METAL GLAZE	10K	5%	1/10W
Q402		TRANSISTOR DTC144EKA-T146		R053		METAL GLAZE	1K	5%	1/10W
Q403 Q405		TRANSISTOR DTA144EKA-T146 TRANSISTOR 2SA1162-G		R054 R056		METAL GLAZE METAL GLAZE	220 1M	5% 5%	1/10W 1/10W
Q+03	0-727-210-22	TRAINSISTOR 25ATT02-G		R057		METAL GLAZE	1K	5%	1/10W
Q406	8-729-216-22	TRANSISTOR 2SA1162-G		1037	1 210 019 91	WIE IT IE GET IEEE	111	570	1/1011
Q408		TRANSISTOR 2SD601A-Q		R058	1-216-049-91	METAL GLAZE	1K	5%	1/10W
Q409		TRANSISTOR 2SD601A-Q		R059		METAL GLAZE	220	5%	1/10W
Q410	8-729-422-27	TRANSISTOR 2SD601A-Q		R060	1-216-033-00	METAL GLAZE	220	5%	1/10W
Q411	8-729-027-38	TRANSISTOR DTA144EKA-T146		R061		METAL GLAZE	1K	5%	1/10W
				R063	1-216-073-00	METAL GLAZE	10K	5%	1/10W
Q1101		TRANSISTOR DTC144EKA-T146		D0 5 4	1.016.040.53	ACCURATE OF A CO	177	<b>5</b> 6.	1 /1 0***
Q1501		TRANSISTOR 2SD601A-Q		R064		METAL GLAZE	1K	5%	1/10W
Q2105		TRANSISTOR 2SD601A-Q		R065		METAL GLAZE	1K	5% 5%	1/10W
Q2106	0-129-422-21	TRANSISTOR 2SD601A-Q		R066 R067		METAL GLAZE METAL GLAZE	1K 220	5% 5%	1/10W 1/10W
				R068		METAL GLAZE	220	5%	1/10W 1/10W
				-1000	055 00			- / 3	-, - • • • •



REF. NO.	PART NO.	DESCRIPTION			REMARK	REF. NO.	PART NO.	DESCRIPTION			REMARK
R070	1-216-033-00	METAL GLAZE	220	5%	1/10W	R213	1-216-113-00	METAL GLAZE	470K	5%	1/10W
R071		METAL GLAZE	220	5%	1/10W 1/10W	R213		METAL GLAZE	470K 470K	5%	1/10W
R072		METAL GLAZE	220	5%	1/10W	R215		METAL GLAZE	470K	5%	1/10W
R073		METAL GLAZE	220	5%	1/10W					- / -	-,
R074	1-216-049-91	METAL GLAZE	1K	5%	1/10W	R216	1-216-113-00	METAL GLAZE	470K	5%	1/10W
						R217	1-216-113-00	METAL GLAZE	470K	5%	1/10W
R075	1-216-049-91	METAL GLAZE	1K	5%	1/10W	R218	1-216-022-00	METAL GLAZE	75	5%	1/10W
R076		METAL GLAZE	220	5%	1/10W	R219		METAL GLAZE	470K	5%	1/10W
R077		METAL GLAZE	1M	5%	1/10W	R220	1-216-113-00	METAL GLAZE	470K	5%	1/10W
R078		METAL GLAZE	100K	5%	1/10W	5001					4 /4 0777
R080	1-216-073-00	METAL GLAZE	10K	5%	1/10W	R221		METAL GLAZE	75 75	5%	1/10W
R081	1 216 022 00	METAL GLAZE	220	5%	1/10W	R222 R223		METAL GLAZE METAL GLAZE	75 75	5% 5%	1/10W 1/10W
R084		METAL GLAZE	10K	5%	1/10W 1/10W	R224		METAL GLAZE	47	5% 5%	1/10W 1/10W
R085		METAL GLAZE	100K	5%	1/10W 1/10W	R225		METAL GLAZE	2.2K	5%	1/10W
R086		METAL GLAZE	220	5%	1/10W	10223	1 210 037 00	WIETTE GETZE	2.21	370	1/10 **
R087		METAL GLAZE	10K	5%	1/10W	R227	1-216-019-00	METAL GLAZE	56	5%	1/10W
						R229		METAL GLAZE	1K	5%	1/10W
R088	1-216-065-91	METAL GLAZE	4.7K	5%	1/10W	R230	1-216-113-00	METAL GLAZE	470K	5%	1/10W
R090	1-216-065-91	METAL GLAZE	4.7K	5%	1/10W	R231	1-216-113-00	METAL GLAZE	470K	5%	1/10W
R091	1-216-057-00	METAL GLAZE	2.2K	5%	1/10W	R235	1-216-041-00	METAL GLAZE	470	5%	1/10W
R092		METAL GLAZE	2.2K	5%	1/10W						
R099	1-216-037-00	METAL GLAZE	330	5%	1/10W	R236		METAL GLAZE	470	5%	1/10W
						R241		METAL GLAZE	470	5%	1/10W
R111		METAL GLAZE	220	5%	1/10W	R245		METAL GLAZE	470	5%	1/10W
R112		METAL GLAZE	220	5%	1/10W	R255		METAL GLAZE	10K	5%	1/10W
R113		METAL GLAZE	220	5%	1/10W	R258	1-216-089-91	METAL GLAZE	47K	5%	1/10W
R115 R117		METAL GLAZE METAL GLAZE	220 220	5% 5%	1/10W 1/10W	R260	1-216-073-00	METAL GLAZE	10K	5%	1/10W
KIII	1-210-033-00	METAL GLAZE	220	370	1/10 **	R261		METAL GLAZE	4.7K	5%	1/10W
R118	1-216-033-00	METAL GLAZE	220	5%	1/10W	R262		METAL GLAZE	82K	5%	1/10W
R119		METAL GLAZE	220	5%	1/10W	R263		METAL GLAZE	82K	5%	1/10W
R120		METAL GLAZE	220	5%	1/10W	R264		METAL GLAZE	47K	5%	1/10W
R121	1-216-033-00	METAL GLAZE	220	5%	1/10W						
R122	1-216-033-00	METAL GLAZE	220	5%	1/10W	R265	1-216-097-91	METAL GLAZE	100K	5%	1/10W
						R266	1-216-057-00	METAL GLAZE	2.2K	5%	1/10W
R123		METAL GLAZE	220	5%	1/10W	R268		METAL GLAZE	220K	5%	1/10W
R124		METAL GLAZE	220	5%	1/10W	R275		METAL GLAZE	220	5%	1/10W
R125		METAL GLAZE	220	5%	1/10W	R276	1-216-033-00	METAL GLAZE	220	5%	1/10W
R127		METAL GLAZE METAL GLAZE	220	5%	1/10W	D277	1 216 025 01	METAL CLAZE	100	50/	1/10W/
R128	1-210-055-00	METAL GLAZE	220	5%	1/10W	R277 R278		METAL GLAZE METAL GLAZE	100 100	5% 5%	1/10W 1/10W
R131	1-216-065-91	METAL GLAZE	4.7K	5%	1/10W	R279		METAL GLAZE	100	5%	1/10W
R131		METAL GLAZE	4.7K	5%	1/10W	R280		METAL GLAZE	470	5%	1/10W
R133		METAL GLAZE	4.7K	5%	1/10W	R281		METAL GLAZE	470	5%	1/10W
R147		METAL GLAZE	2.2K	5%	1/10W						
R148	1-216-057-00	METAL GLAZE	2.2K	5%	1/10W	R282	1-216-041-00	METAL GLAZE	470	5%	1/10W
						R283		METAL GLAZE	470	5%	1/10W
R149		METAL GLAZE	2.2K	5%	1/10W	R284		METAL GLAZE	470	5%	1/10W
R154		METAL GLAZE	100	5%	1/10W	R285		METAL GLAZE	470	5%	1/10W
R155		METAL GLAZE	100	5%	1/10W	R286	1-216-025-91	METAL GLAZE	100	5%	1/10W
R156		METAL GLAZE	470K	5%	1/10W	D207	1 21 6 02 5 01	METAL CLASE	100	50/	1 /1 0337
R157	1-216-017-91	METAL GLAZE	47	5%	1/10W	R287		METAL GLAZE	100	5%	1/10W
R158	1 216 112 00	METAL CLAZE	470K	50/	1/1007	R288 R289		METAL GLAZE METAL GLAZE	100 100	5%	1/10W
R158		METAL GLAZE METAL GLAZE	470 <b>K</b> 47	5% 5%	1/10W 1/10W	R290		METAL GLAZE	100	5% 5%	1/10W 1/10W
R160		METAL GLAZE	470K	5%	1/10W	R291		METAL GLAZE	100	5%	1/10W
R161		METAL GLAZE	470K 47	5%	1/10W 1/10W	1,2/1	1 210 025-71	OLALL	100	5 /0	1/1011
R163		METAL GLAZE	220	5%	1/10W	R294	1-216-043-91	METAL GLAZE	560	5%	1/10W
						R295		METAL GLAZE	10K	5%	1/10W
R164	1-216-033-00	METAL GLAZE	220	5%	1/10W	R296		METAL GLAZE	100	5%	1/10W
R165	1-216-033-00	METAL GLAZE	220	5%	1/10W	R297		METAL GLAZE	68K	5%	1/10W
R171		METAL GLAZE	270	5%	1/10W	R299	1-216-041-00	METAL GLAZE	470	5%	1/10W
R172		METAL GLAZE	270	5%	1/10W						
R173	1-216-035-00	METAL GLAZE	270	5%	1/10W	R301		METAL GLAZE	470	5%	1/10W
D204	1 240 255 11	CADDON	0.47	501	1 /4337 17	R302		METAL GLAZE	1K	5%	1/10W
R204 R206	1-249-377-11	METAL GLAZE	0.47 75	5% 5%	1/4W F	R303		METAL GLAZE	1K	5% 5%	1/10W
K200	1-210-022-00	WIE IAL ULAZE	13	<i>J7</i> 0	1/10W	R304	1-410-049-91	METAL GLAZE	1K	5%	1/10W



REF. NO.	PART NO.	DESCRIPTION			REMARK	REF. NO.	PART NO.	DESCRIPTION			REMARK
R305	1 216 033 00	METAL GLAZE	220	5%	1/10W	R374	1 216 040 01	METAL GLAZE	1K	5%	1/10W
K303	1-210-033-00	WIETAL GLAZE	220	370	1/10 VV	R375		METAL GLAZE	470K	5%	1/10W 1/10W
R306	1-216-025-91	METAL GLAZE	100	5%	1/10W	R376		METAL GLAZE	2.2M	5%	1/10W
R307		METAL GLAZE	1K	5%	1/10W	R377		METAL GLAZE	10K	5%	1/10W
R308	1-216-017-91	METAL GLAZE	47	5%	1/10W	R378	1-216-057-00	METAL GLAZE	2.2K	5%	1/10W
R309	1-216-017-91	METAL GLAZE	47	5%	1/10W						
R310	1-216-017-91	METAL GLAZE	47	5%	1/10W	R379	1-216-073-00	METAL GLAZE	10K	5%	1/10W
						R380		METAL GLAZE	47K	5%	1/10W
R314		METAL GLAZE	220	5%	1/10W	R381		METAL GLAZE	100K	5%	1/10W
R315		METAL GLAZE	220	5%	1/10W	R384	1-249-377-11		0.47	5%	1/4W F
R319		METAL GLAZE	220	5%	1/10W	R401	1-249-377-11	CARBON	0.47	5%	1/4W F
R320		METAL GLAZE	220	5%	1/10W	D 402	1 240 277 11	CARRON	0.47	£0/	1 /4W/ E
R322	1-210-077-00	METAL GLAZE	15K	5%	1/10W	R402 R403	1-249-377-11	METAL GLAZE	0.47 10K	5% 5%	1/4W F 1/10W
R323	1 216 025 01	METAL GLAZE	100	5%	1/10W	R403 R404		METAL GLAZE	10K 1K	5% 5%	1/10W 1/10W
R324		METAL GLAZE	100	5%	1/10W	R404		METAL GLAZE	10K	5%	1/10W
R325		METAL GLAZE	100	5%	1/10W	R407		METAL GLAZE	100	5%	1/10W
R326		METAL GLAZE	1.5K		1/10W	107	1 210 025 71	WIE IT IE GET IEE	100	370	1/1011
R327		METAL GLAZE	1K	5%	1/10W	R408	1-216-025-91	METAL GLAZE	100	5%	1/10W
						R412		METAL GLAZE	100	5%	1/10W
R328	1-216-049-91	METAL GLAZE	1K	5%	1/10W	R413	1-216-025-91	METAL GLAZE	100	5%	1/10W
R330	1-216-025-91	METAL GLAZE	100	5%	1/10W	R414	1-216-049-91	METAL GLAZE	1K	5%	1/10W
R331	1-216-025-91	METAL GLAZE	100	5%	1/10W	R415	1-216-041-00	METAL GLAZE	470	5%	1/10W
R332	1-216-035-00	METAL GLAZE	270	5%	1/10W						
R333	1-208-810-11	METAL GLAZE	15K	0.50%	1/10W	R416		METAL GLAZE	470	5%	1/10W
						R418		METAL GLAZE	100	5%	1/10W
R334		METAL GLAZE	560	5%	1/10W	R422		METAL GLAZE	2.2K	5%	1/10W
R335		METAL GLAZE	220	5%	1/10W	R423		METAL GLAZE	100	5%	1/10W
R337		METAL GLAZE	220	5%	1/10W	R424	1-216-089-91	METAL GLAZE	47K	5%	1/10W
R338		METAL GLAZE	220	5%	1/10W	D 425	1 216 041 00	METAL CLAZE	470	50/	1/1007
R339	1-210-055-00	METAL GLAZE	220	5%	1/10W	R425 R427		METAL GLAZE METAL GLAZE	470 1.2K	5% 5%	1/10W 1/10W
R340	1-216-025-91	METAL GLAZE	100	5%	1/10W	R427 R428		METAL GLAZE	1.2K 1K	5%	1/10W 1/10W
R342		METAL GLAZE	100	5%	1/10W	R429		METAL GLAZE	1K	5%	1/10W
R343		METAL GLAZE	10K	5%	1/10W	R430		METAL GLAZE	1.2K	5%	1/10W
R344		METAL GLAZE	5.6K	5%	1/10W	1430	1 210 031 00	WIETTE GETZE	1.21	570	1/1011
R345		METAL GLAZE	330K	5%	1/10W	R432	1-216-081-00	METAL GLAZE	22K	5%	1/10W
						R433		METAL GLAZE	27	5%	1/10W
R346	1-216-053-00	METAL GLAZE	1.5K	5%	1/10W	R434	1-216-075-00	METAL GLAZE	12K	5%	1/10W
R347	1-216-049-91	METAL GLAZE	1K	5%	1/10W	R435	1-216-075-00	METAL GLAZE	12K	5%	1/10W
R348	1-216-133-00	METAL GLAZE	3.3M	5%	1/10W	R436	1-216-011-00	METAL GLAZE	27	5%	1/10W
R349		METAL GLAZE	1K	5%	1/10W						
R350	1-216-049-91	METAL GLAZE	1K	5%	1/10W	R437	1-249-418-11		1.2K	5%	1/4W F
2051		A COUNTY OF A COUNTY	2 277		4 /4 0777	R438	1-249-418-11		1.2K	5%	1/4W F
R351		METAL GLAZE	3.3K	5%	1/10W	R439	1-249-389-11		4.7	5%	1/4W F
R352		METAL GLAZE METAL GLAZE	2.7K	5%	1/10W	R440	1-249-389-11		4.7	5%	1/4W F
R353 R354		METAL GLAZE	2.7K 10K	5% 5%	1/10W 1/10W	R441	1-210-073-00	METAL GLAZE	10K	5%	1/10W
R355		METAL GLAZE	47K	5%	1/10W	R442	1-216-025-91	METAL GLAZE	100	5%	1/10W
10333	1 210 007 71	WIETTE GETZE	7/IX	370	1/10**	R443		CONDUCTOR, CI		570	1/1011
R356	1-216-025-91	METAL GLAZE	100	5%	1/10W	R444		CONDUCTOR, CI			
R357		METAL GLAZE	1K	5%	1/10W	R1101		METAL GLAZE	4.7K	5%	1/10W
R361		METAL GLAZE	470	5%	1/10W	R1102		METAL GLAZE	27K	5%	1/10W
R362		METAL GLAZE	1K	5%	1/10W						
R363	1-216-077-00	METAL GLAZE	15K	5%	1/10W	R1103	1-216-689-11	METAL GLAZE	39K	5%	1/10W
						R1104	1-216-049-91	METAL GLAZE	1K	5%	1/10W
R364		METAL GLAZE	1.1K	0.50%	1/10W	R1105	1-216-689-11	METAL GLAZE	39K	5%	1/10W
R365	1-216-081-00	METAL GLAZE	22K	5%	1/10W	R1106	1-216-083-00	METAL GLAZE	27K	5%	1/10W
R366		METAL GLAZE	47	5%	1/10W	R1107	1-216-065-91	METAL GLAZE	4.7K	5%	1/10W
R367		METAL GLAZE	27K	5%	1/10W					_	
R368	1-216-057-00	METAL GLAZE	2.2K	5%	1/10W	R1108		METAL OXIDE	22K	5%	2W F
D260	1 016 070 00	METALOLATE	1017	501	1/10337	R1501		METAL CHIP	1.5	5%	1W F
R369		METAL GLAZE	10K	5%	1/10W	R1502		METAL CHIP	10K		1/10W
R370		METAL GLAZE	27K	5% 5%	1/10W	R1504		METAL CHIP	10K		1/10W
R371 R372		METAL GLAZE METAL GLAZE	15K 4.7K	5% 5%	1/10W 1/10W	R1505	1-213-837-11	METAL OXIDE	10	5%	1W F
R372 R373		METAL GLAZE	4./K 18K	5% 5%	1/10W 1/10W	R1506	1-215-888-00	METAL OXIDE	220	5%	2W F
10/3	1 210 077 00		1011	570	1/10 11	R1507		METAL GLAZE	22K	5%	1/10W
							2 231 00				

The componants identified by shading and mark △ are critical for safety.
Replace only with part number specified.

• The components identified by 

in this manual have been carefully factory-selected for each set in order to satisfy regulations regarding X-ray radiation. Should replacement be required, replace only with the value originally used.



REF. NO.	PART NO.	DESCRIPTION	acca.	R	REMARK	REF. NO	О.	PART NO.	DESCRIPTION			REMARK
R1508	1-249-383-11		1.5	5%	1/4W F	C507		1-126-965-11	ELECT	22μF	20%	50V
R1509 R1510		METAL CHIP METAL CHIP	10K 10K		1/10W 1/10W	C508		1-102-212-00	CERAMIC	820PF	10%	500V
K1310	1-210-073-11	WIETAL CITI	1010	0.5070	1/10**	C509		1-106-383-00		0.047µF	10%	200V
R1511		METAL GLAZE	2.2K	5%	1/10W	C510		1-102-002-00		680PF	10%	500V
R1520		METAL GLAZE	47K	5%	1/10W	C511		1-130-475-00		0.0022μF		50V
R1522 R1523		METAL GLAZE METAL GLAZE	47K 10K	5% 5%	1/10W 1/10W	C512		1-136-479-11	FILM	0.001µF	5%	50V
R1523		METAL GLAZE	10K 100K	5%	1/10W 1/10W	C513		1-126-965-11	ELECT	22μF	20%	50V
101021	1 210 0), )1		10011	270	1,10	C514	$\triangle$		CERAMIC		20,0	2KV
R1525		METAL CHIP	30K		1/10W	C515	$\triangle$	1-125-831-91		$0.033 \mu F$	3%	630V
R1526		METAL CHIP	30K		1/10W		$\triangle$	1-117-807-11			3%	1.6KV
R1527		METAL GLAZE	100K	5%	1/10W	C518		1-130-495-00	MYLAR	0.1μF	5%	50V
R1528 R1529		METAL GLAZE METAL GLAZE	47K 100	5% 5%	1/10W 1/10W	C519		1-136-287-11	FII M	0.0047µF	5%	100V
1(132)	1 210 023 71	WIET/IE GE/WEE	100	570	1/10 **	C520		1-162-116-00		680PF	10%	2KV
R2106	1-216-025-91	METAL GLAZE	100	5%	1/10W	C521		1-162-116-00		680PF	10%	2KV
R2109	1-216-041-00	METAL GLAZE	470	5%	1/10W	C523		1-117-673-11	FILM	1.5µF	5%	200V
R2110		METAL GLAZE	10K	5%	1/10W	C524		1-136-287-11	FILM	$0.0047 \mu F$	5%	100V
R2111		METAL GLAZE	47K	5%	1/10W	GF2.		1 102 220 00	CED LA MC	450DE	100/	50011
R2112	1-216-065-91	METAL GLAZE	4.7K	5%	1/10W	C526 C527		1-102-228-00 1-104-664-11		470PF 47μF	10% 20%	500V 25V
R2201	1-216-041-00	METAL GLAZE	470	5%	1/10W	C528		1-104-604-11		2.2μF	20%	250V
R2202		METAL GLAZE	470	5%	1/10W	C529		1-109-961-11		0.75μF	5%	200V
R2203	1-216-025-91	METAL GLAZE	100	5%	1/10W	C530		1-110-626-11		330µF	20%	160V
R2204	1-216-045-00	METAL GLAZE	680	5%	1/10W					•		
R2205	1-216-041-00	METAL GLAZE	470	5%	1/10W	C531		1-126-971-11		470μF	20%	50V
D.2200			450		4 /4 0777	C532		1-126-971-11		470μF	20%	50V
R2208		METAL GLAZE	470	5%	1/10W	C533 C535		1-128-562-11		47μF	20%	100V
R2209	1-216-041-00	METAL GLAZE	470	5%	1/10W	C535 C536		1-106-387-00 1-130-489-00		0.068μF 0.033μF	5% 5%	200V 50V
		<thermistor></thermistor>				C330		1 150 407 00	WII LI W	0.033μ1	370	30 1
						C537		1-104-665-11	ELECT	100μF	20%	25V
TH1501	1-800-193-00	THERMISTOR				C538		1-104-665-11		100μF	20%	25V
						C539		1-162-114-00		$0.0047\mu F$		2KV
		TUNED.				C540		1-130-487-00		0.022μF	5%	50V
		<tuner></tuner>				C541		1-130-489-00	MYLAR	0.033µF	5%	50V
TU1101	8-598-340-00	TUNER, FSS BTF-	WA404			C542		1-104-666-11	ELECT	220µF	20%	25V
TU1102		TUNER, FSS BTF-				C544		1-104-665-11		100μF	20%	25V
						C545		1-104-665-11		100μF	20%	25V
		CDI ICELI				C546		1-107-637-11		22μF	20%	160V
		<crystal></crystal>				C548		1-102-244-00	CERAMIC	220PF	10%	500V
X001	1-577-358-21	VIBRATOR, CERA	AMIC			C550		1-126-935-11	ELECT	470μF	20%	16V
X002		VIBRATOR, CRYS				C551		1-126-935-11		470μF	20%	16V
X301	1-567-505-11	OSCILLATOR, CR	YSTAL			C554		1-129-702-00	FILM	0.001µF	5%	630V
X304	1-577-611-11	OSCILALTOR, CE	RAMIC			C555		1-126-960-11		1μF	20%	50V
						C556		1-130-495-00	MYLAR	0.1μF	5%	50V
******	******	******	******	*****	*****	C602	$\Lambda$	1-113-920-11	CERAMIC	0.0022µF	20%	250V
						C603		1-104-330-91		470PF	10%	1KV
:	* A-1316-367-A	G BOARD, COMP	LETE				$\triangle$	1-136-311-11		0.47µF	20%	125V
		******	****			C605		1-113-920-11		$0.0022 \mu F$	20%	250V
	* 4.057.025.01	DI ATTE TED ANGEG	DI CED CIT	EL D		C606	$\triangle$	1-136-311-11	FILM	0.47μF	20%	125V
		PLATE, TRANSFO SCREW (M3X10),		IELD		C607		1 125 602 11	ELECT/DLOCK)	920uE	200/	2001/
		SCREW (M3X10), SCREW (M3X8), F				C607 C608			ELECT(BLOCK) ELECT(BLOCK)	820μF 820μF	20% 20%	200V 200V
		SCREW +PSW 3X				C612		1-164-646-11		2200PF	10%	500V
						C615		1-136-173-00		0.47μF	5%	50V
						C616		1-136-173-00	FILM	0.47μF	5%	50V
		<capacitor></capacitor>				0215		1 100 100 00	EH M	0.00 5	<b>5</b> 0/	5017
C502	1 126 050 11	ELECT	0.47	200/	50V	C617		1-136-169-00		0.22μF	5% 5%	50V
C502 C504	1-126-959-11 1-102-116-00		0.47μF 680PF	20% 10%	50V 50V	C618 C621		1-136-169-00 1-129-719-00		0.22μF 0.027μF	5% 5%	50V 630V
C505	1-130-471-00		0.001µF	5%	50V	C651		1-107-910-11		0.027μ1 100μF	20%	35V
C506	1-126-933-11		100μF	20%	16V	C652		1-123-024-21		33μF		160V



REF. NO.	PART NO.	DESCRIPTION			REMARK	REF. NO.	PART NO.	DESCRIPTION			REMARK
C653	1-115-755-11	ELECT	180µF	20%	16V	C839	1-137-374-11	FILM	0.047µF	5%	50V
C654	1-115-755-11	ELECT	180μF	20%	16V	C840	1-104-665-11	ELECT	100μF	20%	25V
C655	1-126-943-11	ELECT	2200µF	20%	25V	C841	1-137-374-11	FILM	$0.047 \mu F$	5%	50V
C656	1-126-943-11		2200μF	20%	25V						
C657	1-126-943-11	ELECT	2200μF	20%	25V	C842	1-137-374-11		$0.047\mu F$	5%	50V
9.550		DI DOD	2200 -	2001	5077	C843	1-104-665-11		100μF	20%	25V
C658	1-128-550-11		2200μF	20%	50V	C844	1-126-933-11		100μF	20%	16V
C659	1-102-074-00		0.001µF	10%	50V	C845	1-126-933-11		100μF	20%	16V
C660	1-126-235-11		100μF	20%	6.3V	C846	1-126-933-11	ELECT	100μF	20%	16V
C661	1-102-074-00 1-104-664-11		0.001µF	10% 20%	50V 25V	C847	1 126 022 11	ELECT	100uE	20%	16V
C662	1-104-004-11	ELECT	47μF	20%	23 V	C848	1-126-933-11 1-126-933-11		100μF 100μF	20%	16V 16V
C663	1-104-664-11	FLECT	47μF	20%	25V	C851	1-120-933-11		0.047μF	5%	50V
C664	1-107-888-11		47μF	20%	25V	C852	1-137-374-11		0.047μF	5%	50V
C665	1-104-666-11		220μF	20%	25V	C853	1-137-374-11		0.047μF	5%	50V
C666	1-126-960-11		1µF	20%	50V	0000	1 10, 0, 11	1 121/1	0.0.7, pc2	0,0	50,
C667	1-104-664-11		47μF	20%	25V	C854	1-126-933-11	ELECT	100µF	20%	16V
						C857	1-126-933-11		100μF	20%	16V
C668	1-126-933-11	ELECT	100μF	20%	16V	C858	1-126-941-11	ELECT	470μF	20%	25V
C671	1-104-664-11	ELECT	47μF	20%	25V	C860	1-126-933-11	ELECT	100μF	20%	16V
C672	1-126-971-11	ELECT	470μF	20%	50V	C861	1-137-374-11	FILM	0.047μF	5%	50V
C673	1-162-115-00	CERAMIC	330PF	10%	1KV				,		
C675	1-104-665-11	ELECT	100μF	20%	25V	C862	1-137-374-11	FILM	$0.047 \mu F$	5%	50V
						C863	1-137-374-11	FILM	$0.047\mu F$	5%	50V
C676	1-126-960-11	ELECT	1μF	20%	50V	C864	1-126-933-11	ELECT	100μF	20%	16V
C801	1-104-665-11	ELECT	100μF	20%	25V	C865	1-130-471-00	MYLAR	$0.001 \mu F$	5%	50V
C802	1-104-665-11	ELECT	100μF	20%	25V	C866	1-136-177-00	FILM	1μF	5%	50V
C803	1-126-934-11	ELECT	220μF	20%	16V						
C804	1-126-934-11	ELECT	220μF	20%	16V	C867	1-101-880-00		47PF	5%	50V
						C868	1-101-880-00		47PF	5%	50V
C805	1-126-934-11		220μF	20%	16V	C869	1-130-487-00		0.022μF	5%	50V
C806	1-126-934-11		220μF	20%	16V	C871	1-101-880-00		47PF	5%	50V
C807	1-137-374-11		0.047μF	5%	50V	C872	1-101-880-00	CERAMIC	47PF	5%	50V
C808	1-137-374-11		0.047μF	5%	50V	6072	1 101 000 00	CED ANG	45DE	50/	5011
C809	1-137-374-11	FILM	0.047μF	5%	50V	C873	1-101-880-00		47PF	5%	50V
C010	1 127 274 11	EII M	0.047E	F0/	5037	C880	1-126-961-11		2.2μF	20%	50V
C810 C811	1-137-374-11 1-137-366-11		0.047μF 0.0022μF	5% 5%	50V 50V	C881 C882	1-102-973-00 1-102-973-00		100PF 100PF	5% 5%	50V 50V
C811	1-137-300-11			5%	50V 50V	C883	1-102-973-00		100PF 100PF	5%	50V 50V
C812	1-130-109-00		0.22μF 0.047μF	5%	50V	C003	1-102-973-00	CERAMIC	100FF	370	30 V
C815	1-137-374-11		470μF	20%	25V	C885	1-126-961-11	FLECT	2.2µF	20%	50V
C015	1 120 741 11	LLLCI	470μ1	2070	23 1	C886	1-102-973-00		100PF	5%	50V
C816	1-126-964-11	ELECT	10μF	20%	50V	C887	1-102-973-00		100PF	5%	50V
C817	1-164-096-11		0.01µF	2070	50V	C888	1-102-973-00		100PF	5%	50V
C818	1-126-933-11		100μF	20%	16V	C889	1-126-941-11		470μF	20%	25V
C819	1-126-964-11		10μF	20%	50V						
C820	1-102-114-00		470PF	10%	50V	C897	1-126-941-11	ELECT	470μF	20%	25V
									•		
C821	1-130-495-00		$0.1 \mu F$	5%	50V						
C822	1-164-096-11		$0.01 \mu F$		50V			<connector></connector>			
C823	1-101-880-00	CERAMIC	47PF	5%	50V						
C825	1-104-665-11		100μF	20%	25V	CN501		PLUG, CONNECT			
C826	1-136-165-00	FILM	0.1μF	5%	50V			PIN, CONNECTOR		,	
G025	1 10 5 0 50 11	DI DOM	4.5	2001	5077			PIN, CONNECTOR	*		
C827	1-126-960-11		1μF	20%	50V			PIN, CONNECTOR		RD) 4F	•
C828	1-137-366-11		0.0022μF	5%	50V	CN505 *	1-506-371-00	PIN, CONNECTOR	R 2P		
C829	1-126-959-11		0.47μF	20%	50V	CNIFOC N	1 554 100 11	CONNECTOR DO	4 D.D. (TO. D.	0.400	100
C830	1-136-356-11		470PF	5%	50V			CONNECTOR, BO		OAKL	101
C831	1-126-960-11	ELECT	1μF	20%	50V			PLUG, CONNECTOR		`	
C832	1 126 060 11	ELECT	1uF	200/	50V			PIN, CONNECTOR BO			10D
	1-126-960-11		1μF	20%	50V 50V			CONNECTOR BO			
C833 C834	1-126-960-11 1-104-665-11		1μF 100μF	20% 20%	25V	CN032 *	1-//4-182-11	CONNECTOR, BO	AKD IOB	UAKL	100
C834 C835			•		25 V 25 V	CN652 *	1 573 062 11	DIN CONNECTOR	DC DO A	DD/ 3L	•
C835 C836	1-104-664-11 1-136-169-00		47μF 0.22μF	20% 5%	25 V 50 V			PIN, CONNECTOR PLUG, CONNECT		ND) 3F	
C030	1-130-109-00	1 11-111	0.22μΓ	J /0	JU V			PLUG, CONNECT			
C837	1-126-963-11	ELECT	4.7μF	20%	50V			PLUG, CONNECT			
C838	1-126-965-11		4.7μ1 100μF	20%	25V			CONNECTOR, BO		OARE	10P
2000	- 10.005 11		- ooper	_5/0	1	01.001	_ ,, . 102 11	_ J J , DO	IOD	J. 111L	

The componants identified by shading and mark △ are critical for safety.
Replace only with part number specified.



REF. NO.	PART NO.	DESCRIPTION	REMARK	REF. NO	PART NO	DESCRIPTION		REMARK
CN805 *	1-691-134-11	PIN, CONNECTOR (PC BOARD) 21	2	D847 D848 D849	8-719-923	-19 DIODE MTZJ- -86 DIODE MTZJ- -22 DIODE RD11E	-T-77-15	
		<diode></diode>		D850		-89 DIODE RD5.6		
				D852		-86 DIODE MTZJ-		
D501		DIODE 1SS133T-77		D853		-19 DIODE MTZJ-		
D502		DIODE 1SS133T-77		D854		-19 DIODE MTZJ-		
D503		DIODE RGP02-20EL-6394		D855	8-719-982	-19 DIODE MTZJ-	-30A	
D504		DIODE MTZJ-7.5B DIODE EL1Z		D056	1 164 006	11 CEDAMIC	0.01E	5011
D507	8-719-302-43	DIODE ELIZ		D856		-11 CERAMIC	0.01µF	50V
D508	8 710 000 26	DIODE ERD29-08J		D857 D859		<ul><li>-19 DIODE MTZJ-</li><li>-11 CERAMIC</li></ul>	0.01µF	50V
D508		DIODE ERC06-15S		D859		-11 CERAMIC -19 DIODE MTZJ-		30 V
D510		DIODE ERC06-15S		D000	0-717-702	-1) DIODE WITZ	-30A	
D510		DIODE EL1Z						
D513		DIODE EL1Z				<fuse></fuse>		
D514	8-719-908-03	DIODE GP08D		F601	<b>△</b> 1-532-748	3-11 FUSE, GLASS	S TUBE 6.3A/125V	V
D515	8-719-908-03	DIODE GP08D			1-533-223	-11 CLIP, FUSE		
D517		DIODE RGP02-20EL-6394						
D519		DIODE ISS133T-77						
D520	8-719-302-43	DIODE EL1Z				<ferrite be<="" td=""><td>AD&gt;</td><td></td></ferrite>	AD>	
D521	8-719-302-43	DIODE EL1Z						
D524	8-719-991-33	DIODE 1SS133T-77		FB501	1-410-397	-21 FERRITE	1.1μΗ	
D527		DIODE RD5.1ESB2		FB651		-41 FERRITE	0.45μΗ	
D528		DIODE MTZJ-T-77-15		FB652		-41 FERRITE	0.45μΗ	
D602 △	8-719-052-84	DIODE LN4SB60		FB653		-41 FERRITE	0.45μΗ	
D 651	0.710.510.06	DIODE DANK 20 TA		FB654	1-410-397	-21 FERRITE	1.1μH	
D651		DIODE D1NL20-TA		ED 455	1 110 200	44 EEDDIWE	0.45 11	
D652		DIODE 1SS133T-77		FB655		-41 FERRITE	0.45μH	
D653		DIODE DASA		FB656		-41 FERRITE	0.45μH	
D654 D655		DIODE D2S4μF DIODE RBA-402LLF-A		FB657 FB660		-41 FERRITE -11 FERRITE	0.45µH 0µH	
D033	6-719-001-30	DIODE KBA-402LLF-A		FB661		-11 FERRITE	ошн ОшН	
D656	8-719-052-92	DIODE D10SBS4F						
D657	8-719-052-91	DIODE D4SBS4-F						
D658		DIODE D10SC4M				<ic></ic>		
D660		DIODE 1SS133T-77						
D661	8-719-200-82	DIODE 11ES2		IC501		-90 IC UPC339C		
D	0.710.001.00	DV0DD 4664000 55				-12 TRANSISTOR		
D662		DIODE 1SS133T-77				-11 POWER MOD	OULE DM-48	
D664		DIODE 1SS133T 77		IC651		-13 IC DM-58 -67 IC MC7905CT	ı	
D669 D670		DIODE 1SS133T-77 DIODE MTZJ-13		IC652	0-739-012	-07 IC MIC/905C1		
D670 D691		DIODE M1ZJ-13 DIODE 11ES2		IC653	8 750 231	-53 IC TA7805S		
20/1	5 /17-200-02	DIODE IIEOZ		IC654		-53 IC TA7805S		
D692	8-719-200-82	DIODE 11ES2		IC655		-58 IC TA7812S		
D693		DIODE 11ES2		IC801		-51 IC PA0053B		
D694		DIODE 11ES2		IC802		-51 IC PA0053B		
D801		DIODE RD10ESB2						
D802		DIODE RD10ESB2		IC803	8-759-183	-37 IC CA0007AD		
				IC804	8-759-464	-79 IC PM0011AS		
D803	8-719-110-17	DIODE RD10ESB2		IC805	8-759-711	-28 IC NJM2058D		
D804	8-719-110-17	DIODE RD10ESB2		IC806	8-759-464	-79 IC PM0011AS		
D809		DIODE 1SS133T-77		IC808	8-759-464	-79 IC PM0011AS		
D810		DIODE 1SS133T-77						
D820	8-719-109-68	DIODE RD3.6ESB1		IC809		-37 IC STK392-150		
				IC810		-37 IC STK392-150	0	
D828		DIODE RD5.6ESB2		IC811	8-759-634	-51 IC M5218AP		
D829		DIODE RD5.1ESB2						
D835		DIODE RD5.6ESB2						
D840		DIODE 1SS133T-77				<coil></coil>		
D842	8-719-991-33	DIODE 1SS133T-77		1.500	1 410 470	11 INDLICTOR	47	
D045	9 710 001 22	DIODE 1001227.77		L502		-11 INDUCTOR	47μH	
D845 D846		DIODE 1SS133T-77 DIODE 1SS133T-77		L503		-00 INDUCTOR	0μH 2 2μμΗ	
D040	0-117-771-33	DIODE 1991991-//	I	L506	1-412-332	-11 INDUCTOR	2.2μμΗ	



The components identified by 

in this manual have been carefully factory-selected for each set in order to satisfy regulations regarding X-ray radiation. Should replacement be required, replace only with the value originally used.

The componants identified by shading and mark △ are critical for safety.
Replace only with part number specified.

				ori	iginally	y used.							
	REF. NO.	PART NO.	DESCRIPTION			REMARK	REF. N	0.	PART NO.	DESCRIPTION			REMARK
ì	L509 L601 🛆	1-412-533-21 1-424-248-11	INDUCTOR TRANSFORMER,	47μH LINE FILT	ΓER		R513		1-249-424-11	CARBON METAL	3.9K	5%	1/4W 1/4W
			·				R516		1-215-443-00		8.2K	1%	1/4W
	L651	1-414-158-11		2.2μΗ			D.51.5		1 215 440 00	METAL	1517	10/	1 / 4337
	L652 L653	1-414-158-11 1-414-158-11		2.2μH 2.2μH			R517 R518		1-215-449-00 1-215-456-00		15K 30K	1% 1%	1/4W 1/4W
	L654	1-414-158-11		2.2μΗ			R518		1-247-863-91		22K	5%	1/4 W 1/4W
	L656	1-412-523-11		6.8µH			R522		1-249-428-11		8.2K	5%	1/4W
				•			R523		1-249-437-11		47K	5%	1/4W
	L801	1-406-975-21		0μΗ									
	L802	1-406-975-21	INDUCTOR	0μΗ			R524		1-247-863-91		22K	5%	1/4W
							R525 R528		1-249-405-11	METAL OXIDE	100 68	5% 5%	1/4W F 3W F
			<ic link=""></ic>				R530		1-249-437-11		47K	5%	1/4W
			211 (12)				R531			METAL OXIDE	680	5%	1W F
		1-533-597-31											
	PS602 △	1-533-597-31	LINK, IC				R532		1-260-314-11		68	5%	1/2W
							R533 R534		1-214-912-00		91K 270K	1% 1%	1/2W 1/4W
			<transistor></transistor>				R535		1-215-479-00 1-247-887-00		270K 220K	5%	1/4 W 1/4W
			1101110101010				R536		1-260-288-11		0.47	5%	1/2W
	Q501	8-729-119-80	TRANSISTOR 2SC	2688-LK									
	Q502		TRANSISTOR 2SD		ONY-1)	)	R537		1-260-336-11		4.7K	5%	1/2W
	Q503		TRANSISTOR 2SA				R538		1-247-863-91		22K	5%	1/4W
	Q504 Q505		TRANSISTOR 2SC TRANSISTOR IRF		3 /		R539 R540		1-249-377-11 1-249-379-11		0.47 0.68	5% 5%	1/4W F 1/4W F
	Q303	0-729-931-43	TRANSISTOR IKI	014			R540		1-249-379-11		100	5%	1/4W F 1/2W
	Q506	8-729-119-78	TRANSISTOR 2SC	2785-HFE			10311		1 200 007 11	Crindon	100	570	1/2 **
	Q507	8-729-032-61	TRANSISTOR 2SC	25022-02			R542		1-215-862-11	METAL OXIDE	68	5%	1W F
	Q651		TRANSISTOR 2SA				R543			METAL OXIDE	1	5%	1W F
	Q652		TRANSISTOR 2SC				R544			METAL OXIDE	68	5%	1W F
	Q653	8-729-119-78	TRANSISTOR 2SC	2/85-HFE			R545 R546		1-249-377-11 1-249-377-11		0.47 0.47	5% 5%	1/4W F 1/4W F
	Q654	8-729-119-76	TRANSISTOR 2SA	1175-HFE			K340		1-249-377-11	CARDON	0.47	370	1/ <b>4 VV</b> 1
	Q655	8-729-119-76	TRANSISTOR 2SA	1175-HFE			R547		1-247-807-31	CARBON	100	5%	1/4W
	Q656		TRANSISTOR 2SC				R548		1-249-413-11		470	5%	1/4W
	Q657		TRANSISTOR 2SA				R549		1-247-863-91		22K	5%	1/4W
	Q658	8-729-119-78	TRANSISTOR 2SC	2/85-HFE			R550 R551		1-247-807-31 1-249-437-11		100 47K	5% 5%	1/4W 1/4W
	Q659	8-729-119-76	TRANSISTOR 2SA	1175-HFE			KJJI		1-249-437-11	CARBON	4/K	370	1/4 VV
	Q660		TRANSISTOR 2SC				R552		1-247-807-31	CARBON	100	5%	1/4W
	Q661		TRANSISTOR 2SC				R553		1-247-881-00	CARBON	120K	5%	1/4W
	Q662		TRANSISTOR 2SC				R554		1-249-405-11		100	5%	1/4W F
	Q802	8-729-119-76	TRANSISTOR 2SA	11175-HFE			R556		1-260-117-11		33K	5%	1/2W
	O803	8-729-119-76	TRANSISTOR 2SA	1175-HFE			R557		1-210-490-11	METAL OXIDE	39K	5%	3W F
	Q804		TRANSISTOR 2SC				R558		1-216-490-11	METAL OXIDE	39K	5%	3W F
	Q805	8-729-119-78	TRANSISTOR 2SC	2785-HFE			R559		1-216-490-11	METAL OXIDE	39K	5%	3W F
	Q809		TRANSISTOR 2SC				R560		1-215-399-00		120	1%	1/4W
	Q810	8-729-119-78	TRANSISTOR 2SC	2/85-HFE			₹R561 R563	$\triangle$	1-249-429-11	METAL	10K	5%	1/4W 1/4W
							K303		1-249-429-11	CARDON	101	370	1/ <b>4 VV</b>
			<resistor></resistor>				R564		1-260-131-11	CARBON	470K	5%	1/2W
							R565		1-260-087-11		100	5%	1/2W
	R501	1-249-421-11		2.2K	5%	1/4W	R566		1-249-377-11		0.47	5%	1/4W F
	R502 R503	1-215-879-11	METAL OXIDE	47K 3.3K	5% 5%	1W F 1/4W	R567 R568		1-249-377-11 1-247-903-00		0.47 1M	5% 5%	1/4W F 1/4W
	R503	1-249-419-11		1.5K	5%	1/4W	K308		1-247-903-00	CARDON	1171	370	1/ <b>4 VV</b>
	R505	1-247-895-91		470K	5%	1/4W	R569		1-216-392-11	METAL OXIDE	1.8	5%	3W F
							R570		1-215-910-00	METAL OXIDE	68	5%	3W F
	R506	1-249-429-11		10K	5%	1/4W	R571		1-249-422-11		2.7K	5%	1/4W
	R507	1-249-422-11		2.7K	5% 5%	1/4W	R572		1-247-895-91		470K	5%	1/4W
	R508 R509	1-260-337-11 1-249-437-11		5.6K 47K	5% 5%	1/2W 1/4W	R573		1-249-430-11	CAKBUN	12K	5%	1/4W
	R509 R510		METAL OXIDE	2.2K	5% 5%	3W F	R574		1-249-429-11	CARBON	10K	5%	1/4W
		11			- /0		R577		1-249-422-11		2.7K	5%	1/4W
	R511		METAL OXIDE	2.2K	5%	3W F	R579		1-247-895-91		470K	5%	1/4W
	R512	1-216-482-11	METAL OXIDE	1.8K	5%	3W F							

The componants identified by shading and mark △ are critical for safety.
Replace only with part number specified.



REF. NO.	PART NO.	DESCRIPTION			REMARK	REF. NO.	PART NO.	DESCRIPTION			REMARK
R580	1-247-863-91	CAPRON	22K	5%	1/4W	R806	1-249-429-11	CAPRON	10K	5%	1/4W
R581	1-249-428-11		8.2K	5%	1/4W	R807	1-247-807-31		100	5%	1/4W
K361	1-249-420-11	CARDON	0.2K	370	1/4 **	R808	1-249-429-11		10K	5%	1/4W
R583	1-249-428-11	CAPRON	8.2K	5%	1/4W	R809	1-249-425-11		4.7K	5%	1/4W
R584	1-247-887-00		220K	5%	1/4W	R810	1-249-423-11		4.7K 100	5%	1/4W
R585		METAL OXIDE	39K	5%	3W F	Kolu	1-247-007-31	CARBON	100	370	1/4 vv
R586					1/2W	D011	1 247 907 21	CADDON	100	50/	1/4W
	1-260-292-11		1	5%		R811	1-247-807-31		100	5%	
R588	1-247-863-91	CARBON	22K	5%	1/4W	R812	1-249-429-11		10K	5%	1/4W
D.500	1 247 007 00	CARRON	22017	50/	1 / 4337	R813	1-249-429-11		10K	5%	1/4W
R589	1-247-887-00		220K	5%	1/4W	R814	1-247-807-31		100	5%	1/4W
R591		METAL OXIDE	1K	5%	3W F	R815	1-247-807-31	CARBON	100	5%	1/4W
	1-219-512-11		2.2M	5%	1/2W	2016	4 2 4 7 00 7 24	GIRRON	100	<b>-</b> 0.	4 / 4 * * *
		CEMENTED	0.82	5%	20W	R816	1-247-807-31		100	5%	1/4W
R608 △	1-202-933-61	FUSIBLE	0.1	10%	1/2W F	R817	1-247-807-31		100	5%	1/4W
						R818	1-249-430-11		12K	5%	1/4W
R609	1-247-887-00		220K	5%	1/4W	R820	1-249-429-11		10K	5%	1/4W
R610	1-247-887-00		220K	5%	1/4W	R821	1-249-428-11	CARBON	8.2K	5%	1/4W
R611		METAL OXIDE	2.2	5%	1W F						
R612	1-247-887-00	CARBON	220K	5%	1/4W	R822	1-249-417-11	CARBON	1K	5%	1/4W
R613	1-216-353-00	METAL OXIDE	2.2	5%	1W F	R823	1-249-417-11	CARBON	1K	5%	1/4W
						R824	1-215-462-00	METAL	51K	1%	1/4W
R614	1-247-887-00	CARBON	220K	5%	1/4W	R825	1-249-441-11	CARBON	100K	5%	1/4W
R651	1-249-429-11	CARBON	10K	5%	1/4W	R826	1-215-462-00	METAL	51K	1%	1/4W
R653	1-249-377-11	CARBON	0.47	5%	1/4W F						
R655	1-247-887-00	CARBON	220K	5%	1/4W	R827	1-249-417-11	CARBON	1K	5%	1/4W
R656	1-260-288-11	CARBON	0.47	5%	1/2W	R828	1-249-426-11	CARBON	5.6K	5%	1/4W
						R829	1-249-426-11	CARBON	5.6K	5%	1/4W
R657	1-249-429-11	CARBON	10K	5%	1/4W	R830	1-249-414-11	CARBON	560	5%	1/4W
R658	1-249-417-11	CARBON	1K	5%	1/4W	R831	1-249-414-11	CARBON	560	5%	1/4W
R660	1-249-413-11	CARBON	470	5%	1/4W						
R661	1-249-417-11	CARBON	1K	5%	1/4W F	R832	1-249-441-11	CARBON	100K	5%	1/4W
R662	1-249-425-11	CARBON	4.7K	5%	1/4W	R833	1-249-417-11	CARBON	1K	5%	1/4W
						R834	1-249-441-11	CARBON	100K	5%	1/4W
R664	1-249-425-11	CARBON	4.7K	5%	1/4W	R835	1-249-441-11	CARBON	100K	5%	1/4W
R665	1-247-807-31		100	5%	1/4W	R836	1-247-807-31		100	5%	1/4W
R667	1-249-417-11		1K	5%	1/4W						
R668	1-249-377-11		0.47	5%	1/4W F	R837	1-249-441-11	CARBON	100K	5%	1/4W
R669	1-249-429-11		10K	5%	1/4W	R838	1-249-421-11		2.2K	5%	1/4W
1100)	1 2 17 127 11	CHEST	1011	270	1,	R841	1-247-815-91		220	5%	1/4W
R672	1-249-421-11	CARBON	2.2K	5%	1/4W	R842	1-247-807-31		100	5%	1/4W
R673	1-249-413-11		470	5%	1/4W	R843	1-247-807-31		100	5%	1/4W
R675	1-215-417-00		680	1%	1/4W	1043	1 247 007 31	CHROON	100	570	1/4**
R676		METAL OXIDE	1	5%	2W F	R844	1-247-807-31	CARRON	100	5%	1/4W
R677	1-247-807-31		100	5%	1/4W	R845	1-249-441-11		100K	5%	1/4W
KO77	1-247-007-31	CARDON	100	570	1/4**	R846	1-247-807-31		1001	5%	1/4W
D670	1-249-421-11	CAPRON	2 2K	50%	1/4W	R847	1-247-607-31		100K	1%	1/4W
R679 R680	1-249-421-11		2.2K 1K	5% 5%	1/4W 1/4W	R847 R850	1-215-469-00		100K 100K	1% 1%	1/4W 1/4W
R681	1-249-417-11		1K 1K		<b>I</b>	Noou	1-213-409-00	METAL	100K	1 7/0	1/4 VV
R682				5% 5%	1/4W	R851	1-247-807-31	CARRON	100	5%	1/4W
	1-249-417-11		1K	5% 5%	1/4W						
R683	1-249-417-11	CARDUN	1K	5%	1/4W	R852 R853	1-247-807-31		100 220K	5% 5%	1/4W 1/4W
D.CO.4	1 240 417 11	CARRON	177	50/	1 /4337		1-247-887-00				
R684	1-249-417-11		1K	5%	1/4W	R854	1-249-429-11		10K	5%	1/4W
R686	1-215-421-00		1K	1%	1/4W	R855	1-247-815-91	CARBON	220	5%	1/4W
R687	1-215-441-00		6.8K	1%	1/4W	2056	4 2 4 5 00 5 24	GIRRON	100	<b>-</b> 0.	4 / 4 * * *
R688	1-215-481-00		330K	1%	1/4W	R856	1-247-807-31		100	5%	1/4W
R689	1-249-425-11	CARBON	4.7K	5%	1/4W	R857	1-247-807-31		100	5%	1/4W
D 505	4.040.11=11	G. PROIT	4.77		4 / 477	R858	1-215-455-00		27K	1%	1/4W
R690	1-249-417-11		1K	5%	1/4W	R859	1-215-455-00		27K	1%	1/4W
R692	1-249-425-11		4.7K	5%	1/4W	R860	1-215-455-00	METAL	27K	1%	1/4W
R693	1-249-429-11		10K	5%	1/4W						
R695	1-247-807-31		100	5%	1/4W	R861	1-215-455-00		27K	1%	1/4W
R696	1-249-417-11	CARBON	1K	5%	1/4W	R862	1-215-455-00		27K	1%	1/4W
						R863	1-215-455-00		27K	1%	1/4W
R697	1-249-417-11		1K	5%	1/4W	R865	1-249-424-11		3.9K	5%	1/4W
R801	1-249-437-11	CARBON	47K	5%	1/4W	R867	1-215-461-00	METAL	47K	1%	1/4W
R803	1-249-430-11	CARBON	12K	5%	1/4W						
R804	1-249-429-11	CARBON	10K	5%	1/4W	R868	1-215-445-00	METAL	10K	1%	1/4W
R805	1-247-807-31	CARBON	100	5%	1/4W	R869	1-247-863-11	CARBON	22K	5%	1/4W



REF. NO	PART NO.	DESCRIPTION			REMARK	REF. NO.	PART NO.	DESCRIPTION			REMARK
R871	1-249-417-11		1K	5%	1/4W	R935	1-249-429-11	CARBON	10K	5%	1/4W
R872	1-247-863-11		22K	5%	1/4W						
R873	1-247-807-31	CARBON	100	5%	1/4W	R936	1-249-429-11		10K	5%	1/4W
D074	1 240 420 11	CARRON	1017	<b>50</b> /	1 /4337	R937	1-249-435-11		33K	5%	1/4W
R874	1-249-429-11		10K	5%	1/4W	R938	1-215-421-00		1K	1%	1/4W
R875	1-249-441-11		100K	5%	1/4W	R940	1-249-441-11		100K	5%	1/4W
R876	1-215-451-00		18K	1%	1/4W	R941	1-249-441-11	CARBON	100K	5%	1/4W
R879	1-215-444-00		9.1K	1%	1/4W	Do 42	1 2 10 121 11	GIRRON			4 / 4***
R881	1-249-408-11	CARBON	180	5%	1/4W	R942	1-249-421-11		2.2K	5%	1/4W
						R943	1-249-441-11		100K	5%	1/4W
R882	1-215-445-00		10K	1%	1/4W	R944	1-215-421-00		1K	1%	1/4W
R883	1-215-445-00		10K	1%	1/4W	R945	1-249-429-11		10K	5%	1/4W
R884	1-215-445-00		10K	1%	1/4W	R946	1-215-421-00	METAL	1K	1%	1/4W
R885	1-249-441-11		100K	5%	1/4W						
R886	1-249-428-11	CARBON	8.2K	5%	1/4W	R947	1-249-441-11		100K	5%	1/4W
						R948	1-247-815-91		220	5%	1/4W
R887	1-247-807-31		100	5%	1/4W	R949	1-247-807-31	CARBON	100	5%	1/4W
R888	1-247-807-31	CARBON	100	5%	1/4W	R950	1-247-807-31	CARBON	100	5%	1/4W
R889	1-249-438-11	CARBON	56K	5%	1/4W	R951	1-247-807-31	CARBON	100	5%	1/4W
R890	1-249-441-11	CARBON	100K	5%	1/4W						
R891	1-249-429-11	CARBON	10K	5%	1/4W	R952	1-247-807-31	CARBON	100	5%	1/4W
						R953	1-247-863-91	CARBON	22K	5%	1/4W
R892	1-215-445-00	METAL	10K	1%	1/4W	R954	1-215-433-00	METAL	3.3K	1%	1/4W
R895	1-249-421-11	CARBON	2.2K	5%	1/4W	R955	1-215-433-00	METAL	3.3K	1%	1/4W
R896	1-249-441-11	CARBON	100K	5%	1/4W						
R897	1-247-807-31	CARBON	100	5%	1/4W	R956	1-249-429-11	CARBON	10K	5%	1/4W
R898	1-247-815-91	CARBON	220	5%	1/4W	R957	1-214-800-11	METAL	2.2	1%	1/2W
						R958	1-214-800-11		2.2	1%	1/2W
R899	1-247-815-91	CARBON	220	5%	1/4W	R959	1-215-433-00		3.3K	1%	1/4W
R901	1-249-430-11		12K	5%	1/4W	R960	1-215-451-00		18K	1%	1/4W
R902	1-249-438-11		56K	5%	1/4W	1000	1 213 131 00	WEIRE	1011	170	1/ 1 ***
R903	1-215-421-00		1K	1%	1/4W	R961	1-249-425-11	CARBON	4.7K	5%	1/4W
R904	1-214-800-11		2.2	1%	1/2W	R962	1-214-800-11		2.2	1%	1/2W
IC/OT	1 214 000 11	METILE	2.2	1 /0	1/2 **	R963	1-214-800-11		2.2	1%	1/2W
R905	1-214-800-11	METAI	2.2	1%	1/2W	R964	1-215-433-00		3.3K	1%	1/4W
R906	1-214-800-11		2.2	1%	1/2W	R965	1-215-433-00		3.3K	1%	1/4W
R907	1-247-815-91		220	5%	1/2 W 1/4W	K903	1-213-433-00	WIETAL	3.3K	1 70	1/4 VV
R907	1-247-815-91		220	5%	1/4W	R966	1-247-815-91	CADDON	220	5%	1/4W
R909							1-247-813-91		27K		1/4W
K909	1-215-421-00	METAL	1K	1%	1/4W	R967			27K 27K	1%	
D010	1 215 421 00	METAI	117	1.0/	1 /4337	R968	1-215-455-00 1-215-455-00			1%	1/4W
R910	1-215-421-00		1K	1%	1/4W	R969			27K	1%	1/4W
R911	1-215-455-00		27K	1%	1/4W	R970	1-215-455-00	MEIAL	27K	1%	1/4W
R912	1-215-469-00		100K	1%	1/4W	D071	1 015 455 00	MICTAI	0717	10/	1 / 4337
R913	1-215-455-00		27K	1%	1/4W	R971	1-215-455-00		27K	1%	1/4W
R914	1-215-455-00	METAL	27K	1%	1/4W	R972	1-215-455-00		27K	1%	1/4W
D04#		3. FF(FF) 4. T	2577	4.0.	4 / 4***	R973	1-214-800-11		2.2	1%	1/2W
R915	1-215-455-00		27K	1%	1/4W	R974	1-215-463-00		56K	1%	1/4W
R916	1-215-455-00		27K	1%	1/4W	R975	1-214-800-11	METAL	2.2	1%	1/2W
R917	1-215-455-00		27K	1%	1/4W						
R918	1-215-455-00		27K	1%	1/4W	R976	1-215-433-00		3.3K	1%	1/4W
R919	1-249-435-11	CARBON	33K	5%	1/4W	R977	1-247-815-91		220	5%	1/4W
						R978	1-215-445-00		10K	1%	1/4W
R920	1-214-800-11		2.2	1%	1/2W	R979	1-249-425-11		4.7K	5%	1/4W
R921	1-249-429-11	CARBON	10K	5%	1/4W	R980	1-247-815-91	CARBON	220	5%	1/4W
R922	1-215-445-00	METAL	10K	1%	1/4W						
R923	1-247-863-91	CARBON	22K	5%	1/4W	R981	1-247-815-91	CARBON	220	5%	1/4W
R924	1-215-444-00	METAL	9.1K	1%	1/4W	R983	1-247-815-91	CARBON	220	5%	1/4W
						R984	1-215-444-00	METAL	9.1K	1%	1/4W
R925	1-247-863-91	CARBON	22K	5%	1/4W	R985	1-215-445-00	METAL	10K	1%	1/4W
R926	1-249-408-11	CARBON	180	5%	1/4W	R986	1-215-451-00	METAL	18K	1%	1/4W
R927	1-215-445-00		10K	1%	1/4W						
R928	1-215-445-00		10K	1%	1/4W	R987	1-249-408-11	CARBON	180	5%	1/4W
R929	1-214-800-11		2.2	1%	1/2W	R988	1-215-445-00		10K	1%	1/4W
						R989	1-247-863-91		22K	5%	1/4W
R930	1-214-800-11	METAL	2.2	1%	1/2W	R990	1-249-429-11		10K	5%	1/4W
R931	1-215-445-00		10K	1%	1/4W	R991	1-249-429-11		10K	5%	1/4W
R933	1-215-453-00		22K	1%	1/4W					2,0	-> > ***
R934	1-249-429-11		10K	5%	1/4W	R993	1-247-863-91	CARBON	22K	5%	1/4W
	=> 11			•			. 500 71				

D709

8-719-109-89 DIODE RD5.6ESB2



REF. NO.	PART NO.	DESCRIPTION			REMARK	REF. NO.	PART NO.	DESCRIPTION			REMARK
R996 R997 R998	1-247-815-91 1-215-445-00 1-249-434-11	METAL	220 10K 27K	5% 1% 5%	1/4W 1/4W 1/4W	D710	8-719-991-33	DIODE 1SS133T-7	7		
R999	1-249-434-11		27K	5%	1/4W			<ic></ic>			
		<relay></relay>				IC701	8-759-434-39	IC TDA6106Q			
RY601 ⚠	1-755-018-11	RELAY						<coil></coil>			
		<transformer< td=""><td>l&gt;</td><td></td><td></td><td>L701</td><td>1-410-682-31</td><td>INDUCTOR</td><td>470μΗ</td><td></td><td></td></transformer<>	l>			L701	1-410-682-31	INDUCTOR	470μΗ		
		TRANSFORMER, TRANSFORMER,						<transistor></transistor>			
T503 🛆	1-431-212-11	TRANSFORMER,	HORIZON	TAL I	LINEAR	Q701		TRANSISTOR 2SA			
T504 🗥	1-453-238-11	TRANSFORMER			(007//X4A4)	Q702	8-729-119-76	TRANSISTOR 2SA	A1175-HFE		
		TRANSFORMER,		red (I	DT'			<resistor></resistor>			
		TRANSFORMER,				R701	1-219-743-11	CARBON	100	5%	1/2W
						R702	1-215-425-00		1.5K	1%	1/4W
						R703 R704	1-215-437-00 1-260-132-11		4.7K 560K	1% 5%	1/4W 1/2W
******	********	*******	*****	*****	*****	R705	1-215-424-00		1.3K	1%	1/4W
*	A-1331-777-A	CR BOARD, COM	PLETE			R706	1-215-437-00	METAL	4.7K	1%	1/4W
		*********	*****			R707	1-249-435-11	CARBON	33K	5%	1/4W
						R708	1-215-428-00		2K	1%	1/4W
						R709	1-260-101-11		1.5K	5%	1/2W
		<capacitor></capacitor>				R710	1-215-903-11	METAL OXIDE	68K	5%	2W F
						R711	1-249-435-11	CARBON	33K	5%	1/4W
C702	1-102-959-00		22PF	5%	50V	R712	1-247-807-31		100	5%	1/4W
C703	1-104-664-11		47μF	20%	25V	R713	1-249-437-11		47K	5%	1/4W
C704	1-126-964-11		10μF	20%	50V	R714	1-260-099-11		1K	5%	1/2W
C705 C706	1-161-754-00 1-126-934-11		0.001μF 220μF	10% 20%	2KV 16V	R715	1-260-133-11	CARBON	680K	5%	1/2W
C700	1-120-934-11	ELECT	220μ1	2070	10 V	R717	1-249-417-11	CARBON	1K	5%	1/4W
C707	1-107-504-11	CERAMIC	10PF	0.5PF	500V	R718	1-247-807-31		100	5%	1/4W
C708	1-102-050-00	CERAMIC	$0.01 \mu F$	99%	500V	R719	1-260-087-11	CARBON	100	5%	1/2W
C709	1-162-115-00		330PF	10%	2KV						
C712	1-107-662-11	ELECT	22μF	20%	250V			<spark gap=""></spark>			
								SFARK GAF>			
		<connector></connector>				SG701 SG702	1-519-422-11 1-519-422-11	- ,			
		TAB (CONTACT)									
		PLUG, CONNECT									
		PLUG, CONNECT		70TT) 1	D	****	***	********	b -	********	b -
		PIN, CONNECTOR SOCKET, CRT	R (5MM PI)	(CH) I	P	*****	****	*****	****	~~~~	****
		PLUG, CONNECT	OR 9P			3	<sup>c</sup> A-1331-778-A	CG BOARD, COM			
		<diode></diode>						CADA CITODS			
D701	8-719-991-33	DIODE 1SS133T-7	7					<capacitor></capacitor>			
D701		DIODE 1SS133T-7				C732	1-102-963-00	CERAMIC	33PF	5%	50V
D703		DIODE 1SS133T-7				C733	1-161-754-00		0.001µF	10%	2KV
D704		DIODE 1SS133T-7				C735	1-102-050-00		0.01µF	99%	500V
D705	8-719-923-86	DIODE MTZJ-T-77	7-15			C736	1-162-115-00	CERAMIC	330PF	10%	2KV
						C737	1-107-662-11	ELECT	$22\mu F$	20%	250V
D706		DIODE MTZJ-T-77									
D708		DIODE RD10ESB2									



The componants identified by shading and mark ≜ are critical for safety.
Replace only with part number specified.

REF. NO.	PART NO.	DESCRIPTION			REMARK	REF. NO.	PART NO.	DESCRIPTION			REMARK
		<connector></connector>						<connector></connector>			
CN733 * CN734 *	1-564-510-11 1-564-507-11 1-508-784-00	TAB (CONTACT) PLUG, CONNECT PLUG, CONNECT PIN, CONNECTOI SOCKET, CRT	OR 4P	ГСН) 1	P	CN763 * CN764 △	1-564-507-11 1-508-784-00 1-251-182-11	TAB (CONTACT) PLUG, CONNECTO PIN, CONNECTOI SOCKET, CRT PLUG, CONNECT	R (5MM PI	ГСН) 1	P
		PLUG, CONNECT PLUG, CONNECT				CN766	1-564-513-11	PLUG, CONNECT	OR 10P		
		<diode></diode>						<diode></diode>			
D731 D732 D733	8-719-991-33	DIODE 1SS133T-7 DIODE 1SS133T-7 DIODE RD10ESB	7			D761 D762 D763 D764	8-719-923-86 8-719-110-17	DIODE 1SS133T-7 DIODE MTZJ-T-77 DIODE RD10ESB2 DIODE MTZJ-T-77	7-15 2		
		<ic></ic>						<ic></ic>			
IC731	8-759-434-39	IC TDA6106Q				IC761	8-759-434-39	IC TDA6106Q			
		<coil></coil>						<coil></coil>			
L731	1-410-682-31	INDUCTOR	470μΗ			L761	1-410-682-31	INDUCTOR	470μΗ		
		<resistor></resistor>						<resistor></resistor>			
R731 R732 R733 R735 R736 R737 R738 R739 R740 R741 R742 R743	1-219-743-11 1-260-132-11 1-215-421-00 1-249-441-11 1-215-430-00 1-260-101-11 1-215-903-11 1-260-133-11 1-260-099-11 1-215-435-00 1-247-885-00 1-247-807-31 1-519-422-11 1-519-422-11	CARBON METAL CARBON METAL CARBON METAL OXIDE CARBON CARBON METAL CARBON METAL CARBON METAL CARBON CARBON CARBON CARBON CARBON CARBON CARBON	100 560K 1K 100K 2.4K 1.5K 68K 680K 1K 3.9K 180K 100	5% 5% 1% 5% 1% 5% 5% 5% 5% 5% 5%	1/2W 1/4W 1/4W 1/4W 1/4W 1/2W 1/2W 1/2W 1/4W 1/4W	R761 R762 R763 R764 R765 R766 R767 R768 R769 R770 R771	1-260-133-11 1-260-099-11 1-247-807-31 1-260-087-11 1-519-422-11	CARBON METAL CARBON METAL CARBON METAL OXIDE CARBON CARBON CARBON	100 560K 910 5.6K 2.4K 1.5K 68K 680K 1K 100	5% 5% 1% 5% 1% 5% 5% 5% 5% 5%	1/2W 1/2W 1/4W 1/4W 1/4W 1/2W 1/2W 1/2W 1/2W 1/2W
*****************						**************************************					
*	A-1331-779-A	CB BOARD, COM						********	*****		
							A-1372-474-A	HA MOUNT (VAR	2)		
		<capacitor></capacitor>						<capacitor></capacitor>			
C762 C763 C765 C766 C767	1-102-963-00 1-161-754-00 1-102-050-00 1-162-115-00 1-107-662-11	CERAMIC CERAMIC CERAMIC	33PF 0.001μF 0.01μF 330PF 22μF	5% 10% 99% 10% 20%	50V 2KV 500V 2KV 250V	C1301 C1302 C1304 C1305 C1306	1-130-495-00 1-126-959-11 1-126-964-11 1-130-495-00 1-126-964-11	ELECT ELECT FILM	0.1μF 0.47μF 10μF 0.1μF 10μF	5% 20% 20% 5% 20%	50V 50V 50V 50V 50V



REF. NO.	PART NO.	DESCRIPTION			REMARK	REF. NO.	PART NO.	DESCRIPTION			REMARK
C1307	1-126-964-11	ELECT	10μF	20%	50V	*	A-1390-826-A	Z BOARD, COMP.			
		<connector></connector>					4-382-854-11	SCREW (M3X10),	P, SW (+)		
CN1302	* 1-564-526-11	PLUG, CONNECT PLUG, CONNECT	OR 11P					<capacitor></capacitor>			
CN1304	* 1-364-318-11	PLUG, CONNECT	OR 3P			C1433 C1434	1-106-343-00 1-106-383-00		0.001μF 0.047μF	10% 10%	200V 200V
		<diode></diode>				C1435 C1436	1-107-667-11 1-137-364-11	ELECT FILM	2.2μF 0.001μF	20% 5%	160V 50V
D1301 D1302 D1303	8-719-110-17	DIODE RD10ESB2 DIODE RD10ESB2 DIODE RD10ESB2	2			C1437 C1438	1-137-364-11 1-106-383-00		0.001μF 0.047μF	5% 10%	50V 200V
D1304 D1305	8-719-053-43	DIODE SLR-325V DIODE SLR-325V	CT31			C1439 C1440	1-161-830-00 1-126-933-11	CERAMIC	0.0047μF 100μF	20%	500V 16V
D1306		DIODE RD10ESB2				C1441 C1443	1-102-074-00 1-126-935-11	CERAMIC	0.001μF 470μF	10% 20%	50V 16V
D1307 D1308	8-719-110-17	DIODE RD10ESB2 DIODE RD10ESB2	2			C1444	1-107-639-11		47μF	20%	160V
D1309	8-719-109-89	DIODE RD5.6ESB	32			C1445 C1446	1-126-933-11 1-126-933-11		100μF 100μF	20% 20%	16V 16V
		<ic></ic>						<connector></connector>			
IC1301	8-742-088-10	HYB IC SBX1780-	-51(10)					PLUG, CONNECT			
		<jack></jack>				CN1403 *	1-564-506-11	PLUG, CONNECT PLUG, CONNECT PLUG, CONNECT	OR 3P		
J1301	1-770-361-11	TERMINAL BLOO	CK, S					PLUG, CONNECT			
		<resistor></resistor>				CN1433 *	1-564-507-11	PLUG, CONNECT PLUG, CONNECT	OR 4P		
R1301	1-249-425-11	CARBON	4.7K	5%	1/4W	CN1461 *	1-564-506-11	PIN, CONNECTOR PLUG, CONNECT	OR 3P	RD) 4I	2
R1302 R1303	1-249-416-11 1-249-417-11		820 1K	5% 5%	1/4W 1/4W	CN1462*	1-564-507-11	PLUG, CONNECT	OR 4P		
R1304	1-249-425-11	CARBON	4.7K	5%	1/4W			PLUG, CONNECT			
R1305	1-247-815-91	CARBON	220	5%	1/4W	CN 1464 *	1-564-507-11	PLUG, CONNECT	OR 4P		
R1306 R1307	1-247-815-91 1-249-420-11		220 1.8K	5% 5%	1/4W 1/4W			<diode></diode>			
R1307	1-247-895-91		470K	5%	1/4W 1/4W			<diode></diode>			
R1309 R1310	1-247-895-91		470K 10K	5% 5%	1/4W 1/4W	D1431 D1432		DIODE RD39ESB2			
K1310	1-249-429-11	CARBON	10K	370	1/4 VV	D1432 D1433		DIODE 1SS133T-7			
R1311	1-247-804-11		75 75	5%	1/4W						
R1312 R1314	1-247-804-11 1-247-807-31		75 100	5% 5%	1/4W 1/4W			<connector></connector>			
R1315	1-247-804-11		75	5%	1/4W	DV1/21	1 451 454 11	DEFLECTION YO	VE		
		<switch></switch>				D11431	1-431-434-11	DEFECTION TO	KE		
61201	1 572 100 11	ONTEGU KENDO	ADD					<coil></coil>			
S1301 S1302		SWITCH, KEYBO SWITCH, KEYBO				L1431	1-410-478-11	INDUCTOR	47μΗ		
S1303		SWITCH, KEYBO				L1432	1-410-478-11	INDUCTOR	47μΗ		
S1304 S1305		SWITCH, KEYBO SWITCH, KEYBO									
S1306		SWITCH, KEYBO						<transistor></transistor>			
S1307	1-572-198-11	SWITCH, KEYBO	ARD			Q1431 Q1432		TRANSISTOR 2SO TRANSISTOR 2SO			
						Q1432 Q1433		TRANSISTOR 2SA			
******	******	******	*******	****	******	Q1434 Q1435	8-729-119-78	TRANSISTOR 2SO TRANSISTOR 2SO	C2785-HFE		
			, , , , , , , , , , , , , , , , , , , ,	011 201							





The componants identified by shading and mark ≜ are critical for safety.
Replace only with part number specified.

REF. NO.	PART NO.	DESCRIPTION		REMARI	REF. NO. PART	ΓNO.	DESCRIPTION	REMARK
Q1436	8-729-119-78	TRANSISTOR 2SC	2785-HFE					
					1-505	5-378-11	SPEAKER (10CM)	
					1-556	5-945-21	CABLE, P-P	
		<resistor></resistor>					CABLE, P-P	
							CORD, POWER (WITH NOISE I	FILTER)
R1401	1-249-414-11		560 5%		8-598	3-414-00	ANTENNA SWITCH AS-2F	
R1402	1-249-414-11		560 5%					
R1415		METAL OXIDE	120 5%		△ 8-733	3-528-05	PICTURE TUBE 07MAC3 (B)	
R1418		METAL OXIDE	120 5%					ND SPRING)
R1431	1-249-414-11	CARBON	560 5%	6 1/4W			PICTURE TUBE 07MXC2 (G)	
D 1 100	1 240 414 11	CARRON	560 50	1 (4557	△ 8-/33	3-553-05	PICTURE TUBE 07MXC3 (R)	
R1432	1-249-414-11		560 5% 120 5%					
R1435 R1436		METAL OXIDE METAL OXIDE	120 5% 120 5%					
R1430 R1437	1-249-414-11		560 5%		*********	******	**********	******
R1437 R1438	1-249-414-11		18K 5%					
K1436	1-249-432-11	CARDON	101 37	0 1/4 VV	ACCI	FSSORIE	ES AND PACKING MATERIALS	
R1439	1-249-432-11	CARBON	18K 5%	6 1/4W			*********	
R1440	1-249-414-11		560 5%					
R1441	1-249-417-11		1K 5%		3-862	2-541-41	MANUAL, INSTRUCTION	
R1442	1-249-408-11		180 5%				BOARD, TOP	
R1443	1-249-377-11	CARBON	0.47 5%	6 1/4W F			SHEET, PROTECTION	
					* 4-041	1-425-01	BAG, PROTECTION	
R1445	1-249-403-11	CARBON	68 5%	6 1/4W	* 4-057	7-651-02	CUSHION (UPPER) (ASSY)	
R1448	1-249-416-11	CARBON	820 5%	6 1/4W				
R1449	1-249-403-11	CARBON	68 5%	6 1/4W			CUSHION (LOWER) (ASSY)	
R1450	1-249-417-11	CARBON	1K 5%	6 1/4W			INDIVIDUAL CARTON	
R1451	1-249-411-11	CARBON	330 5%	6 1/4W		7-658-01		
					* 4-057	7-659-01	BOARD, BOTTOM	
R1452	1-249-417-11		1K 5%				DELLOWE GOLD CLUBER	
R1453	1-249-401-11		47 5%				REMOTE COMMANDER  ***********************************	
R1454	1-260-311-11		39 5%				******	
R1455	1-249-384-11		1.8 5%		1 472	2 740 21	DEMOTE COMMANDED (DM V	12(4)
R1456	1-215-916-00	METAL OXIDE	680 5%	6 3W F			REMOTE COMMANDER (RM-Y POCKET, COVER (FOR RM-Y13)	
R1457	1-249-417-11	CARBON	1K 5%	6 1/4W F				
R1458	1-249-384-11		1.8 5%					
R1459	1-249-400-11	CARBON	39 5%	6 1/4W F				
R1460	1-215-916-00	METAL OXIDE	680 5%	3W F				
R1461	1-249-414-11	CARBON	560 5%	6 1/4W				
R1462	1-249-414-11	CARRON	560 5%	6 1/4W				
R1462 R1464	1-249-414-11		1K 5%					
R1465		METAL OXIDE	120 5%					
R1466		METAL OXIDE	120 5%					
		e ske ske ske ske ske ske ske ske ske sk						
~~~~~	~~~~~~~	······································	*******	*****				
		MISCELLANEOUS						
<u> </u>	1-223-925-11	RESISTOR ASSY	(HIGH-VOLT	AGE)				
		DEEL ECTION VO		- /	1			

Sony Ichinomiya Corporation

Quality Assurance Division

 $\triangle$  1-451-454-11 DEFLECTION YOKE (G)  $\triangle$  1-451-455-31 DEFLECTION YOKE (R) (B)

1-452-909-11 MAGNET ASSY, 4 POLE

**1-452-790-21 NECK ASSY 1-452-790-21 NECK ASSY**